A practical approach to scale

- Use Clos topologies:
 - Use many low-radix switches in multiple stages to scale to arbitrary size
 - Substantial path diversity and redundancy
- Merchant silicons
 - off-the-shelf, allows regular and rapid upgrades