


Set Zebra Scanner to USB-OPOS

Scan this barcode once — no PC or software required.

The scanner resets and re-enumerates directly as USB-OPOS.



OPOS (IBM Hand-Held with Full Disable)

USB OPOS host variant

When to use

AlleavesAuto sets USB-OPOS automatically during install. Use this sheet only when no scanner was attached during the run, or in a no-PC situation — the end result is identical.

How it works

Works from the factory USB-Keyboard-HID default in a single scan. Model-agnostic across Zebra USB scanners (DS2208, DS4608, DS8108, DS9308, LI2208, MP7000, ...). The host PC still needs the Zebra OPOS / CoreScanner driver (installed by AlleavesAuto) for an application to read the scanner.

To revert

Scan "USB HID Keyboard" / "Set Defaults" from the scanner's Product Reference Guide, or use 123Scan. The OPOS switch is permanent and survives power cycles.