Question 1 from Task1

What type of cable is used to connect the Ethernet interface on a host PC to the Ethernet interface on a
switch?
Ans: **Copper Straight-through cable**

What type of cable is used to connect the Ethernet interface on a switch to the Ethernet interface on a Router?
Ans: **Copper Straight-through cable**

What type of cable is used to connect the Ethernet interface on a router to the Ethernet interface on a Host PC?
Ans: **Copper Cross-Over cable**

Question 2 from Task 2

When the prompt returns, issue the reload command. Answer no if asked to save changes. What would happen if you answered yes to the question, “System configuration has been modified. Save?”
Ans: **Answering YES stores the current running configuration in NVRAM, ensuring the changes are permanently saved.**

Question 3 Task 3

Why would you want to disable DNS lookup in a lab environment?
Ans: **In a lab environment, DNS lookup is turned off to avoid delays and unnecessary DNS requests, since access to external websites or the internet is not needed.**

What would happen if you disabled DNS lookup in a production environment?
Ans: **Turning off DNS lookup in a production environment would stop domain names from being resolved, meaning users would have to use IP addresses to access websites, and any services that rely on DNS would stop functioning properly.**

Question 4 from Task 3

Why is it not necessary to use the enable password password command?
Ans: **The enable password command stores the password in plain text, which means it can be easily viewed in the configuration file**

Question 5 Task 3

When does this banner display?
Ans: **The banner appears as soon as someone connects to the router terminal, before the login process begins.**

Why should every router have a message-of-the-day banner?
Ans: **It is used to alert users and present important or legal notices before they log in.**

Question 6 Task 3

What is a shorter version of this command?
Ans: **copy run start**

Question 7 Task 6


From the host attached to R1, is it possible to ping the default gateway?
Ans: **Yes**
From the host attached to R2, is it possible to ping the default gateway
Ans: **Yes**


Question 8 Task 6


from the router R1, is it possible to ping R2 using the command ping 192.168.2.2?
Ans: **Yes**
From the router R2, is it possible to ping R1 using the command ping 192.168.2.1?
Ans: **Yes**


Question 9 Task 7

What is missing from the network that is preventing communication between these devices?
Ans: **This happens because there is no routing path configured between R2 and R1. In particular, R2 does not have a static route or a dynamic routing protocol entry that tells it how to reach R1's network.**




Cisco Packet Tracer - /home/rafi/Downloads/421/Lab/Basic_Router_Config.pka - Guest - 2026-02-25 15:29:57
File Edit Options View Tools Extensions Window Help
Logical
Physical
x: 407, y: 147
PC-PT
PC1
2960-24TT
S1
1841
R1
Time: 00:03:23
(Select a Device to Drag and Drop to the Workspace)
R2
Physical
Config
CLI
Attributes
IOS Command Line Interface
Press RETURN to get started.
!!!AUTHORIZED ACCESS ONLY!!!
User Access Verification
Password:
R2>enable
Password:
Password:
R2#show ip route
Codes: C - connected, S - static, I - IGRP, R - RIP, M - mobile, B - BGP
D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
E1 - OSPF external type 1, E2 - OSPF external type 2, E - EGP
i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area
* - candidate default, U - per-user static route, o - ODR
P - periodic downloaded static route
Gateway of last resort is not set
C 192.168.2.0/24 is directly connected, Serial0/0/0
C 192.168.3.0/24 is directly connected, FastEthernet0/0
R2#
Copy
Paste
Top


****
!!!AUTHORIZED ACCESS ONLY!!!
****
User Access Verification
Password:
R1>enable
Password:
R1#show ip route
Codes: C - connected, S - static, I - IGRP, R - RIP, M - mobile, B - BGP
D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
E1 - OSPF external type 1, E2 - OSPF external type 2, E - EGP
i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area
* - candidate default, U - per-user static route, o - ODR
P - periodic downloaded static route
Gateway of last resort is not set
C 192.168.1.0/24 is directly connected, FastEthernet0/0
C 192.168.2.0/24 is directly connected, Serial0/0/0
R1#
R1#show ip interface brief
Interface IP-Address OK? Method Status Protocol
FastEthernet0/0 192.168.1.1 YES manual up up
FastEthernet0/1 unassigned YES NVRAM administratively down down
Serial0/0/0 192.168.2.1 YES manual up up
Serial0/0/1 unassigned YES NVRAM administratively down down
Vlan1 unassigned YES unset administratively down down
R1#
Copy
Paste
Top


****
!!!AUTHORIZED ACCESS ONLY!!!
****
User Access Verification
Password:
R2>enable
Password:
Password:
R2#show ip route
Codes: C - connected, S - static, I - IGRP, R - RIP, M - mobile, B - BGP
D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
E1 - OSPF external type 1, E2 - OSPF external type 2, E - EGP
i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area
* - candidate default, U - per-user static route, o - ODR
P - periodic downloaded static route
Gateway of last resort is not set
C 192.168.2.0/24 is directly connected, Serial0/0/0
C 192.168.3.0/24 is directly connected, FastEthernet0/0
R2#show ip interface brief
Interface IP-Address OK? Method Status Protocol
FastEthernet0/0 192.168.3.1 YES manual up up
FastEthernet0/1 unassigned YES NVRAM administratively down down
Serial0/0/0 192.168.2.2 YES manual up up
Serial0/0/1 unassigned YES NVRAM administratively down down
Vlan1 unassigned YES unset administratively down down
R2#
Copy
Paste
Top