Yushin robo Z Axis Zero position teaching procedure

Yushin robo X, Y, Z Axis Zero position teaching procedure

1 service man login

PW ushiny

2 home position page

3 choose axis

4 traverse

5 initialize

Motor on

6 manual mode (break not control slowly move

7 holes match line straight / or zero position marking

8 set home position

9 logout