Working with discrete signals

Lab 2, DSP

Objective

Students should gain knowledge on some of the basic Matlab functions for handling discrete signals

Theoretical aspects

The following aspects shall be explained

- 1. Plotting data signals (vectors)
 - multiple plots on same graph
 - plot options
 - sub-figures
- 2. Loading / saving data from .mat files
- 3. Working with audio data
 - importing signals from audio files (audioread() function)
 - playing signals through the speaker
- 4. Applying windows to signals
 - concept of window
 - Hann window in Matlab

Exercises

1. Plot on the same figure the signals $sin(2\pi ft)$ and $cos(2\pi ft)$, with f=0.3 and $t\in[0,10]$.

- 2. Save the vectors above in the file 'mysave.mat'. Clear the variables from the Matlab workspace, then load them back from 'mysave.mat'
- 3. Load the audio file 'sound.wav' in the Matlab workspace
 - a. Play it through the computer's audio device
 - b. Change the sampling frequency to half the correct value, and play again. How will the sound be changed?
 - c. Amplify the sound by multiplying the data by 4. Play the sound and observe the difference.
 - d. Swap the left and right channels (it's a stereo file).
 - e. Apply the Hann window to the audio signal (to both channels) and play it.
- 4. Generate a long signal (1000000 elements) looking like [1, -1, 1, -1, ...] and play it using Fs = 8000. What signal is generated? What is it's frequency? Hints:
 - what is the discrete frequency of the signal?
 - what is the analog frequency reconstructed?
- 5. Generate and play a 3 seconds long sinusoidal signal with f=2000Hz, considering Fs=8000Hz

Final questions

1. TBD