
Digital Signal Processing

I. Sampling of analog signals

I.1. Analog and Digital Signals

Signals

- ► Signal = a measurable quantity which varies in time, space or some other variable
- **Examples**:
 - ▶ a voltage which varies in time (1D voltage signal)
 - sound pressure which varies in time (sound signal)
 - intensity of light which varies across a photo (2D image)
- ▶ Represented as a mathematical function, e.g. v(t).



Glossary


- ► Glossary:
 - "e.g." = "exampli gratia" (lat.) = "for example" (eng.) = "de exemplu" (rom.)
 - ▶ "i.e." = "id est" (lat) = "that is" (eng.) = "adică" (rom.)

Signal dimension

- **Unidimensional** (1D) signal = a function of a single variable
 - **Example:** a voltage signal $\underline{v}(t)$ only varies in time.
- ► Multidimensional (2D, 3D ... M-D) signal = a function of a multiple variables
 - Example: intensity of a grayscale image I(x, y) across the surface of a photo
- ▶ In these lectures we consider only 1D signals, but the theory is similar

Continuous and discrete signals

- ► Continuous (analog) signal = function of a continuous variable
 - ▶ Signal has a value for possible value of the variable in the defined range
 - ▶ The variable may be defined only in a certain range (e.g. $t \in [0, 100]$), but it is a compact range
- ▶ Discrete signal = function of a discrete variable
 - ► Signal has values only at certain discrete values (samples)
 - ▶ Indexed with natural numbers: x[-1], x[0], x[1] etc.
 - Outside the samples, the signal is not defined



Notation


- ► We use the following notation:
- Continuous signal
- $\chi(t)$
 - ightharpoonup Has **round parantheses**, e.g. $x_a(t)$ Sometimes has the a subscript

 - The variable is usually t (time)
 - \triangleright x(2.3) = the value of the signal a(t) at t = 2.3
- Discrete signal
 - Has square brackets, e.g. x[n]
 - ightharpoonup The variables are denoted as n or k (suggest natural numbers)
 - \triangleright x[3] =the value of the signal x[n] for n = 3
 - \triangleright x[1.5] = does not exist





Signals with continuous and discrete values




- ▶ Not only the time can be <u>continuo</u>us or <u>discrete</u>
- ► The signal **values** can also be continuous or discrete
 - Example: signal values stored as 8-bit or 16-bit values
- On digital systems, signals always have discrete values due to finite number precision

Discrete frequency

- A signal is **periodic** if the values repeat themselves after a certain time (**period**)
- ► Frequency = inverse of period
- ▶ Pulsation $\omega = 2 * \pi * frequency$
- Continuous signals:
 - Periodic: $x_a(t) = x(t+T)$
 - T is usually measured in seconds (or some other unit) $F = \frac{1}{T} \text{ is measured in Hz} = \frac{1}{s} \text{ (Hertz)}$
- Discrete signals:
 - Periodic: x[n] = x[n + N]
 - N has no unit, because it is just a number

$$f = \frac{1}{N} \text{ has no unit} \text{ also}$$







f = 1 = 10 Hz

Frequency limits







▶ Because period
$$T$$
 can be $T \rightarrow 0$



- \triangleright Smallest period is N=2 (excluding N=1, constant signals)
- \triangleright Consequence of using natural numbers to index the samples (x[0], x[1], x[2]...), without any physical unit attached
- For mathematical reasons, we will consider negative frequencies as well (remember SCS) (e.g. $-\omega$)

$$\cos(2\pi f_{\alpha}) = 511$$
 forwer














Domain of definition

$$\times$$
 [M]


- **Finite-length** discrete signals x[n]:
 - have only a certain number N of samples (e.g. for n = 0, 1, ... N-1)
 - they are not defined outside these samples
 - can be represented as a **vector** of numbers (e.g. like in Matlab, C)
- ▶ **Infinite-length** discrete signals x[n]:
 - e.g. defined for n = ... 2, -1, 0, 1, 2, ... or





Vector space of signals

- ► All signals of a certain length *N* form a **vector space**
- In mathematics, a vector space = a set V of elements {v} (called "vectors") such that:
 - ightharpoonup the sum of any two elements from V is still a member of V
 - lacktriangle any vector from V multiplied by a constant is still a member of V
- ► These properties can easily be verified for signals




I.2. Sampling

Sampling

- ► Sampling = Taking the values from an analog signal at certain discrete moments of time, usually periodic
- ightharpoonup Distance between two samples = sampling period T_s
- **Sampling frequency** $F_s = \frac{1}{T_s}$
- ► Why sampling?
 - Converts continuous signals to discrete
 - Processing of continuous signals is expensive
 - Processing of discrete signals is cheap (digital devices)
 - Sometimes nothing is lost due to sampling

Graphical example



$$x[s] = X\alpha(s \cdot Ts)$$

$$x[m] = X\alpha(m \cdot Ts)$$

Sampling equation

► Mathematically, it is described by **the sampling equation**:

$$x[n] = x_a(n \cdot T_s)$$

- ▶ Produces a discrete signal x[n] from a continuous signal $x_a(t)$
- The *n*-th value of the discrete signal x[n] is the value of the analog signal $x_a(t)$ taken after *n* sampling periods, at time $n \cdot T_s$

Sampling of harmonic signals

Let's sample a cosine:
$$x_a(t) = cos(2\pi Ft)$$

$$x[n] = x_a(nT_s)$$

$$= cos(2\pi F nT_s)$$

$$= cos(2\pi F n \frac{1}{F_s})$$

$$= cos(2\pi F \frac{1}{F_s})$$

$$X_{ol}(t) = 2 \cdot \omega_{S} \left(z_{T} \cdot (1 + \omega_{S} \cdot t) \right)$$

$$Somple with $T_{S} = 3 \text{ MHz}$


$$X_{Ol}(t) = 2 \cdot \omega_{S} \left(z_{T} \cdot (1 + \omega_{S} \cdot t) \right)$$

$$Z_{Ol}(t) = 2 \cdot \omega_{S} \left(z_{T} \cdot (1 + \omega_{S} \cdot t) \right)$$$$

$$X[M] = 2.000 \left(2\Pi \cdot \begin{bmatrix} 3 \\ 3 \end{bmatrix} \cdot M\right)$$

Pmax = =

$$f = \frac{F}{F_s}$$



Discrete frequency is relative

$$f = \frac{F}{F_s}$$

- Discrete frequency should be understood as a value **relative to the** sampling frequency
- lacksquare Example: $f=rac{1}{4}$ means "coming from an analog frequency F which was $\frac{1}{4}$ of the sampling frequency"


 - It could have been a 100Hz signal sampled with 400Hz => 100Hz it could also have been a 100Hz signal sampled with 12MHz = 100Hz =

$$f = \frac{1}{2} = \frac{F}{Fs}$$

$$f = \frac{1}{5} = \frac{1}{5}$$
 the $\frac{1}{5}$

False friends

Note: A discrete sinusoidal signal might not *look* sinusoidal, when its frequency is high (close to $\frac{1}{2}$).



Sampling theorem (Nyquist-Shannon)

The Nyquist-Shannon sampling theorem:

If a signal $x_a(t)$ that has maximum frequency F_{max} is sampled with a a sampling frequency $F_s \ge 2F_{max}$,

then it can be perfectly reconstructed from its samples using the formula:

$$x_a(t) = \sum_{n=-\infty}^{+\infty} x[n] \cdot \frac{\sin(\pi(F_s t - n))}{\pi(F_s t - n)}.$$

$$f_{s} \geq 2 \cdot F_{max}$$

$$f \leq \frac{1}{2}$$

Comments on the sampling theorem

- All the information in the original signal is contained in the samples, provided the sampling frequency is high enough
- ► It is much easier to process discrete samples instead of onalog signals (e.g. using Matlab instead of capacitors :))
- Sampling with $F_s \geq 2F_{max}$ makes the discrete frequency smaller than 1/2

$$f = \frac{F}{F_s} \le \frac{F_{max}}{F_s} \le \frac{1}{2}$$

Example of the sampling theorem in action

Sampling theorem in action:

- ► Humans can only hear sounds up to ~20kHz
- ▶ Use sampling rates higher than 40kHz => no quality loss
 - ► Standardized for CD-Audio: 44100Hz

Aliasing

- http://www.dictionary.com/browse/alias:
 - "alias": a false name used to conceal one's identity; an assumed name
- ▶ What happens when the sampling frequency is not high enough?
- Example: F = 600Hz sampled with $F_s = 1000Hz$


$$x[n] = x_a(nT_s)$$

$$= cos(2\pi600nT_s)$$

$$= cos(2\pi600n\frac{1}{1000})$$

$$= cos(2\pi\frac{6}{10}n)$$

Bad sign: We get a frequency larger than $f_{max} = \frac{1}{2}$



(es (2T 400 t) 1 (es (2T 4 m)

nough?

$$X_{\alpha}(t) = cos(2\pi \cdot 600 \cdot t)$$

$$X_{\alpha}(t) = cos(2\pi \cdot 6 \cdot m)$$

$$= cos(2\pi \cdot 4 \cdot m)$$

$$= cos(2\pi \cdot 6 \cdot m)$$

Funny things with cos() and sin()

- ▶ Discrete cos() and sin() have funny properties
- ▶ They are **the same** when adding an integer to the frequency:

$$\cos(2\pi(f+k)n) = \cos(2\pi fn + (2kn\pi) = \cos(2\pi fn))$$

► So all these discrete frequencies are identical:


$$f = \dots = (-1.4) = (-0.4) = (0.6) = (1.6) = (2.6) = (3.6) = \dots$$

▶ In addition, negative frequencies can be turned into positive:


$$\cos(2\pi(-f)n) = \cos(2\pi f n)$$

$$\sin(2\pi(-f)n) = -\sin(2\pi fn)$$

$$X[M] = \cos\left(2\pi f_{M}\right) = \cos\left(2\pi f_{M}\right)$$




Aliasing



Aliasing:


- Every discrete frequency f outside the interval $\left[-\frac{1}{2},\frac{1}{2}\right]$ is **identical** (an "alias") with a frequency from this interval $f_{alias} \in \left[-\frac{1}{2},\frac{1}{2}\right]$
- ▶ Just add or subtract 1's to f until the result is in $\left[-\frac{1}{2}, \frac{1}{2}\right]$

Aliasing example - low frequency signal




) = 400 Hz

Aliasing example - high frequency signal, same samples



600 H2

Aliasing example - samples only



The problem of aliasing

- Sampling different signals can lead to exactly same samples
- ▶ Problem: how to know from what signal did the samples come from? Impossible.
- **Example:**
 - ▶ all these discrete frequencies are identical:

$$f = -0.4 = 0.4 = 0.6 = 1.6 = \dots$$

- ▶ so if $F_s = 1000 Hz$, the original signal could have been any frequency F out of: 400Hz or 600Hz or 1400Hz or 1600Hz or ...
- Exercise: check some of these


Anti-alias

- Aliasing only affects digital signals (it is caused by sampling)
- Sampling according to Shannon theorem guarantees no aliasing:

$$F_s \ge 2F_{max} \Rightarrow f = \frac{F}{F_{max}} \le \frac{1}{2}$$

▶ Better remove from the signal the frequencies larger than $\frac{F_s}{2}$, which will not be sampled correctly, otherwise they will create a false frequency and bring confusion

Anti-alias



- Anti-alias filter: a low-pass filter situated before a sampling circuit, rejecting all frequencies $F > \frac{F_s}{2}$ from the signal before sampling
 - ► Standard practice in the design of processing systems

ADC

Ideal signal reconstruction from samples

Sourping
$$t \rightarrow \frac{m}{fs}$$

Rec: $m \rightarrow t.ts$

- ► Reconstruction = opposite of sampling
- Produces a continuous signal from a discrete one

Ideal reconstruction equation:

$$x_r(t) = x[\frac{t}{T_s}] = x[\underbrace{t \cdot F_s}]$$

A discrete frequency f becomes $F = f \cdot F_s$

Reconstruction and aliasing

- ▶ What value to use for *f*?
 - \blacktriangleright we know f = f + 1 = f + 2 = ..., which one to use?
- ▶ The reconstruction assumes all f are in the interval $[-\frac{1}{2}, \frac{1}{2}]$
 - ► apply reconstruction equation
 - ▶ the resulting signal has all frequencies $F \leq \frac{F_s}{2} = F_N$ (= "the Nyquist frequency")
- ▶ In exercises: Always bring f in the interval $\left[-\frac{1}{2}, \frac{1}{2}\right]$ before reconstruction
- Reconstruction always produces signals with frequencies in $\left[-\frac{F_s}{2}, \frac{F_s}{2}\right]$
 - Only signals or components sampled according to the sampling theorem will be reconstructed identically
 - ▶ Any other components are replaced with their aliased counterparts

A/D and D/A conversion



- ► Sampling + quantization + coding is usually done by an **Analog to Digital Converter (ADC)**
 - It takes an analog signal and produces a sequence of binary-coded values
- Reconstructing an analog signal from numeric samples is done by a <u>Digital</u> to Analog Converter (DAC)
 - Usually the reconstruction is not based on sampling theorem equation, which is too complicated, but with simpler empirical solutions
- You have <u>ADCs</u> and <u>DACs</u> for any In or Out audio jack (phone, computer etc)



Signal quantization and coding

- ▶ In practice, the amplitudes of the samples are converted to binary representation
- ▶ Because of this, the amplitudes are rounded to fixed levels, e.g. 8-bit values (256 distinct levels), 16-bit values (65536).
- ► This "rounding" is known as quantization
- ► The "rounding error" is known as **quantization error**
- Converting the value to binary form is known as coding
- ▶ ADCs handle sampling, quantization and coding simultaneously