# Implementing digital FIR filters in the lattice form

Lab 7, SDP

### **Table of contents**

1	Objective	1
2	Theoretical notions	1
3	Theoretical exercises	2
4	Practical exercises	2
5	Final questions	4

# 1 Objective

The students should become familiar with lattice-type realization structure used for implementing FIR filters.

#### 2 Theoretical notions

Lattice form for an FIR filter of order 3:

Equations:




Figure 1: Lattice form, order 3

$$\begin{split} A_0(z) &= B_0(z) = 1 \\ A_m(z) &= A_{m-1}(z) + K_m \cdot z^{-1} \cdot B_{m-1}(z) \\ A_{m-1}(z) &= \frac{A_m(z) - K_m \cdot B_m(z)}{1 - K_m^2} \\ B_m(z) &= z^{-m} B_m(z^{-1}) = \text{ like } A_m(z), \text{ with coefficients reversed} \end{split}$$

These equations allow to convert H(z) to the reflection coefficients needed by the lattice implementation, or to find H(z) from a given lattice implementation.

#### 3 Theoretical exercises

- 1. Find the FIR filter coefficients in direct form, if the reflection coefficients of the lattice FIR structure are:  $K_1 = \frac{1}{2}$ ,  $K_2 = 0.6$ ,  $K_3 = -0.7$ ,  $K_4 = \frac{1}{3}$ .
- 2. Find the reflection coefficients of the lattice structure for a FIR filter with system function:

$$H(z) = 1 + \frac{2}{5}z^{-1} + \frac{7}{20}z^{-2} + \frac{1}{2}z^{-3}$$

#### 4 Practical exercises

- 1. In Matlab, use the fdatool tool to design one of the following filters:
  - a. A low-pass FIR filter of order 5, equiripple type, with cutoff frequency around 5kHz (transition band from 4.8kHz to 5.2 kHz) at a sampling frequency of 44.1kHz;
  - b. A high-pass FIR filter of order 5, equiripple type, with cutoff frequency around 1kHz (transition band from 900Hz to 1.1 kHz) at a sampling frequency of 44.1kHz;

c. A band-pass FIR filter of order 5, equiripple type, with passband around 700Hz to 4Hz (transition bands from 600Hz to 800 Hz, and from 3.9kHz to 4.1 kHz) at a sampling frequency of 44.1kHz.

Note: for this type of filter, fdatool requires not the cutoff frequency, but the limits of the transition band around that cutoff frequency.

2. Export the filter coefficients to Matlab Workspace, with the name Num.

Use the tf2latc() function from Matlab to convert the coefficients Num of the transfer function to coefficients of the *lattice* form. Name the resulting vector K and display it.

Afterwards, use the inverse function latc2tf() to convert the coefficients K of the *lattice* form back into coefficients of the direct forms, and check that we obtain the same values as in Num.

#### Note 1:

• It is possible that you get the following error when tf2latc():

```
Error using levdown At least one of the reflection coefficients is equal to one. The algorithm fails for this case.
```

This happens because the vector Num is symmetrical (first coefficient equal to last, etc) (is a linear-phase filter).

As a workaround, we must forcefully break the symmetry, for example by adding a small  $\epsilon$  to the first coefficient:

```
Num(1) = Num(1) + 0.0000001
```

#### Note 2:

• Using latc2tf() you will not obtain back the same values as in Num, but instead the values divided to the first entry, Num / Num(1). This is because the *lattice* form requires that the first coefficient of H(z) is always 1.

Therefore, the coefficients in K don't actually implement the filter Num, but actually the filter Num / Num(1). This means that in the Simulink model the input signal must first be passed through an additional Gain block with value Num(1) (i.e.  $b_0$ ), before it is fed into the *lattice* structure.

- 3. In Simulink, implement the FIR filter in *lattice* form.
  - a. Build the schematic, putting in the Gain blocks the coefficients from the vector K (K(1), K(2), etc)

- b. At the output put a visualization block ("Scope") and display the impulse response (input "Discrete Impulse") and the step response (input "Step").
- 4. In Matlab, create a function to filter a vector  $\mathbf{x}$  with a FIR system with known *lattice* coefficients K, obtaining the output vector  $\mathbf{y}$ .

Find a way to compute the output y[n] at some time moment n, based on the schematic. In other words, if we know the schematic, how can we implement it in the form of equations or lines of code?

You can use the following guiding template:

```
function y = filter_lattice_FIR(K, x)
% Filter the vector x with a lattice FIR filter with coefficients K

ord = length(K);
% Write code here:

for i=1:length(x)
    y(n) = ...
end
```

5. Test this function, by calling it with the coefficients K of the filter above, using an input signal x as follows:

```
a. a vector with one 1 followed by 19 zeros (unit impulse)b. a vector with 20 values of 1 (unit step)
```

Plot the resulting vectors with stem().

## 5 Final questions

1. TBD