

## CHAPTER 4 PNEUMATICAL DIAGRAMS

**GENERAL**  
PNEUMATICAL SYMBOLS

P 4-1


**CSM 66/84/84V III**  
BASE PNEUMATICAL DIAGRAM  
HEAD PNEUMATICAL DIAGRAM  
NOZZLE-STATION PNEUMATICAL DIAGRAM


P 4-2  
P 4-3  
P 4-4



**CSM TRAYFEEDER 31**  
OVERALL PNEUMATICAL DIAGRAM

P 2-37


## HEAD PNEUMATIC DIAGRAM








Speed controller




Filter regulator with manometer




Damper



Vacuum generator



Vacuum generator with valve




Vacuum sensor



Cylinder

**PNEUMATICAL SYMBOLS**




CHAPTER 4 PNEUMATICAL DIAGRAMS

4-5

5322 871 63603 v96.00

CHAPTER 4 PNEUMATICAL DIAGRAMS

CHAPTER 4 PNEUMATICAL DIAGRAMS



**NOZZLE-STATION PNEUMATICAL DIAGRAM**