

UltraBlend Pro Blender

User Manual

Overview

The UltraBlend Pro Blender is a 1200W countertop blender designed for smoothies, soups, and food prep. It features 6 stainless steel blades and 4 pre-programmed settings.

Package Contents

- 1x Motor base
- 1x 1.5L BPA-free pitcher
- 1x Blade assembly
- 1x Tamper tool
- Recipe booklet

Safety Instructions

- Always turn off and unplug the blender before cleaning or handling the blades.
- Do not operate the blender empty or without the lid securely attached.
- Keep hands and utensils away from the blades while the motor is running.
- Do not blend liquids hotter than 60C (140F) as pressure buildup may cause the lid to eject.

Setup Instructions

- 1 Wash the pitcher, lid, and blade assembly before first use.
- 2 Attach the blade assembly to the base of the pitcher and twist to lock.
- 3 Place the pitcher onto the motor base until it clicks into place.
- 4 Plug in the unit; the control panel will light up.

Usage

Select a pre-programmed setting (Smoothie, Soup, Ice Crush, Pulse) or use manual speed control (1-10). Use the tamper tool through the lid opening to push ingredients toward the blades while the motor is running. Never remove the lid while blending.

Troubleshooting

Motor won't start: Confirm the pitcher is locked onto the base; the safety interlock prevents operation otherwise.

Blender is unusually loud or vibrating: Turn off immediately and check that ingredients are not overloading the pitcher.

Leaking from the base: Check that the blade assembly gasket is seated correctly.

Warranty

The UltraBlend Pro Blender includes a 3-year limited warranty covering the motor and a 1-year warranty on the pitcher and blades. Contact support@ultrablend-example.com for service.