







DT chamber  
reference point  
= Coordinate  
origin (0,0,0)



Scintillator  
reference point



Legend:

- : Channel segmentation along x-axis
- : Channel segmentation along y-axis