Populating Occupancy Grids from LIDAR Scan Data

Course 4, Module 2, Lesson 2 – Part 2

UNIVERSITY OF TORONTO
FACULTY OF APPLIED SCIENCE & ENGINEERING

Learning Objectives

- Create a simple Inverse Measurement Model
- Discuss an improvement using Bresenham line algorithm

Inverse Measurement Module

$$l_{t,i} = \text{logit}\left(p(m^i|y_t)\right) + l_{t-1,i} - l_{0,i}$$

- State of the occupancy grid given a measurement
- So far we have only seen the following measurement model:

$$p(y_t|m^i)$$

  o State of the occupancy grid given a measurement
- A inverse measurement model is needed!

Inverse Measurement Module

- Scanner bearing:

$$\phi^s = [-\phi_{max}^s \quad ... \quad \phi_{max}^s] \qquad \phi_j^s \in \phi^s$$

- Scanner ranges:

$$r^s = [r_1^s \quad ... \quad r_j^s] \qquad r_j^s \in [0, r_{max}^s]$$

Inverse Measurement Module

Scan line

Environment
(Elliptical Wall)

Inverse Measurement Module

$\mathcal{F}_{vehicle}$

$\mathcal{F}_{map}$

x_{1,t}, x_{2,t}, x_{3,t}
where x_1 and x_2 are cartesian
coordiantes of sensor and x_3 is its
orientation

Inverse Measurement Module

Low Probability

High Probability

No Information

Inverse Measurement Module – To be fixed

(r^i, ϕ^i)

Closest relative bearing:

$$k = \operatorname{argmin}\left(\left|\phi^i - \phi_j^s\right|\right)$$

Relative range:

$$r^i = \sqrt{\left(m_x^i - x_{1,t}\right)^2 + \left(m_y^i - x_{2,t}\right)^2}$$

Relative bearing:

$$\phi^i = \tan^{-1}\left(\frac{m_y^i - x_{2,t}}{m_x^i - x_{1,t}}\right) - x_{3,t}$$

Inverse Measurement Module

- **α** - defines the affected range for high probability
- **β** - defines the affected angle for low and high probability

All squares in this area are affected

Inverse Measurement Module - Algorithm

- No Information

  if $\quad r^i > \min(r^s_{max}) \quad$ or $\quad |\phi^i - \phi^s_k| > \beta/2$

- High probability

  if $\quad r^s_k < r^s_{max} \quad$ and $\quad |r^i - r^s_k| > \alpha/2$

- Low probability

  if $\quad r^i < r^s_k$

High Probability

Low Probability

No Information

Inverse Measurement Module

- Example – red cells denote high probability of occupied, given measurement denoted by red x.

Inverse Measurement Module With Ray Tracing

- Ray tracing algorithm using Bresenham's line algorithm
  - Rasterized line algorithm
  - Uses very cheap fixed point operations for fast calculations
- Perform update on each beam from the LIDAR rather then each cell on the grid
  - Preforms far fewer updates (ignores no information zone)
  - Much cheaper per operation

Summary

- Create a simple Inverse Measurement Model
- Discuss an improvement using Bresenham line algorithm