



Group I or Group II aiming pad locations may be used.

NOTES

Group I aiming pad location (front view) is that prescribed for 2B1 sealed beam units.

<sup>•</sup> Group II aiming pad location (front view) is that prescribed for 1A1/2A1 sealed beam units