# Forma Gaming Chair Manual and Assembly

Thank you for purchasing a MAINGEAR Forma Gaming Chair.

Please see below, or click here for a downloadable PDF of the Manual and Assembly Guide for Forma Chairs (https://mega.nz/file/EWwHGILR#bNslArh0-1rTyo-JvTaB36uWXefbITfIGca93lUYEvU).

## Contents

For illustration only. Contents may vary.



1. Backrest
2. Seat Base
3. Head Pillow
4. Lumbar Cushion
5. Wheel Base
6. Wheels
7. Side Covers & Bolts
8. Multi-Tilt Control Unit
9. Gloves
10. Hydraulic Lift Cylinder
11. Telescoping Cover
12. Hex Wrench
13. Spare Bolt

## Assembly Instructions

Please use gloves for assembly.



1. Insert and push each wheel into the base.



2. Remove the red protecive cap on the top of the base if present. Insert the hydraulic lift cylinder into the center of the base.



3. Place the telescoping cover over the hydraulic lift cylinder.



4. Remove the pre-assembled bolts and washer from the seat back with the hex wrench.



9. Insert top of the hydraulic lift cylinder into the mounting hole on the control unit, then place the chair upright.

5. Remove the protective foam covers from the brackets of the seat base. Position the backrest carefully between the brackets. Insert all 4 bolts (2 on each side) and bring to a loose fit with the hex wrench. Tighten each bolt simultaneously until all are snug.



6. Install the side covers and tighten the bolts to secure them in place. (Place the cover designated "R" on the side of the chair with the lever.)



7. Rest the chair on the seat back. Remove the 4 pre-mounted bolts and washers from the underside.



8. Align the multi-tilt control unit with the holes on the underside of the chair, making sure the "front" arrow is pointing towards the front of the chair. Insert the bolts and washers and tighten all bolts simultaneously.

We're here to help

## Adjustable Functions

For illustration only. Functions may vary.

**Seat adjustment**

Tilt and lock lever is located on the opposite side of the chair. Twist lever down to lock at desired angle. Twist lever up and lean back to disengage the tilt lock.

**Armrest adjustment**




**IMPORTANT SAFETY INFORMATION**

Recommended weight load should not exceed 330lbs (149kg) for the FORMA R, and 350lbs (158kg) for the FORMA GT. The chair should only be used for normal seating. Do not use the chair in any potentially dangerous positions. Please exercise caution when using the maximum reclining and tilt position to avoid any injuries.

**DO NOT** have more than one person on the seat.
**DO NOT** sit on the edge of the seat.
**DO NOT** stand on the seat.
**DO NOT** play with the reclining mechanism
**DO NOT** exceed reclining limits.

For support please call Micro Center at:

**1-800-207-3434**

**If you have any issues with your Forma chair, you can contact Micro Center support or have your chair replaced under warranty at any Micro Center store in the US for 5 years from your date of purchase.**

*Still need help? Contact Us (#)*

*Last updated on July 23, 2024*

**RELATED ARTICLES**

Customer Service Contact Info (/article/19-customer-service-contact-info)

© MAINGEAR (https://maingear.com/) 2026. Powered by Help Scout (https://www.helpscout.com/docs-refer/?co=MAINGEAR&utm_source=docs&utm_medium=footerlink&utm_campaign=Docs+Branding)