

Embedded Systems with ARM Cortex-M Microcontrollers in Assembly Language and C

CSE33 I: Microprocessor Interfacing and Embedded Systems

Lecture#9: C and Assembly Mixing (Chapter#10)

Basic Data Types in C

Data Type	Data Size (bits)	Alignment	Data Range
bool	8	byte	0 or 1. Bits 1-7 are ignored
char	8	byte	-128 - 127(signed) or 0 - 255(unsigned)
int	32	word	-2,147,483,648 - 2,147,483,647(signed) or 0 - 4,294,967,296(unsigned)
short int	16	halfword	-32,768 - 32,767(signed) or 0 - 65,536(unsigned)
long int	32	word	same as int
long long	64	word	-9,223,372,036,854,775,808 - 9,223,372,036,854,775,807(signed) or 0 - 18,446,744,073,709,551,616(unsigned)
float	32	word	+/- 1.4023×10^{-45} to $3.4028 \times 10^{+38}$, always signed
double	64	word	+/- 4.9406×10^{-324} to 1.7977×10^{308} , always signed
long double	96	word	very large range
pointer	32	word	0 to 4,294,967,296

Load and Store Data

unsigned char	LDRB/STRB
unsigned short	LDRH/STRH
unsigned int	LDR/STR
char	LDRSB/STRSB
short	LDRSH/STRSH

Struct

```
struct Position {  
    char x;  
    char y;  
    char x;  
    int time;  
    short scale;  
} array[10];
```




Struct

```
struct Position {  
    char x;  
    char y;  
    char x;  
    int time;  
    short scale;  
} array[10];
```



```
struct Position {  
    char x;  
    char y;  
    char x;  
    char padding_1[1];  
    int time;  
    short scale;  
    char padding_2[2];  
} array[10];
```




Struct

```
__packed struct Position {  
    char x;  
    char y;  
    char x;  
    int time;  
    short scale;  
} array[10];
```




Struct

```
__packed struct Position {  
    char x;  
    char y;  
    char x;  
    int time;  
    short scale;  
} array[10];
```



Unaligned Accesses



Two memory accesses are required to fetch the unaligned word!

Struct

```
struct Position {  
    char x;  
    char y;  
    char x;  
    char padding_1[1];  
    int time;  
    short scale;  
    char padding_2[2];  
} array[10];
```

*Optimized for
speed
(default)*

```
__packed struct Position {  
    char x;  
    char y;  
    char x;  
    int time;  
    short scale;  
} array[10];
```

*Optimized for
space*

Static Variables

C Code

```
int foo();

int main(void) {
    int y;
    y = foo(); // y = ?
    y = foo(); // y = ?
    y = foo(); // y = ?
    while(1);
}

int foo() {
    int x = 5;
    x = x + 1;
    return(x)
}
```

C Code

```
int foo();

int main(void) {
    int y;
    y = foo(); // y = ?
    y = foo(); // y = ?
    y = foo(); // y = ?
    while(1);
}

int foo() {
    static int x = 5;
    x = x + 1;
    return(x)
}
```

Static Variables

C Code	Assembly Code
<pre>int foo(); int main(void) { int y; int x=5; y = foo(x); // y = 6 y = foo(x); // y = 6 y = foo(x); // y = 6 while(1); } int foo(int x) { int x = 5; // local variable x = x + 1; return(x) }</pre>	<pre>AREA static_demo, CODE EXPORT __main ALIGN ENTRY __main PROC BL foo ; r0 = 6 BL foo ; r0 = 6 BL foo ; r0 = 6 stop B stop ENDP foo PROC MOV r0,#5 ADD r0,r0,#1 BX LR ENDP END</pre>



Static Variables

C Code	Assembly Code
<pre>int foo(); int main(void) { int y; y = foo(); // y = 6 y = foo(); // y = 7 y = foo(); // y = 8 while(1); } int foo() { // x is initialized only once static int x = 5; // a static variable x = x + 1; return(x) }</pre>	<pre>AREA static_demo, CODE EXPORT __main ALIGN ENTRY __main PROC BL foo ; r0 = 5 BL foo ; r0 = 6 BL foo ; r0 = 7 stop B stop ENDP foo PROC LDR r1,=x LDR r0,[r1] ADD r0,r0,#1 STR r0,[r1] BX LR ENDP AREA myData, DATA ALIGN x DCD 5 END</pre>

Example of C Calling Assembly

C Program (main.c)	Assembly Program (strlen.s)
<pre>char str[25] = "Hello!"; extern void strlen(char* s); int main(void){ int i; i = strlen(str); while(1); }</pre>	<pre>AREA stringLength, CODE EXPORT strlen ; make strlen visible ALIGN strlen PROC PUSH {r4, lr} ; preserve r4 and lr MOV r4, #0 ; initialize length loop LDRB r1, [r0, r4] ; r0 = string address CBZ r1, exit ; branch if zero ADD r4, r4, #1 ; length++ B loop ; do it again exit MOV r0, r4 ; place result in r0 POP {r4, pc} ; exit ENDP</pre>

Example of Accessing C Variables

C Program (main.c)	Assembly Program (count.s)
<pre>int counter; extern int getValue(); extern void setValue(int c); void increment(); int main(void) { int c = 0; setValue(1); increment(); c = getValue(); while(1); } void increment(){ counter += 2; }</pre>	<pre>AREA count, CODE IMPORT counter ALIGN setValue PROC EXPORT setValue LDR r1, =counter STR r0, [r1] BX lr ENDP getValue PROC EXPORT getValue LDR r1, =counter LDR r0, [r1] BX lr ENDP increment PROC EXPORT increment [WEAK] LDR r1, =counter LDR r0, [r1] ADD r0, r0, #1 STR r0, [r1] BX lr ENDP END</pre>

Example of Assembly Calling C

Assembly Program (main.s)		C Program (strlen.c)
<pre>AREA my_strlen, CODE EXPORT __main IMPORT strlen ALIGN ENTRY __main PROC LDR r0, =str BL strlen stop B stop ENDP AREA myData, DATA ALIGN Str DCB "12345678",0 END</pre>		<pre>int strlen(char *s){ int i = 0; while(s[i] != '\0') i++; return i; }</pre>

Example of Accessing Data Defined in Assembly

Assembly Program	C Program
<pre>AREA main, CODE EXPORT __main IMPORT getValue IMPORT increment IMPORT setValue ALIGN ENTRY __main MOVS r2,#0 MOVS r0,#1 BL setValue BL increment BL getValue MOV r2,r0 stop B stop AREA myData, DATA EXPORT counter counter DCD 0 END</pre>	<pre>extern int counter; int getValue() { return counter; } void increment() { counter++; } void setValue(int c) { counter = c; }</pre>

