

Warranty Tab – User Tutorial

Oct 3, 2026 · @Thilina Senadheera

Overview

The Warranty tab keeps every warranty DIMO gives, follows each customer claim from report to closure, and recovers the cost from the manufacturer. Contact with customers and manufacturers is made by phone, email or portal as today; the system records each step and sends the reminders.


Open it from the side menu: **Warranty**. The top of the screen shows four counters you can tap: Active warranties, Expiring ≤ 90 days, Open claims and Claims open ≥ 14 days.

Tab	What it shows	Who sees it
Warranties	Every warranty record, with customer, project, owner and status filters	All warranty users
Claims	Customer claims and the next step on each	All warranty users
Reported from visits	Issues sales found on site visits (sales see My reported issues)	All warranty users
By brand	Installed items and claims grouped by brand	All warranty users
Manufacturer claims	Back-to-back claims (RMA) to manufacturers	Not shown to sales
Manufacturers	Master list and scorecard of each manufacturer	Not shown to sales

Each claim shows a coloured stage tag that tells you the next step: To verify, To assign (Sr. Elec. Eng.), Inspection due, Decision due, Goodwill – SM Projects, Rectify, Close.

The site is fixed first; the cost is then claimed back from the manufacturer

Highlighted: the step only the Senior Electrical Engineer can do



warranty claim and manufacturer claim flow

Chargeable and rejected claims skip rectification and are closed with the reason; only covered claims under the supplier's warranty go to the manufacturer.

Who does what

The Senior Electrical Engineer – Project Execution is the warranty officer and the only person who assigns engineers. Operations runs the back end and covers for the warranty officer.

Role	Main jobs in the Warranty tab
Senior Electrical Engineer – Project Execution (warranty officer)	Enters warranties and claims; assigns engineers (only this role) ; decides covered / chargeable / rejected; chooses DIMO stock or manufacturer replacement; raises and drives manufacturer claims (RMA); closes claims

Role	Main jobs in the Warranty tab
Operations Executive	Enters warranties (completion records) and claims; verifies claims raised by sales and SM Projects; registers projects with manufacturers; returns goods (courier, tracking, freight); records GRN / credit notes; back-up warranty officer
Assistant Engineers (3)	Inspect on site and record findings and photos; rectify or replace; record the rectification
Sales person	Reports issues from site visits; raises claims on own projects / categories (they start as To verify); quotes the customer for chargeable work
SM Projects	Raises claims from direct complaints; approves goodwill cover; decides absorb or escalate when a manufacturer rejects a claim; receives overdue alerts
GM	Can also decide absorb or escalate; sees everything

Step 1 – Register the warranty when a project is completed

Who: Operations Executive or Senior Electrical Engineer.

Every warranty needs an invoice number or a contract / PO number, so a claim can always be traced back to our supply.

1. Open the warranty record:

- Project in the system: open the project and tap + **Completion record** (the project and customer fill in for you).
- Project not in the system: Warranty → + **Completion record** → choose **Not in the system (outside project)** and type the project name and customer (use the same customer name as in the debtors list).

2. **Invoice / contract:** invoice number and date, contract / PO number, supply value and currency (LKR or USD).

3. **Completion dates:** delivery, testing & commissioning and handover dates; choose what the warranty **starts from** (handover, T&C, delivery or invoice).

4. **Warranty lines (installed items):** tap + **Line** for each product group – category, product group, brand, quantity, warranty to client and supplier warranty ends. The system warns when our warranty to the client is longer than the supplier's ("Gap").
5. Owner: leave blank and the sales person for that category becomes the owner, or choose one. Add site address, site contact and project engineer.
6. Save. The record shows as **Active**, turns **Expiring ≤ 90 days** near the end, and the brand on each line links it to the manufacturer automatically.

Step 2 – Raise a claim or report an issue

There are two ways in: **raise a claim** when you can find the warranty record, or **report an issue** when you cannot.

Raise warranty claim (warranty desk, sales on own projects / categories, SM Projects)

1. Warranty → + **Raise warranty claim**, or open the warranty and tap **Raise claim**.
2. **Warranty:** search by invoice / contract number, customer or project.
3. **Failure:** choose the item (warranty line) or *Not sure / several items*, then what failed, quantity, location on site and how it was reported (customer call, email, letter, sales visit, site inspection).
4. Only the Senior Electrical Engineer sees **Assign to engineer** here. Everyone else saves, and the claim starts as **To verify** for Operations.
5. Tap **Enter claim**. Add photos or the customer letter on the claim screen.

Report warranty issue (sales, from a visit or the Warranty tab)

1. In a sales visit tap **Report warranty issue**, or Warranty → **Report warranty issue**.
2. Fill **Where** (customer, project / site name, location, site contact) and **What you saw** (description, approx. quantity); add photos.
3. Tap **Report issue**. It appears under **Reported from visits**; Operations finds or creates the warranty and turns it into a claim, or dismisses it with a reason.

Sales see their reports under **My reported issues**.

Step 3 – Verify and assign

Claims raised by sales or SM Projects are checked by Operations first; only the Senior Electrical Engineer assigns the engineer.

1. **Verify (Operations Executive):** open the claim tagged **To verify**, check the invoice / contract and the warranty line, then tap **Verify** and add a note (e.g. invoice checked). The claim moves to **To assign (Sr. Elec. Eng.)** and the Senior Electrical Engineer is

notified.

2. **Assign (Senior Electrical Engineer):** open the claim and tap **Assign engineer**, choose one of the Assistant Engineers (or yourself). On a claim still To verify the button reads **Verify & assign** and does both. Use **Re-assign** to change the engineer later.
3. A wrong or duplicate claim can be stopped with **Cancel claim** and a reason.

Step 4 – Inspect and decide

The assigned engineer inspects; the Senior Electrical Engineer decides whether DIMO covers it.

1. **Record inspection (assigned engineer):** inspection date and findings. Add site photos and batch / date codes – the manufacturer will ask for them.
2. **Decide (Senior Electrical Engineer):** tap **Decide** and choose:
 - **Covered** – DIMO repairs or replaces free of charge.
 - **Chargeable – quote the customer** – not under warranty; sales quotes the work.
 - **Rejected** – misuse, not our supply, etc. A reason is required for chargeable and rejected.
3. **Goodwill:** choosing Covered on an item that is out of warranty sends a goodwill request to SM Projects. The claim shows **Goodwill – SM Projects** until it is approved or rejected in **Approvals** (button **Approve / reject goodwill**). If rejected, the claim becomes chargeable.

Step 5 – Rectify and close the customer claim

The customer does not wait for the manufacturer: replace from DIMO stock now if needed, and claim back separately (next section).

1. **Record rectification (engineer or warranty desk):** date, what was done, cost, and **Replaced from** – *DIMO stock or Manufacturer's replacement*.
2. Upload the customer's confirmation or completion note on the claim.
3. **Close claim (warranty desk):** date and customer confirmation / note. A claim can be closed while its manufacturer claim is still open; the recovered value is added to the claim later when the RMA closes.

Claiming back from the manufacturer

Every covered claim on a product still under the supplier's warranty is claimed back to back from the manufacturer through a manufacturer claim (RMA).

A. Keep the Manufacturers list up to date

Who: Senior Electrical Engineer, Operations Executive or SM Projects.

1. Warranty → **Manufacturers** → + **Manufacturer**.
2. Name (same as the brand on warranty lines), local agent, contact (person, email, phone, portal), standard warranty terms, evidence needed for a claim.
3. **Project registration required?** and **Register within (days after the warranty start)**.
4. Save. Warranty lines with that brand link to it automatically. The list also works as a scorecard: claims raised, accepted, rejected and value recovered.

B. Register the project with the manufacturer

Who: Operations Executive.

1. Open the warranty → section **Registration with the manufacturer**. The due date is calculated from the manufacturer's rule.
2. Register on the manufacturer's portal or by email, then tap **Record**: registration date, manufacturer reference, note.
3. If a line shows the wrong manufacturer, change it on the line (warranty desk).

C. Raise and follow the manufacturer claim (RMA)

Who: Senior Electrical Engineer (warranty officer); Operations for returns and receipts.

1. On a covered claim tap **Manufacturer claim (RMA)**, or Warranty → Manufacturer claims → + **Manufacturer claim**.
2. Choose the manufacturer. Other covered claims for the same manufacturer are listed – tick **Include** to group them. For each item enter product, quantity, batch / date code and value claimed; + **Item** adds one not linked to a customer claim.
3. Enter the evidence collected and tap **Create manufacturer claim**. Upload photos and letters on the RMA screen.
4. Contact the manufacturer yourself, then record each step on the RMA as it happens:
 - a. **Manufacturer contacted** – date, how / reference.
 - b. **RMA no. received** – the manufacturer's RMA number.
 - c. **Goods returned** (Operations) – courier, tracking no., freight cost.
 - d. **Manufacturer decision** – Accepted, Partly accepted or Rejected, with the settlement: replacement, credit note or repair.
 - e. **Replacement / credit received** (Operations) – GRN no. or credit note no., value recovered.
5. **Close manufacturer claim**. The value recovered is shared across the linked customer claims.

D. When the manufacturer rejects

1. SM Projects (and the Senior Electrical Engineer) are alerted.
2. SM Projects (or GM) taps **Absorb or escalate**:
 - **Absorb the cost (DIMO)** – the RMA can then be closed.
 - **Escalate to the manufacturer** – the decision is reopened; record the new decision when it comes.

Alerts you will receive

Alerts arrive in the bell (notifications) and as phone push messages; tap one to open the record.

When	Who is alerted
A claim is raised by sales or SM Projects	Operations (to verify)
A claim needs an engineer	Senior Electrical Engineer
You are assigned a claim	The assigned engineer
Goodwill cover requested	SM Projects (Approvals)
Registration due in 14 days, on the due date, and when overdue	Operations, Senior Electrical Engineer; SM Projects when overdue
Covered claim with no manufacturer claim after 5 working days	Senior Electrical Engineer
No RMA number 7 days after contacting the manufacturer	Senior Electrical Engineer
No decision 30 days after goods returned	Senior Electrical Engineer, SM Projects
Manufacturer rejected a claim	SM Projects, Senior Electrical Engineer
Nothing received 30 days after acceptance	Operations, Senior Electrical Engineer, SM Projects
Every Monday	Summary of open manufacturer claims

The Warranty tab also flags claims open ≥ 14 days (red counter) and warranties expiring within 90 days (amber).

Tips and FAQ

- **I can't find the warranty when raising a claim.** Search by invoice or contract number first. Still missing? Sales: use **Report warranty issue**. Warranty desk: tap + **New completion record (project not recorded yet)** on the claim form.
- **I uploaded the wrong file.** Tap **Remove** next to it (the uploader or GM can remove).
- **Can sales assign an engineer?** No. Only the Senior Electrical Engineer assigns; Operations verifies.
- **Do we wait for the manufacturer before fixing the site?** No. Replace from DIMO stock, record *Replaced from: DIMO stock*, and run the manufacturer claim in parallel.
- **One shipment back for several sites?** Yes – group several covered claims for the same manufacturer in one RMA with **Include**.
- **Where do I see how a manufacturer performs?** Warranty → **Manufacturers** shows claims raised, accepted, rejected and value recovered.
- **Every screen has a History section** showing who did what and when.