

61045001	CD-100A Phonograph Assembly (60 Hz)	Ref
61045002	CD-100A Phonograph Assembly (50 Hz)	Ref.
61035002	• Shell Assembly	1
60927901	• Bracket-Cash Bag	1
21451801	• Lock Spring	1
30866905	• Protective Strap	2
70240126	• Screen-Wire Mesh	1
21537203	• Tee Nut	2
20932601	• Tee Nut	6
21750618	• Vent Tube	1
21750616	• Vent Tube	1
2 40702808	• Skid Rail	2
3 30625701	• Hand Hold Cover	4
4 30634001	• Caster and Cup Assembly	4
5 30868402	• Enclosure Screen	1
6 20879501	• Power Cord Holder	2
7 21265203	• Tie Down Plate Assembly	1