

- Powers are displayed on the bar indicator and also on the 3 digits secondary counter:

Ref.	Power	Unit	Symbol	ΣL	Tariff
P1	Active Absorbed	MW/kW/W	→	•	T1
P2	Active Supplied	MW/kW/W	←	•	T1
P3	Reactive Inductive	Mvar/kvar/var	£	•	T1
P4	Reactive Capacitive	Mvar/kvar/var	⊥	•	T1
P5	Active Absorbed	MW/kW/W	→	•	T2
P6	Active Supplied	MW/kW/W	←	•	T2
P7	Reactive Inductive	Mvar/kvar/Var	£	•	T2
P8	Reactive Capacitive	Mvar/kvar/Var	⊥	•	T2