
116281

CIRCUIT SIMULATOR SOFTWARE INSTALLATION





1) Open the <u>VSCode</u> and click the <u>Extensions</u> icon

Download Visual Studio Code

Free and built on open source. Integrated Git, debugging and extensions.



Windows

Windows 7, 8, 10

User Installer 64 bit 32 bit
System Installer 64 bit 32 bit
szip 64 bit 32 bit



 业 .rpm Red Hat, Fedora, SUSE

 .deb
 64 bit

 .rpm
 64 bit


 .tar.gz
 64 bit

Snap Store






2) Right-click on the installer and click Run as administrator




If this window popups, click Yes

If this window popups, click OK






3) Click the I accept the agreement and <u>click the Next > button up to</u>
<u>Select Additional Tasks</u>






4) Select all options, and click the Next > button







5) Click the Install button to start the installation



6) Click the Finish button to complete the installation



INSTALL VIRTUAL SERIAL PORT DRIVER



INSTALL VIRTUAL SERIAL PORT DRIVER

1) Extract the virtual-serial-port-driver-6.9.rar to a temporal directory.

Clipboard

Quick access

Desktop


12 items

2) In the extracted directory, Right-click on the vspd.exe and choose Run as

administrator

3) After the installation is completed, copy the vspdctl.dll and paste (replace) it into the installed directory, e.g., C:\Program Files (x86) \ Eltima Software \ Virtual Serial

Port Driver 6.9




vspdctl.dll

vspd.exe

Ho2Install.txt


INSTALL PROTEUS CIRCUIT SIMULATOR



INSTALL PROTEUS CIRCUIT SIMULATOR



- 1) Extract the Proteus 8.9_SP2_PRO.rar to a temporal directory.
- 2) In the extracted directory, Right-click on the Proteus 8.9_SP2_PRO.exe and choose Run as administrator




INSTALL C COMPILER FOR PIC24



INSTALL C COMPILER FOR PIC24




- 1) Extract the ecc-embedded-2.0.0.zip to a temporal directory.
- 2) In the extracted directory, Right-click on the ecc-embedded-2.0.0.exe and choose Run as administrator



If this window protected popups, click More info and Run anyway






INSTALL ECC-LAB-TOOLS-2.0.2.EXE



INSTALL ECC-LAB-TOOLS-2.0.2.EXE

- 1) Extract the ecc-lab-tools-2.0.2.exe.zip to a temporal directory.
- 2) In the extracted directory, Right-click on the ecc-lab-tools-2.0.2.exe and choose Run as administrator



If this window protected popups, click More info and Run anyway



