SAMPLE PROGRAM

(1) ADD instruction using immediate operands

Program

```
AREA  ADDER , CODE , READONLY
MOV r0, #11
mov r1, #12
ADD r2 , r0 , r1
back b back
END
```

OUTPUT

Before Execution

Register content

R1: 0X00000000

R2: 0X00000000

R0: 0X00000000

After Execution

R0: 0X0000000B $[(11)_{10} = (B)_{16}$

R1: 0X0000000C $[(12)_{10} = (C)_{16}$

R2: 0X00000017 $[(23)_{10} = (17)_{16}$


C:\Users\Nitish kumar\Documents\Arm\add\add1.uvproj - µVision4
File Edit View Project Flash Debug Peripherals Tools SVCS Window Help
Registers
Register Value
Current
R0 0x00000000
R1 0x00000000
R2 0x00000000
R3 0x00000000
R4 0x00000000
R5 0x00000000
R6 0x00000000
R7 0x00000000
R8 0x00000000
R9 0x00000000
R10 0x00000000
R11 0x00000000
R12 0x00000000
R13 (SP) 0x00000000
R14 (LR) 0x00000000
R15 (PC) 0x00000000
CPSR 0x000000D3
SPSR 0x00000000
User/System
Fast Interrupt
Interrupt
Supervisor
Abort
Undefined
Internal
PC $ 0x00000000
Mode Supervisor
States 0
Sec 0.00000000
Project Registers
Disassembly
3: mov r1,#20
0x00000000 E3A01014 MOV R1,#0x00000014
4: mov r2,#12
0x00000004 E3A0200C MOV R2,#0x0000000C
5: add r0.r1.r2
add.s
1
2 area add,code,readonly
3 mov r1,#20
4 mov r2,#12
5 add r0,r1,r2
6 back b back
7 end
Command
*** Restricted Version with 32768 Byte Code Size Limit
*** Currently used: 16 Bytes (0%)
ASSIGN BreakDisable BreakEnable BreakKill BreakList BreakSet BreakAccess COVERAGE DEFINE
Call Stack + Locals
Name Location/Value Type
__asm_0x0 0x00000000 void f()
Real-Time Agent: Target Reset
Simulation
t1: 0.00000000 sec
L:3 C:1
Type here to search
ENG
IN

(2) PROGRAM TO FIND ONE COMPLEMENT OF DATA STORED IN A LOCATION.

```
    AREA ONES, CODE, READONLY
    ENTRY
START
        LDR r1,= Value
        LDR r2, [r1]
        MVN r3, r2
        LDR r1,= Result
        STR r3,[r1]
back    b back
Value dcd  0X00
        AREA DATA1, DATA, READWRITE
Result dcd 0X0
    END
```

OUTPUT

Before Execution

$R1$: 0X 00 000000

$R2$: 0X00 00 0000

$R3$: 0X 00 00 0000

After execution

Address of location ↓ value

$R1$: 0X00000000

$R2$: 0X 00000000 [$R_2 = R_1$]

$R3$: 0XFFFFFFFF [$R_3 = \bar{R_2}$]

$R1$: 0X40000000 ← Address of location Result

[Result] : FFFFFFFF


C:\Users\Nitish kumar\Documents\Arm\comp\compl.uvproj - µVision4
File Edit View Project Flash Debug Peripherals Tools SVCS Window Help
Registers
Register Value
Current
R0 0x00000000
R1 0x00000000
R2 0x00000000
R3 0x00000000
R4 0x00000000
R5 0x00000000
R6 0x00000000
R7 0x00000000
R8 0x00000000
R9 0x00000000
R10 0x00000000
R11 0x00000000
R12 0x00000000
R13 (SP) 0x00000000
R14 (LR) 0x00000000
R15 (PC) 0x00000000
CPSR 0x000000D3
SPSR 0x00000000
User/System
Fast Interrupt
Interrupt
Supervisor
Abort
Project Registers
Disassembly
4: ldr r1,=value
0x00000000 E59F1014 LDR R1,[PC,#0x0014]
5: ldr r2,[r1]
0x00000004 E5912000 LDR R2,[R1]
6: mvn r3,r2
0x00000008 E1E03002 MVN R3,R2
7: ldr r1,=result
0x0000000C E59F100C LDR R1,[PC,#0x000C]
compl.s
1 area ones,code,readonly
2 entry
3 start
4 ldr r1,=value
5 ldr r2,[r1]
6 mvn r3,r2
7 ldr r1,=result
8 str r3,[r1]
9 back b back
10 value dcd 0x0A
11 area datal,data,readwrite
12 result dcd 0x00
13 end
Command
Running with Code Size Limit: 3
Load "C:\\Users\\Nitish kumar\\
*** Restricted Version with 327
*** Currently used: 40 Bytes (0
ASSIGN BreakDisable BreakEnable
Call Stack + Locals Memory 1
Memory 1
Address: 0x00000018
0x00000018: 0A 00 00 00 18 00 00 00 00 00 00 40 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x00000043: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x0000006E: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x00000099: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x000000C4: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x000000EF: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x0000011A: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x00000145: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x00000170: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x0000019B: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x000001C6: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x000001F1: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Real-Time Agent: Target Reset
Simulation
t1: 0.00000000 sec
L:4 C:1
CAP NUM SCRL
Type here to search
ENG IN
20:53
03/06/2021