# **Install and operate with Turtlebot2**

### **Installation**


Open new terminal and complete the following commands:

- Download the installation script: wget https://raw.githubusercontent.com/nitroclubs/ROS\_and\_simulations \_install\_scripts/main/install\_turtlebot2\_packs.sh
- Give permissions to the file: chmod 775 install\_turtlebot2\_packs.sh
- Run the script: bash ./install\_turtlebot2\_packs.sh
- When the process is complete you will see the massage <Complete!!! > at the end of the terminal. Close the terminal!

### Starting turtlebot2 in Gazebo simulation

Open new terminal and enter the command:


roslaunch turtlebot\_gazebo turtlebot\_world.launch



#### Move the robot in the simulation

In order to teleoperate the Turtlebot2 robot with the keyboard, launch the teleoperation node with below command in a new terminal window. This terminal must be active if you want to send commands.

roslaunch turtlebot\_teleop keyboard\_teleop.launch



To terminate the teleop node enter the Ctrl+C in the terminal that run that node.

## **Turtlebot2** Gmapping demo:

In four separate terminal windows:

Chose depth sensor and Start the Turtlebot2 simulation environment: export TURTLEBOT\_3D\_SENSOR=asus\_xtion\_pro roslaunch turtlebot\_gazebo turtlebot\_world.launch

## Start the gmapping demo:


roslaunch turtlebot\_navigation gmapping\_demo.launch

### Start the rviz visualizer:

roslaunch turtlebot\_rviz\_launchers view\_navigation.launch

### Start the teleop node:

roslaunch turtlebot\_teleop keyboard\_teleop.launch



To save the generated map, you can run the map\_saver utility in new terminal:

rosrun map\_server map\_saver -f ~/turtlebot2\_map

# Turtlebot2 Navigation demo:

In three separate terminal windows:

- Start the Turtlebot2 simulation environment: export TURTLEBOT\_3D\_SENSOR=asus\_xtion\_pro roslaunch turtlebot\_gazebo turtlebot\_world.launch
- Start the turtlebot2 navigation: roslaunch turtlebot\_navigation amcl\_demo.launch map\_file:=\$HOME/turtlebot2\_map.yaml
- Start the rviz visualizer: roslaunch turtlebot\_rviz\_launchers view\_navigation.launch
  - Estimate Initial Pose

Initial Pose Estimation must be performed before running the Navigation as this process initializes the AMCL parameters that are critical in Navigation. TurtleBot3 has to be correctly located on the map with the LDS sensor data that neatly overlaps the displayed map.

1. Click the 2D Pose Estimate button in the RViz menu.



- 2. Click on the map where the actual robot is located and drag the large green arrow toward the direction where the robot is facing.
- 3. Repeat step 1 and 2 until the LDS sensor data is overlayed on the saved map.
- Set Navigation Goal
- 1. Click the 2D Nav Goal button in the RViz menu.



2. Click on the map to set the destination of the robot and drag the green arrow toward the direction where the robot will be facing.