

## **CEME-TUBE LLC.**

2907 Harvey St. Hudson, WI 54016 Tel: 715-377-2133 Fax: 715-377-2135

Email: info@cemetube.com www.cemetube.com

- A standard black **Ceme-Tube** must be used below grade to provide strength and frost resistance.
- Slide Bollard Ceme-Tube onto standard black Ceme-Tube and fasten together with screws in collar area. (screws not provided)
- A minimum of 4 pieces of No. 5 (5/8") or 3 pieces of No.6 (3/4") rebar should be used inside the **Ceme-Tube** Bollard for additional strength.

NOTE: 4 Pieces of No.6 (3/4") rebar in the **Ceme-Tube** Bollard will equal the strength of a 5" Schedule 40 pipe filled with concrete. If more strength is needed, add more rebar.

- Rebar should extend at least 2' below the level of grade. (On a standard 4' above grade bollard, a 20' piece of rebar cut into 3 equal pieces will provide 3' of support below grade and 3-1/2' above grade.
- If using multiple **Ceme-Tube** Bollard forms in one area, the tops can be trimmed down after setting, and before filling to match heights with each other.
- Fill Bollard with concrete to within 12" of top, slide rebar down into concrete, then finish filling with concrete to top.
- Before concrete hardens, attach domed lid with provided stainless steel screws in dimpled areas of dome cap.
- Clean off any concrete residue from outside of Bollard Ceme-Tube.
- Installation is complete.

