Distribution Sega Racer 2022-2024 - njz3

An up-to-date online version of the QUICKSTART and README files are available here: Une version en ligne à jour du fichier README est disponible ici :

 $https://github.com/njz3/BFF_gameassets/blob/main/image_njz3/README.md\ https://github.com/njz3/BFF_gameassets/blob/main/image_njz3/QUICKSTART.md\ https://github.com/njz3$

ENGLISH

MINIMUM PC REQUIREMENTS

The SSD is designed to run on a PC with:

- an intel 4th gen (or later) processor, or an AMD Ryzen or later.
- 4GB RAM minimum
- Nvidia 1030 graphics adapter or higher (1050Ti recommended)
- a permanently connected USB keyboard or mouse (in order to be able to use the use the DInput keyboard emulation function)
- either a FullHD LCD monitor to enjoy the full range of games, or a CRT monitor supporting 1024x768.
- if you're using a VideoAmp board, you can use either the 31kHz or 24kHz interlaced modes for all games except Teknoparrot HD, and a specific 15kHz edition in 1280x240p or 1280x480i "stretch" mode is possible with fewer games (only MAME, model 1/2/3 and Naomi via Flycast).

DISC DRIVE INSTALLATION

Your computer must be switched off and the power cord removed to avoid any electric shock. Open your computer and attach the SATA disk drive into your computer. Connect it using a SATA cable to an available port on your motherboard and connect the other side to the drive at the small SATA connector for data. Then connect the drive to your ATX power supply using the second, larger connector, taking care not to break the connectors. Close your computer and move on to the next BIOS configuration step.

MOTHERBOARD BIOS CONFIGURATION

IMPORTANT To enable disks to boot, you need to configure your motherboard BIOS to boot on the SATA port to which the drive is connected, disable "Secure Boot" and use the "Legacy BIOS" (MBR) boot mode, not UEFI.

To configure the BIOS, you generally need to press a keyboard key at the very first moment your computer is switched on. A very quick message at boot will display which key to press. Depending on the motherboard, the BIOS configuration menu can be accessed by pressing the keys "F1", "F2", "F8", "F10", "F12", or "DELETE", "BACKSPACE".

Once the BIOS configuration menu is open, look for the boot disk and select the SATA port to which the drive is connected

Then go to the boot type configuration page, and disable the "Secure Boot" mode if it is active. The disk image is designed to run in MBR mode, so don't use UEFI mode and select "Legacy BIOS" (MBR) boot mode.

FIRST BOOT

On first start-up, give Windows time to boot up and install your drivers. Once the disk has booted up, you should see the Hyperspin game selection screen. Exit Hyperspin by pressing "ESC" to go to the "Exit?" menu, then "V" to confirm "Exit". You'll now have the Windows desktop and can continue the configuration.

If you can connect your PC to the Internet, first run Windows Update to get your drivers automatically.


NETWORK CONFIGURATION (MULTIPLAYER/LINK MODE)

Multiplayer (or link) mode is already configured for the images. You can either link 2 computers directly (no need for a crossover cable) without internet access, or use a switch to link more than 2 computers, or connect your computers to a home network and the Internet. In all cases, you'll need to reconfigure your network settings as these are usually lost once the disk has been installed in your computer. Go to the network configuration page and set the following parameters:

- IPv4 address: 192.168.1.4 for cab 1 (or 192.168.1.5 for cab 2, and .6 or .7, or .X ... depending on your multi-cab setup). Some games, such as Daytona 2 support up to 8 or 16 machines in multiplayer mode.
- Subnet mask: 255.255.255.0
- Gateway: 192.168.1.254 (can be changed to 192.168.1.1 depending on your LAN)
- DNS: 8.8.8.8 or 8.8.4.4 (Google DNS)
- Broadcast address: 192.168.1.255

Also in network configuration, set private network and disable the Firewall.

Note: For network gaming on model 2 emulator (Sega Rally, Daytona 1, etc.) you need to enable support for long frames (3kB) either via an option on your network board driver, or enable the "Jumbo Frames" (MTU > 3kB) option in the Ethernet board adapter properties, and have a 1GBit Ethernet switch that supports "Jumbo Frames".



PASSWORD AND REMOTE CONNECTION

By default, Teamviewer and TightVNC (server mode) are preinstalled and enabled. Please note: it is your responsibility to protect your network from external access.

The session password for the Racecab (admin) user is racecab. The password for VNC is racecab.

FRANCAIS

CONFIGURATION MINIMALE PC

Le SSD est prévu pour fonctionner sur un PC avec :

- un processeur intel 4th gen (ou plus récent), ou un AMD Ryzen ou plus récent.
- 4GB de RAM minimum
- une carte graphique type Nvidia 1030 ou plus récent (1050Ti recommandé)
- une souris ou un clavier USB branché en permanence (ceci afin de pouvoir utiliser la fonction d'émulation de clavier DInput)
- soit un moniteur LCD FullHD pour profiter de l'ensemble des jeux, soit un moniteur CRT supportant le 1024x768.
- si vous utilisez une carte VideoAmp il est possible d'utiliser les modes 31kHz ou 24kHz entrelacé pour tous les jeux hors jeux Teknoparrot HD, et une édition spécifique 15kHz en 1280x240p ou 1280x480i en mode "stretch" est possible avec moins de jeux (uniquement MAME, model 1/2/3 et Naomi via Flycast).

INSTALLATION DU DISQUE

Votre ordinateur doit être éteint et le cordon secteur retiré pour éviter tout choc électrique. Ouvrez votre ordinateur et fixer le disque SATA dans votre ordinateur. Reliez ce dernier à l'aide d'un câble SATA sur un port disponible de votre carte mère et connectez l'autre côté au disque au niveau du petit connecteur SATA pour les données. Reliez ensuite le disque à votre alimentation ATX en utilisant le second connecteur, plus grand, en faisant attention à ne pas casser les connecteurs. Refermez votre ordinateur et passez à l'étape suivante de configuration du BIOS.

CONFIGURATION DU BIOS DE LA CARTE MERE

IMPORTANT Pour que les disques puissent démarrer, vous devez configurer votre BIOS de carte mère pour démarrer sur le port SATA sur lequel est branché le disque, désactiver le "Secure Boot" et utiliser le mode de démarrage "Legacy BIOS" (MBR), et non UEFI.

Pour configurer le BIOS, il faut en général presser une touche clavier au tout premier instant d'allumage de votre ordinateur. Un affichage très rapide à l'allumage vous indique en général la touche à presser. Ainsi, selon les cartes mères, le menu de configuration du BIOS est accessible en pressant les touches "F1", "F2", "F8", "F10", "F10", "F10", "F10", "RETOUR ARRIERE".

Une fois le menu de configuration du BIOS ouvert, cherchez la page de configuration du disque de démarrage, et sélectionner le port SATA sur lequel le disque est connecté.

Allez ensuite dans la page de configuration du type de démarrage, et désactiver le mode "Secure Boot" s'il est actif. L'image disque est prévue pour fonctionner en mode MBR, ainsi n'utilisez pas le mode UEFI et sélectionnez le mode de démarrage "Legacy BIOS" (MBR).

PREMIER DEMARRAGE

Au premier démarrage, laisser le temps à Windows de démarrer puis installer vos drivers. Une fois le disque démarré, vous devrier avoir l'écran Hyperspin de sélection de jeu. Quittez Hyperspin en faisant "ESC" pour aller au menu "Exit?", puis "V" pour confirmer "Exit". Vous allez à présent avoir le bureau Windows et vous pouvez poursuivre la configuration.

Si vous pouvez connecter votre PC à internet, lancez en premier Windows Update pour récupérer vos drivers automatiquement.


CONFIGURATION RESEAU (MODE MULTIPLAYER/LINK)

Le fonctionnement en multiplayer (ou link) est déjà prévu dans les images. Vous pouvez soit relié en direct 2 ordinateurs (cable croisé inutile) sans avoir besoin d'accès à internet, soit utiliser un switch pour relier plus de 2 ordinateurs, ou relier vos ordinateurs à un réseau domestique et à internet. Dans tous les cas, il est nécessaire de re-configurer les paramètres réseau car ceux-ci sont en général perdus après installation du disque dans votre ordinateur. Allez dans la page de configuration du réseau et définissez les paramètres suivants :

- adresse IPv4: 192.168.1.4 pour cabine 1 (ou 192.168.1.5 pour cabine 2,et .6 ou .7, ou .X .. selon la cabine en multi). Certains jeux comme Daytona 2 supportent jusqu'à 8 ou 16 machines en multiplayer.
- Masque de sous-réseau: 255.255.255.0
- Passerelle : 192.168.1.254 (modifable selon votre réseau LAN en 192.168.1.1)
- DNS: 8.8.8.8 ou 8.8.4.4 (DNS de Google)
- Broadcast address: 192.168.1.255

Toujours dans la configuration réseau, mettre réseau privé et désactivez le Firewall.

Note: Pour le jeu en réseau sur model 2 emulator (Sega Rally, Daytona 1, etc.) if faut impérativement activer le support des trames de longues taille (3kB) soit via une option de votre carte réseau, soit activer l'option "Jumbo Frames" dans votre carte Ethernet (MTU > 3kB) et avoir un switch Ethernet 1GBit qui supporte les "Jumbo Frames".



MOT DE PASSE ET "REMOTE CONNECTION"

Par défaut, Teamviewer et TightVNC (mode serveur) sont préinstallés et le bureau à distance est activé. Attention, il est de votre responsabilité de protéger votre réseau d'un accès extérieur.

Le mot de passe de session pour l'utilisateur Racecab (admin) est racecab. Le mot de passe pour VNC est racecab