	JAMMA							
	Solder si (Bottom				P	Parts side (Top)		
	GND		Α	1		GND		
			В	2				
	+5V	+	С	3	+	+5V		
	NO/ Fix		D E	4 5		NC/ Fix		
	NC/-5v	+	F		+	NC/-5v		
	+12V Key		Н	6 7		+12V Key		
	Coin counter #2	+	J	8	+	Coin counter #1		
	Coin lockout #2	+	K	9	+	Coin lockout #1		
	Speaker (-)	+	L	10	+	Speaker (+)		
	NC		М	11		NC		
	Video green	+	N	12	+	Video red		
	Video sync	+	Р	13	*	Video blue		
	Service button	+	R	14		Video GND		
	Tilt/Slam switch	+	s	15	+	Test button		
	Coin switch #2 P2	+	Т	16	+	Coin switch #1 P1		
	P2 Start	+	U	17	+	P1 Start		
Trackball 2 Y-Dir	P2 Up	+	v	18	+	P1 Up	Trackball 1 Y-Dir	
Trackball 2 Y-Clk	P2 Down	+	w	19	+	P1 Down	Trackball 1 Y-Clk	
Trackball 2 X-Dir	P2 Left	+	Х	20	+	P1 Left	Trackball 1 X-Dir	
Trackball 2 X-Clk	P2 Right	+	Υ	21	+	P1 Right	Trackball 1 X-Clk	
	P2 button A	+	z	22	+	P1 button A		
	P2 button B	+	а	23	+	P1 button B		
	P2 button C	+	b	24	+	P1 button C		
	P2 button D	+	С	25	+	P1 button D		
	NC/P2 button E (¹)	+	d	26	+	NC/P1 button E (¹)		
	GND		е	27		GND		
			f	28				

MVS					
Solder s	ide			P	arts side
(Botton	n)				(Top)
GND		A	1		GND
		В	2		
+5V	+	С	3	+	+5V
NC		D E	4 5		NC
	+	F		+	
+12V Key		Н	6 7		+12V Key
_	+	J		+	_
Coin counter #2		-	8		Coin counter #1
Coin lockout #2	+	K	9	+	Coin lockout #1
Left Speaker (+)	+	L	10	<u>+</u>	Right Speaker (+)
Test button	+	M	11	*	Mono audio (+)
Video green	+	N	12	+	Video red
Video sync	+	Р	13	+	Video blue
Service button	+	R	14		Video GND
Coin switch #4 P4	+	S	15	+	Coin switch #3 P3
Coin switch #2 P2	+	Т	16	+	Coin switch #1 P1
P2 Start	+	U	17	+	P1 Start
P2 Up	+	V	18	+	P1 Up
P2 Down	+	w	19	+	P1 Down
P2 Left	+	х	20	+	P1 Left
P2 Right	+	Υ	21	+	P1 Right
P2 button A	+	z	22	+	P1 button A
P2 button B	+	а	23	+	P1 button B
P2 button C	+	b	24	+	P1 button C
P2 button D	+	С	25	+	P1 button D
Select game down	+	d	26	+	Select game up
GND		e	27		GND
		f	28		

JAMMAI	МІА					
	Ider side Bottom)			P	Parts side (Top)	
GND		Α	1		GND	
		В	2			
+5 V	+	С	3	+	+5 V	
		D	4			
NC		E	5		NC	
+12V	+	F	6	+	+12V	
Key		Н	7		Key	
NC		J	8		NC	
NC		K	9		NC	
Spkr (-)	+	L	10	+	Spkr(+)	
TEST2 BTN	+	М	11		NC	
Video green	•	N	12	•	Video red	
Video sync	+	Р	13	•	Video blue	
SERVICE BT	N →	R	14		Video GND	
TILT	+	s	15	+	TEST BTN	
P2 Coin switc	ch #2	Т	16	+	P1 Coin switch #1	
P2 Start	+	U	17	+	P1 Start	
P2 Up	+	V	18	+	P1 Up	
P2 Down	+	w	19	+	P1 Down	
P2 Left	+	х	20	+	P1 Left	
P2 Right	+	Υ	21	+	P1 Right	
P2 BTN1	+	z	22	+	P1 BTN1	
P2 BTN2	+	а	23	+	P1 BTN2	
P2 BTN3	+	b	24	+	P1 BTN3	
P2 BTN4	+	С	25	+	P1 BTN4	
P2 BTN5	+	d	26	+	P1 BTN5	
		е	27			
GND		f	28		GND	

1/161/111	NECS S	D.C.C.					
KICK HAR	NESS C	PS2					
GND		1	2		GND		
NC		3	4		NC		
+12V	+	5	6	+	+12V		
NC		7	8		NC		
P2 BTN8	+	9	10		NC		
NC		11	12		NC		
NC		13	14		NC		
P1 BTN8	+	15	16		NC		
P1 BTN7	+	17	18		NC		
P1 BTN6	+	19	20		NC		
P2 BTN6	+	21	22		NC		
P2 BTN7	+	23	24		NC		
NC		25	26		NC		
NC		27	28		NC		
NC		29	30		NC		
NC		31	32		NC		
GND		33	34		GND		



