Bunny Rob's State Diagram

DANCE PARTY + Music

shake

Disco lights on:
p0 is pressed

p1 is pressed:
Feed carrot!

HAPPY

3 seconds

NORMAL

10 seconds

3 seconds

APPEASED

Pat : p2 pressure

Punch / Hit: 6g

ANGRY

light level > 20

light level < 2

SLEEPING

light level < 20

light level < 2

DOZING OFF

Key:

Microbit actions

STATES