Bonusaufgaben zum C/C++-Praktikum

Einführung in C





Übungsblatt 5

Hinweise zur Abgabe:

verwendet als Grundlage für die Bearbeitung die im Moodle bereitgestellte Vorlage. Beachtet auch die Hinweise auf dem ersten Bonuszettel.

Aufgabe 5.1: [C] Mit Strings arbeiten (5 Punkte)

Bitte bearbeite diese Aufgabe in string.h und string.c sowie die main-Funktion in main.c.

5.1a) Mit strcpy () konkatenieren (2 Punkte)

Implementiere die Funktion char *concatenate(const char *a, const char *b), die Speicher für die zusammengefügte Zeichenkette allokiert und durch Aufrufe von strcpy(char *destination, const char * source) aus der Standardbibliothek beide übergebenen Zeichenketten zusammenfügt. Sie darf auch die Funktion strlen(const char *str) verwenden.

Füge deiner main()-Funktion einen Aufruf von char *concatenate(const char *a, const char *b) hinzu.

5.1b) String split (3 Punkte)

Implementiere die Funktion int split (char** dest, const char* src, const char* splitStr).

Die Funktion soll die Zeichenkette src in ein Array von Zeichenketten unterteilen. Die Unterteilung soll immer dort stattfinden, wo splitStr in src vorhanden ist. Das Array von Zeichenketten soll in dest gespeichert werden und die Anzahl von Zeichenketten soll der Rückgabewert sein. Wichtig ist, dass splitStr nicht ein Zeichen ist, sondern eine Zeichenkette. Ihr könnt davon ausgehen, dass dest groß genug ist.

Beispiel: Nach dem Aufruf der Funktion mit den Parametern src = "Hello;;World;;!" und splitStr = ";;" soll das Array ["Hello", "World", "!"] in dest abspeichern und 3 zurückgeben.

Teste dies Beispiel in der main-Funktion.

Hinweise

• Für das Zusammenfügen zweier Strings können auch einfache Schleifen oder auch die Funktion sprintf aus der C Standardbibliothek verwendet werden. sprintf funktioniert ähnlich wie printf, nur dass das Ergebnis in einer Zeichenkette gespeichert wird, anstatt ausgegeben zu werden.

Aufgabe 5.2: [C] Register-Manipulation (5 Punkte)

Bitte bearbeite diese Aufgabe in registers.h und registers.c sowie die main-Funktion in main.c.

In Mikrocontrollern werden Peripheriekomponenten wie Analog-Digital-Wandler, serielle Kommunikationsschittstellen usw. meist über Register gesteuert. Diese können vom Prozessor analog zum Hauptspeicher adressiert werden. In dieser Aufgabe sollt ihr ein Pseudoregister über verschiedene Wege manipulieren. Hierbei ist es wichtig, dass nur die gewünschten Bits verändert werden und die restlichen Bits des Registers nicht verändert werden, da das sonst Einfluss auf die Hardware haben würde. Das Register, das ihr verändern sollt, ist in der Header-Datei register. h vorgegeben.

Das Datenblatt des Registers findet ihr am Ende des Aufgabenblatt. Keine Sorge, ihr müsst nicht das gesamte Datenblatt ausgiebig studieren. Konzentriert euch am besten auf die Dokumentation der für euch relevanten Bits.

Schreibt den Code hierfür in der main () -Funktion in main.c

5.2a) Bitweise Operatoren (2 Punkte)

Als erstes sollt ihr das Register über bitweise Operatoren manipulieren, z.B. mit sogenannten Bitmasken. Bei einer Bitmaske sind Zielbits 1 und allen anderen Bits 0, sodass z.B. (REG & BIT17) mit BIT17 = (1 << 17) als true interpretiert werden kann, wenn das 17. Bit 1 ist, ansonsten ergibt es false. In C gibt es den Typ bool nicht nativ, dafür wird der Wert 0 als false interpretiert und jede andere Zahl als true. Abbildung 1 zeigt ein Beispiel für beide Fälle.

```
unsigned int BIT4 = 1 << 4; // 0b00010000

unsigned int REG1 = 0b00001111;
unsigned int isBit4Set1 = REG & BIT4; // 0b00000000 = 0 = false

unsigned int REG2 = 0b11110000;
unsigned int isBit17Set2 = REG2 & BIT 4; // 0b00010000 = 16 = true</pre>
```

Abbildung 1: Beispiel für eine Bitmaske

Implementiere die Funktion void setRegisters (Register_t* reg), die bitweise Operatoren benutzt, um folgende Einstellungen im Register reg zu setzen:

- ADC 6 und 7 digital enabled, der Rest disabled
- T_q divider zu $60 * T_{clk} = T_q$
- $AD_{REF+} = Internal\ V_{REFH},\ AD_{REF-} = AV_{SS}$

Alle anderen Felder des Registers müssen und dürfen nicht verändert werden.

Füge der main-Funktion einen Aufruf von setRegisters hinzu, dem das vorgegebene Register ADCCON3 übergeben wird.

Tipp: Benutzt defines wie #define BIT17 (1 << 17), um euren Code übersichtlicher zu machen.

5.2b) Mit Structs (2 Punkte)

Ein anderer Weg zur Registermanipulation ist das Struct. Mit dem Syntax aus Abbildung 2 können einzelne Bitfelder oder Gruppen manipuliert werden.

Implementiere die Funktion void setRegistersStruct (Register_t* reg), die ein solches Struct benutzt, um die selben Änderungen wie in 5.2a im Register reg vorzunehmen.

Füge der main-Funktion auch eien Aufruf dieser Funktion hinze. In der nächsten Aufgabe werden wir etwas hinzufügen, mit dem man entscheiden kann, welche der beiden Optionen benutzt werden soll.

Achtung: Ihr sollt immer noch das selbe Register manipulieren, d.h. ihr müsst sicherstellen, dass euer Struct zur richtigen Speicherstelle zeigt.

```
struct Register_Example {
   // Kleinstes Bit
   uint32_t 16;
                         // Die ersten 16 Bit werden ignoriert
   uint32 t some char : 8; // some char ist 8 Bit groß
                        // flag ist ein Bit groß
   uint32_t flag : 1;
   uint32_t 7;
                         // Bits können ignoriert werden, indem der Name
   weggelassen wird
   // Höchstes Bit
}
unsigned int SOME_REG = 0b00000000000000000000000000000; // Beispiel Register
struct Register_Example* reg = &SOME_REG;
                                                       // Register als
   struct darstellen
reg->some_char = 'A';
                                                       // Zugriff auf Bit
   16-23
reg->flag = 1;
                                                       // Zugriff auf Bit
   24
//
                     //
//
                  flag some_char
```

Abbildung 2: Struct mit welchem bestimmte Bits eines 32-Bit Register manipuliert werden können

5.2c) Variante zur Compile-Zeit auswählen (1 Punkt)

Wir haben jetzt zwei Varianten kennengelernt um Register zu manipulieren. Wir wollen jetzt den Präprozessor benutzen um uns zur Compile-Zeit für eine der beiden Varianten zu entscheiden. Mit den #if, #elif, #else, #endif und #ifdef Direktiven des Präprozessors könnt ihr definierte Konstanten überprüfen bzw. prüfen, ob eine Konstante existiert. Beim Kompilieren könnt ihr mithilfe der zusätzlichen Option -D Name [=Wert] der Konstante mit dem Namen den Wert zuweisen. Baut in die main ()-Funktion folgendes Verhalten ein:

Wenn das Programm mit -D USE_STRUCTS kompiliert wird, dann soll die Structs Variante benutzt werden, ansonsten die Bitweise Operators Variante.

Abbildung 3 zeigt ein kleines Beispiel. Wenn das Programm mit gcc -D F main.c kompiliert wird, dann gibt es "Hello" aus, mit gcc main.c gibt es "Word" aus.

```
int main() {
#ifdef F
        printf("Hello");
#else
        printf("World");
#endif
}
```

Abbildung 3: Beispiel für Präprozessor Direktiven

PIC32 Family Reference Manual

Register 22-3: ADCCON3: ADC Control Register 3

Bit Range	Bit 31/23/15/7	Bit 30/22/14/6	Bit 29/21/13/5	Bit 28/20/12/4	Bit 27/19/11/3	Bit 26/18/10/2	Bit 25/17/9/1	Bit 24/16/8/0
31:24	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0
31.24	ADCSEL<1:0>		CONCLKDIV<5:0>					
23:16	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0
	DIGEN7 ⁽⁵⁾	DIGEN6 ⁽⁵⁾	DIGEN5 ⁽⁵⁾	DIGEN4 ⁽⁵⁾	DIGEN3 ⁽⁵⁾	DIGEN2 ⁽⁵⁾	DIGEN1 ⁽⁵⁾	DIGEN0 ⁽⁵⁾
15:8	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R-0, HS, HC	R/W-0	R-0, HS, HC
	VREFSEL<2:0>		TRGSUSP	UPDIEN	UPDRDY	SAMP ^(1,2,3,4)	RQCNVRT	
7:0	R/W-0	R-0, HS, HC	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0
	GLSWTRG	GSWTRG	ADINSEL<5:0> ⁽⁵⁾					

Legend:HC = Hardware SetHS = Hardware ClearedR = Readable bitW = Writable bitU = Unimplemented bit, read as '0'-n = Value at POR'1' = Bit is set'0' = Bit is clearedx = Bit is unknown

bit 31-30 ADCSEL<1:0>: Analog-to-Digital Clock Source (TCLK) bits

Refer to the "12-bit High-Speed Successive Approximation Register (SAR)" chapter in the specific device data sheet for the ADC Clock source selections.

bit 29-24 CONCLKDIV<5:0>: Analog-to-Digital Control Clock (Tq) Divider bits

bit 23 **DIGEN7:** ADC7 Digital Enable bit⁽⁵⁾

1 = ADC7 is digital enabled

0 = ADC7 is digital disabled

bit 22 **DIGEN6:** ADC6 Digital Enable bit⁽⁵⁾

1 = ADC6 is digital enabled0 = ADC6 is digital disabled

bit 21 **DIGEN5:** ADC5 Digital Enable bit⁽⁵⁾

1 = ADC5 is digital enabled

0 = ADC5 is digital disabled

bit 20 **DIGEN4:** ADC4 Digital Enable bit⁽⁵⁾

1 = ADC4 is digital enabled

0 = ADC4 is digital disabled

- Note 1: The SAMP bit has the highest priority and setting this bit will keep the S&H circuit in Sample mode until the bit is cleared. Also, usage of the SAMP bit will cause settings of the SAMC<9:0> bits (ADCCON2<25:16>) to be ignored.
 - 2: The SAMP bit only connects Class 2 and Class 3 analog inputs to the shared ADC. All Class 1 analog inputs are not affected by the SAMP bit.
 - 3: The SAMP bit is not a self-clearing bit and it is the responsibility of application software to first clear this bit and only after setting the RQCNVRT bit to start the analog-to-digital conversion.
 - 4: Normally, when the SAMP and RQCNVRT bits are used by software routines, all TRGSRCx<4:0> bits and STRGSRC<4:0> bits should be set to '00000' to disable all external hardware triggers and prevent them from interfering with the software-controlled sampling command signal SAMP and with the software-controlled trigger RQCNVRT.
 - 5: Depending on the device, the function will vary. Refer to the "ADC" chapter in the specific device data sheet to determine the function that is available for your device.

Section 22. 12-bit High-Speed SAR ADC

Register 22-3: ADCCON3: ADC Control Register 3 (Continued)

bit 19 **DIGEN3:** ADC3 Digital Enable bit⁽⁵⁾

1 = ADC3 is digital enabled

0 = ADC3 is digital disabled

bit 18 **DIGEN2:** ADC2 Digital Enable bit⁽⁵⁾

1 = ADC2 is digital enabled

0 = ADC2 is digital disabled

bit 17 **DIGEN1:** ADC1 Digital Enable bit⁽⁵⁾

1 = ADC1 is digital enabled

0 = ADC1 is digital disabled

bit 16 **DIGEN0:** ADC0 Digital Enable bit⁽⁵⁾

1 = ADC0 is digital enabled

0 = ADC0 is digital disabled

bit 15-13 VREFSEL<2:0>: Voltage Reference (VREF) Input Selection bits

VREFSEL<2:0>	ADREF+	ADREF-	
111	AVDD	Internal VREFL	
110	Internal VREFH	AVss	
101	Internal VREFH	External VREFL	
100	Internal VREFH	Internal VREFL	
011	External VREFH	External VREFL	
010	AVDD	External VREFL	
001	External VREFH	AVss	
000	AVDD	AVss	

bit 12 TRGSUSP: Trigger Suspend bit

- 1 = Triggers are blocked from starting a new analog-to-digital conversion, but the ADC module is not disabled
- 0 = Triggers are not blocked
- bit 11 UPDIEN: Update Ready Interrupt Enable bit
 - 1 = Interrupt will be generated when the UPDRDY bit is set by hardware
 - 0 = No interrupt is generated
- bit 10 UPDRDY: ADC Update Ready Status bit
 - 1 = ADC SFRs can be updated
 - 0 = ADC SFRs cannot be updated

Note: This bit is only active while the TRGSUSP bit is set and there are no more running conversions of any ADC modules.

- bit 9 SAMP: Class 2 and Class 3 Analog Input Sampling Enable bit (1,2,3,4)
 - 1 = The ADC S&H amplifier is sampling
 - 0 = The ADC S&H amplifier is holding
- Note 1: The SAMP bit has the highest priority and setting this bit will keep the S&H circuit in Sample mode until the bit is cleared. Also, usage of the SAMP bit will cause settings of the SAMC<9:0> bits (ADCCON2<25:16>) to be ignored
 - 2: The SAMP bit only connects Class 2 and Class 3 analog inputs to the shared ADC. All Class 1 analog inputs are not affected by the SAMP bit.
 - 3: The SAMP bit is not a self-clearing bit and it is the responsibility of application software to first clear this bit and only after setting the RQCNVRT bit to start the analog-to-digital conversion.
 - 4: Normally, when the SAMP and RQCNVRT bits are used by software routines, all TRGSRCx<4:0> bits and STRGSRC<4:0> bits should be set to '00000' to disable all external hardware triggers and prevent them from interfering with the software-controlled sampling command signal SAMP and with the software-controlled trigger RQCNVRT.
 - 5: Depending on the device, the function will vary. Refer to the "ADC" chapter in the specific device data sheet to determine the function that is available for your device.

PIC32 Family Reference Manual

Register 22-3: ADCCON3: ADC Control Register 3 (Continued)

bit 8 RQCNVRT: Individual ADC Input Conversion Request bit

This bit and its associated ADINSEL<5:0> bits enable the user to individually request an analog-to-digital conversion of an analog input through software.

- 1 = Trigger the conversion of the selected ADC input as specified by the ADINSEL<5:0> bits
- 0 = Do not trigger the conversion

Note: This bit is automatically cleared in the next ADC clock cycle.

- bit 7 GLSWTRG: Global Level Software Trigger bit
 - 1 = Trigger conversion for ADC inputs that have selected the GLSWTRG bit as the trigger signal, either through the associated TRGSRC<4:0> bits in the ADCTRGx registers or through the STRGSRC<4:0> bits in the ADCCON1 register
 - 0 = Do not trigger an analog-to-digital conversion
- bit 6 GSWTRG: Global Software Trigger bit
 - 1 = Trigger conversion for ADC inputs that have selected the GSWTRG bit as the trigger signal, either through the associated TRGSRC<4:0> bits in the ADCTRGx registers or through the STRGSRC<4:0> bits in the ADCCON1 register
 - 0 = Do not trigger an analog-to-digital conversion

Note: This bit is automatically cleared in the next ADC clock cycle.

bit 5-0 ADINSEL<5:0>: Analog Input Select bits⁽⁵⁾

These bits select the analog input to be converted when the RQCNVRT bit is set, where, MAX_AN_INPUT is the maximum analog inputs available on the device.

- Note 1: The SAMP bit has the highest priority and setting this bit will keep the S&H circuit in Sample mode until the bit is cleared. Also, usage of the SAMP bit will cause settings of the SAMC<9:0> bits (ADCCON2<25:16>) to be ignored.
 - 2: The SAMP bit only connects Class 2 and Class 3 analog inputs to the shared ADC. All Class 1 analog inputs are not affected by the SAMP bit.
 - 3: The SAMP bit is not a self-clearing bit and it is the responsibility of application software to first clear this bit and only after setting the RQCNVRT bit to start the analog-to-digital conversion.
 - 4: Normally, when the SAMP and RQCNVRT bits are used by software routines, all TRGSRCx<4:0> bits and STRGSRC<4:0> bits should be set to '00000' to disable all external hardware triggers and prevent them from interfering with the software-controlled sampling command signal SAMP and with the software-controlled trigger RQCNVRT.
 - 5: Depending on the device, the function will vary. Refer to the "ADC" chapter in the specific device data sheet to determine the function that is available for your device.