

How to find MAC address of Ports from iDRAC


1. Login to iDRAC system of Dell Machines (vmware / ca\$hc0w)



2. Navigate to the System->Overview Tab on the Home page



3. Click on the "Network Devices" Button on the System Overview tab. It shows the summary of the different NIC cards inserted and the MAC address of the NIC card itself.



4. To find the MAC address of individual ports of the different NIC cards, click on the NIC card and click on the particular port in the NIC card and expand the port partition information.

