Production Supporting Systems in Factories

ระบบสนับสนุนการผลิตในโรงงานอุตสาหกรรม

Cloud database

Context

The `scope` of a particular context value.

- `Node` - only visible to the node that set the value
- `Flow` - visible to all nodes on the same flow (or tab in the editor)
- `Global` - visible to all nodes

Sample flow

- Show random value (real time).
- Store the maximum value.




Data and Chart
0
timestamp
function 5
switch
set flow.current
nirand/current
connected
chart
debug 10
Textbox
nirand/current
connected
Max value
abc

`function` node

```
msg.payload = Math.random()
return msg;
```