

GeoTiff negative value Converting in QGIS

ArcGIS has the tendency to read CARIS depths as negative values. Use the raster calculator to convert negative value to positive values.

- 1. Create a regular gridded surface directly from the HIPS track lines
- 2. With the correct surface selected in the CARIS Layers tab, go to **File > Export > Coverages> Raster**.
- 3. In the Export Raster dialog box use the *Format:* dropdown option to choose either **Export Raster** to **GeoTiff** or **Export Raster to BAG**.




4. Open QGIS and Drag the Tiff Data from Browser to the viewer window to add raster.




5. If the depth values are in negative, multiply the raster with -1 in order to convert the depth values to positive.


Raster → Raster Calculator, the following window opened




Select the folder to save the result at the Output Layer from Result layer



Double Click the raster files from **Raster bands** window to pull the rater files to the **Raster calculation Expression** window and write the calculation expression, such as click * sign for multiplication, and -1 (to convert negative value to positive value) and hit **OK**



Check the converted value in the Layer window



6. Make sure the raster files look good and send the TIFF/GeoTIFF files for weekly report. If you want to export the raster in different file format, follow the following steps

Write click on the file and select **Export**, then the following window open to select file format and select file name and folder to save it.

