

---

**Re: Talk to Optode Through Scicon**

---

**From** IOP Seaglider <iopsg@uw.edu>

**Date** Fri 11/21/2025 4:17 PM

**To** Marquardt, Jace <jace.marquardt@oregonstate.edu>

**Cc** VerWey, Brian <Brian.Verwey@oregonstate.edu>

[This email originated from outside of OSU. Use caution with links and attachments.]

Hi Jace -

From the glider menu choose hw/loggers/sc/direct. You might want to add "stroke=1" so that the glider doesn't reboot in 10 minutes (i.e., if you're going to be longer than 10 minutes).

At the scicon > prompt, use the "attach" command and note the hwchan setting for the optode.

To talk to optode, use the term command, e.g.,

term 1 9600 stroke

Change the 1 to whatever hwchan the optode is attached to. If you don't add the stroke argument here then scicon will reboot in 1 minute (it has a much shorter watchdog timer than the glider). When you're done with optode comms, use Ctrl-d to return to the scicon prompt and then ctrl-Q to return to the glider menu.

Jason

---

**From:** Marquardt, Jace <jace.marquardt@oregonstate.edu>

**Sent:** Friday, November 21, 2025 4:12 PM

**To:** IOP Seaglider <iopsg@uw.edu>

**Cc:** VerWey, Brian <Brian.Verwey@oregonstate.edu>

**Subject:** Talk to Optode Through Scicon

Hello again!

We are attempting to calibrate our optode post-deployment and need to communicate with the optode directly. Is there a way to communicate with individual sensors connected to the Scicon board? I was looking through the Scicon manual and didn't see instructions for doing this.

Thanks,  
Jace