

Inverter Cooling-System Return-to-Service Checklist

Maintenance Release Control · SD-8400 / Fault A12

DOCUMENT	FPL-CHK-INV-RTS-024
VERSION	2.4
EFFECTIVE	July 8, 2026
STATUS	Approved — Synthetic
OWNER	Commissioning & Maintenance (Synthetic)

3. Return-to-service acceptance criteria

Complete every applicable item before releasing an SD-8400 inverter from an A12 Maintenance Hold. An acknowledged alarm is not evidence that the underlying condition has cleared.

- 1 Record the authorized inspection or maintenance disposition, including any obstruction removed and any qualified work performed.
- 2 Confirm intake screens, exhaust openings, guards, and the exterior cooling-air path are clear and restored to their approved configuration.
- 3 Confirm fan feedback is present and stable. After fan command is stable at or above 80 percent, verify command/feedback variance remains at or below 5 percentage points for ten continuous minutes.
- 4 Confirm no new A12 event occurs during the ten-minute verification interval and no abnormal fan noise or vibration is reported.
- 5 Obtain control-room authorization, record the release, and monitor the next loaded operating interval for recurrence.

Do not release: If any acceptance criterion is unmet, feedback is missing or unstable, variance remains above 5 percentage points, or A12 repeats, retain Maintenance Hold and escalate to qualified maintenance.

Field inspection / maintenance

Control-room release