## File Format of Key.dat

#### **UPDATES**

Version	Authors	Actions	Revision	Date	Distribution
1.0	ΟZ	Coding		13/09/1994	
1.1	DL & BL	Documentation in		02/07/2002	
		French			
2.0	JCW	Re-Creation in		28/02/2009	
		English &			
		Renovation coding			
2.1	JCW	Edits		04/05/2011	
3.0	JCW	Update the length		16/08/2017	
		limit to 255			

Information in this document is subject to change without notice and does not represent a commitment on the part of the supplier. The software described in this document is furnished under a license agreement. The software may be used or copied only in accordance with the terms of the agreement. It is against the law to copy software on any medium except as specifically allowed in the license agreement. The purchaser may make one copy of the software for backup purposes. No part of this manual may be reproduced or transmitted in any form or by any means, without the express permission of the supplier. Whilst the utmost care is taken to ensure the accuracy of the data contained herein, it is provided on the understanding that the supplier shall under no circumstances, be liable for any injuries, expenses, or losses which may be in any way attributable to the use or adaptation of such data.

All trademarks duly acknowledged.

#### **CONTENTS**

Location of the configuration file	4
Function key code number for triggering an action	5
Function key code number for the standard actions	6
The format in the configuration file	8
Importing the function key actions file from the C1 folder	10

Key\_ConfigFormat\_120 Last update : 16/08/2017 Page 3/10

### Location of the configuration file

The function key action configuration file "KEY.DAT" is saved in the subfolder C – Ctemp – Ctemp\Bak of the project folder.

# Function key code number for triggering an action

Key code Description			
1	F1 (Shift type D - not available)		
2	F2		
3	F3		
4	F4		
5	F5		
6	F6		
7	F7		
8	F8		
9 F9			
10 F10 (Shift type D - not available)			
11	F11		
12	F12		
13	F13		
14	F14		
15	F15		
16	F16		
17	BackSpace		
18	Reserved for Tab		
19	Reserved for Enter		
20	Reserved for Shift		
21	Reserved for Control		

22	Reserved for Alt			
23	Reserved for Pause			
24	Esc			
25	Reserved for Space			
26	PageUp			
27	PageDown			
28	End			
29	Home			
30	ArrowLeft			
31	ArrowUp			
32	ArrowRight			
33	ArrowDown			
34	Reserved for Print			
35	Insert			
36	Delete			
37	Reserved for NumLock			

# Function key code number for the standard actions

Key code	Description		
1	On line help		
2 Operation menu (logon and logoff)			
3	Administration menu (user rights configuration)		
4	About window		

5	Reserved		
6	Display menu bar		
7	Display event viewer		
8	Hide menu		
9	SCADA Basic Program management		
10	Exit from the Supervisor		
11	Refresh screen		
12	Report Replay Toolbox		
19	Command zone		
21	Next window		
22	Previous window		
23	Next zone		
24	Previous zone		
25	First zone		
26	Last zone		
121	Variable selector		

### The format in the configuration file

	The format in the configuration file				
No	Description	Т	Size (byte s)	Value	
1	Action type	N	2	1 = Send animation	
				2 = Standard action	
				4 = Function to execute	
2	Key modifier	С	4	"" or "U" = UP	
	DOWN (Key pressed or UP/Key released)			"D" = DOWN	
	SHIFT +			"S" = SHIFT	
				"C" = CTRL	
	CTRL + (Control key) The key combination			The combination of the above cases	
3	Function key code number for triggering an action	N	2	See the section (1)	
4	If Action type = 2, Function key code number for the standard action.	N	2	See the section (2)	
	If not, Nonsense.				
5	If Action type=1, Window – The name of the mimic window which contains the animation.	С	12		
	If Action type=4, Program - The name of the SCADA BASIC program which contains the function to execute.				

				1
6	Branch - The database branch to be used. (Optional.)	С	255	
7	If Action type=1, Identifier - The identifier of the animation which is to operate.	С	30	
	If Action type=4, Function - The function to be executed.			
8	If Action type=4, Arguments - A list of arguments for the function. These may be retrieved using the GETARG instruction.	O	255	
	If not, Nonsense.			
9	Enabling flag	Z	2	0 =Disabled
				Nonzero = Enabled
10	Enabling Bit - The name of a database bit which, if specified, must have a value of 1 to enable the action.	С	256	
11	Reserved			
12	Reserved			
13	Object origin	N	2	0 = local Nonzero = 3 <sup>rd</sup> party objects
14	Object version number	Ν	2	
15	Description	С	255	

## Importing the function key actions file from the C1 folder

The function key actions can be imported from a file in the "C1" subfolder under the project. The file name should be written in the "INCLUDE.DAT" file in the "C1" folder. The object origins of the imported actions will be automatically set to -1 and saved in the "KEY.DAT" file in the "CTEMP" folder.