

Enumala_ConfigFormat_810 Last update : 30/03/2007

UPDATES

Version	Author	Action	Review	Date	Publication
1.0				20/11/98	

Information in this document is subject to change without notice and does not represent a commitment on the part of the supplier. The software described in this document is furnished under a license agreement. The software may be used or copied only in accordance with the terms of the agreement. It is against the law to copy software on any medium except as specifically allowed in the license agreement. The purchaser may make one copy of the software for backup purposes. No part of this manual may be reproduced or transmitted in any form or by any means, without the express permission of the supplier. Whilst the utmost care is taken to ensure the accuracy of the data contained herein, it is provided on the understanding that the supplier shall under no circumstances be liable for any injuries, expenses or losses which may be in any way attributable to the use or adaptation of such data.

All trademarks duly acknowledged.

Enumala_ConfigFormat_810 Last update: 30/03/2007 The **ENUMLABEL** record defines the text for an alarm value in each language.

No.	Description	Туре	Size	Value
1	Type of record	С	9	ENUMLABEL
2	Logical name of the text	С	12	
3	Label for language 1	С	80	
Ν	Label for language N	С	80	

Example:

ENUMLABEL, EnumLab1, Français val0 prio0, Deutsch val0 prio0, English val0 prio 0

The following records define an alarm list.

BEGINNAMELIST

ENUMVALUE

ENUMDEFAULTVALUE

ENDNAMELIST

The **BEGINNAMELIST** record defines a list name.

No.	Description	Туре	Size	Value
1	Type of record	С	13	BEGINNAMELIST
2	Name of the list	С	12	
3	Comment	С	40	

Example:

BEGINNAMELIST, NameList1, Comment1

The **ENUMVALUE** record associates a level of priority and a label with an alarm value.

No.	Description	Туре	Size	Value
1	Type of record	С	9	ENUMVALUE
2	Value of alarm	N	4	-2147483648 to 2147483647
3	Level of priority	N	4	0 to 30
4	Logical name of label	С	12	
5	Value during break	N	4	1: the alarm is displayed
				0: the alarm is not

Enumala_ConfigFormat_810

Last update: 30/03/2007

		1
		displayed
		LUISUIAVEU
		alspia y sa

Example:

ENUMVALUE,0,0,EnumLab1,1

ENUMVALUE, 1, 2, EnumLab 2, 0

ENUMVALUE, 2, 3, EnumLab 3, 0

ENUMVALUE, 3, 4, EnumLab 4, 0

The **ENUMDEFAULTVALUE** record enables you to associate a priority level and a label with alarm values not specified in the list.

No.	Description	Туре	Size	Value
1	Type of record	С	9	ENUMDEFAULTVA LUE
2	Level of priority	N	4	0 to 30
3	Logical name of the label	С	12	

Example:

ENUMDEFAULTVALUE, 0, EnumLabDef

The **ENDNAMELIST** record enables you to specify the end of the list.

No.	Description	Туре	Size	Value
1	Type of record	С	11	ENDNAMELIST

Last update: 30/03/2007

Here is an example of the content of an ENUMALA.DAT file.

ENUMLABEL, EnumLab1, Français val0 prio0, Deutsch val0 prio0, English val0 prio0 **ENUMLABEL**, EnumLab2, Français val1 prio2, Deutsch val1 prio2, English val1 prio2 **ENUMLABEL**, EnumLab3, Français val2 prio3, Deutsch val2 prio3, English val2 prio3 **ENUMLABEL**, EnumLab4, Français val3 prio4, Deutsch val3 prio4, English val3 prio4 **ENUMLABEL**, EnumLab5, Français val7 prio5, Deutsch val7 prio5, English val7 prio5 **ENUMLABEL**, EnumLabDef, Français valeur inconnue ?, Deutsch ?, English ?

BEGINNAMELIST, NameList1, Comment1,

ENUMVALUE, 0, 0, EnumLab 1, 1

ENUMVALUE,1,2,EnumLab2,0

ENUMVALUE, 2, 3, EnumLab 3, 0

ENUMVALUE,3,4,EnumLab4,0

ENUMDEFAULTVALUE, 15, EnumLabDef,

ENDNAMELIST

BEGINNAMELIST, NameList2, Comment2,

ENUMVALUE,0,0,EnumLab1,1

ENUMVALUE, 1, 2, EnumLab 2, 0

ENUMVALUE, 3, 5, EnumLab 3, 0

ENUMVALUE,7,4,EnumLab5,1

ENUMDEFAULTVALUE, 15, EnumLabDef,

ENDNAMELIST

Note: Only the first two language fields in the ENUMLABEL record are used.

Last update : 30/03/2007