

Grid Lost Fault

Author: Wesley
Reviewer: Eason

FAQ\Hybrid INV

Issue introduction

The error Grid Lost Fault on the inverter screen.

Confirmation of basic information

[Photo] SN numbers of inverters.

Guidance for installer

Step 1: Use a multimeter to measure the phase voltage and line voltage at the AC port.

	
phase voltage	line voltage(line voltage= $\sqrt{3}$ ×Phase voltage)

Ensure grid voltage is normal.

Step 2: Check the system status sampling information, which inverter displays on the screen.

Ensure the detection of grid voltage in the inverter is normal.

Settings path: *About* → *System status* → *On-grid*





