

How to Reset Date and Time


Author: Daniel

Reviewer: Eason

Account

Issue introduction


Reset date and time



Operation guidance


Step1: Go to <Plant management> and find the station you want to change the date and time of.

Setting path: *Me*→*Plant management*→*Plant*



Step2: Go to <Edit plant> and change the time zone, then save the settings.

Setting path: < . . . > → *Edit plant* → *Time zone* → *Save*



Please note

- If the setting fails, please check your mobile network, ensure a stable connection, log out of your account, and then log back in. Follow the steps above to make the changes.