

BMS Break

Alarm Attribute

Alarm name	Alarm Severity	Alarm Category
BMS Break	General	Battery alarm

Possible Cause

Cause ID	Possible Cause
1	Battery circuit disconnection fault.
2	Battery voltage sensor disconnection fault.

Suggestion

1. Upgrade to the latest firmware and restart the battery.
2. If the issue remains, provide the completed troubleshooting results to SolaX technical support team through video or images. Including but not limited to:
 - 1) SN number of the inverter.