

BMS Charge Unresponsive

Alarm Attribute

Alarm name	Alarm Severity	Alarm Category
BMS Charge Unresponsive	General	Battery alarm

Possible Cause

Cause ID	Possible Cause
1	Battery charging not responding.
2	The battery is requesting charging from the inverter but the battery cannot receive current.

Suggestion

- 1.Check the minimum charging current setting on the inverter, it should not be 0A.
- 2.Use forced charging mode to charge the battery. If charging is successful, upgrade the inverter firmware to the latest version once the battery is fully charged.
- 3.If forced charging is not possible, ensure the ambient temperature meets the battery's charging conditions.
- 4.If the issue remains, provide the completed troubleshooting results to SolaX technical support team through video or images.Including but not limited to:
 - 1) SN number of the inverter and battery.