

# BMS High Temperature

## Alarm Attribute

| Alarm name           | Alarm Severity | Alarm Category |
|----------------------|----------------|----------------|
| BMS High Temperature | General        | Battery alarm  |

## Possible Cause

| Cause ID | Possible Cause                 |
|----------|--------------------------------|
| 1        | Battery high-temperature fault |

## Suggestion

1.Connect the batteries to the system one by one to identify the faulty battery. If the issue remains, provide the completed troubleshooting results to SolaX technical support team through video or images.Including but not limited to:

- 1) SN number of the inverter.
- 2)SN number of the faulty battery.