

BMS Lower Voltage

Alarm Attribute

Alarm name	Alarm Severity	Alarm Category
BMS Lower Voltage	General	Battery alarm

Possible Cause

Cause ID	Possible Cause
1	Battery cell lower-voltage fault: The voltage of the battery cell is less than 2.85V

Suggestion

1. Use forced charging mode to recharge the battery. If forced charging is not possible, use the T-BAT-Charger to charge the battery individually.

2. If the battery cannot be awakened with charging, provide the completed troubleshooting results to SolaX technical support team through video or images. Including but not limited to:

1) SN number of the inverter.