

DCV Over Current Protection Fault

Alarm Attribute

Alarm name	Alarm Severity	Alarm Category
DCV Over Current Protection Fault	General Alarm	Inverter alarm

Possible Cause

Cause ID	Possible Cause
1	DCV Fault: The on-grid component of DCV exceeds the threshold set by the safety code

Suggestion

- 1.Update the firmware and restart the inverter.
- 2.If the issue remains, provide the inverter's SN number to the SolaX technical support team for further analysis.