

Grid Voltage Fault

Alarm Attribute

Alarm name	Alarm Severity	Alarm Category
Grid Voltage Fault	General	Inverter alarm

Possible Cause

Cause ID	Possible Cause
1	Grid Voltage fault: The grid voltage exceeds the permissible limits set by the safety code.

Suggestion

- 1.Check if the safety code settings are correct and measure the grid voltage to ensure it is within the normal range.
- 2.Update the firmware to the latest version.
- 3.If the issue remains, provide the completed troubleshooting results to SolaX technical support team through video or images.Including but not limited to:
 - 1) SN number of the inverter.
 - 2) Measurement result of the grid voltage.