

PV Connection Direction Fault

Alarm Attribute

Alarm name	Alarm Severity	Alarm Category
PV Connection Direction Fault	General	Inverter alarm

Possible Cause

Cause ID	Possible Cause
1	The PV string is connected in reverse polarity.

Suggestion

1.Measure the voltage of the photovoltaic panels.Check whether the PV string is connected to the inverter in reverse polarity. If yes, wait until the PV string current decreases to below 0.01 A, set DC SWITCH to OFF, and adjust the PV string polarity.

2.If the fault persists, you can turn off the AC and DC switches, wait for 5 minutes, and then turn on the AC and DC switches.

3.If the issue remains, provide the completed troubleshooting results to SolaX technical support team through video or images.Including but not limited to:

- 1) SN number of the inverter.
- 2) The measurement result of the PV voltage.