


MRT-1092 (03/31/16) "Solder Pot - Solder Height Gauge"

- 1. Fill solder to the bottom of the gauge (initial fill height) without the pump in the solder pot.
- 2. When the pump is immersed in the solder pot it will raise the level of solder to the scribed line on the gauge. (Pump fill line)
- 3. Height may vary when using 75mm Wave pump & 2"X2" Wave pump.

NOTE: Do not fill the solder pot above the pump fill line!



Customer Service Nordson SELECT, Inc. 22425 East Appleway Ave Suite 1 Liberty Lake, WA 99019

Office: +1.509.924.4898 Fax: +1.509.533.1299