

NORIKS boxer briefs

Modal boxer briefs — measurements, wearing and care.

Material	95 % modal, 5 % elastane
Sizes	S – 4XL
Seams	Flat seams, no edges that chafe
Waistband	Elastic, without squeezing
Washing	up to 30 °C, delicate cycle, no bleach



IN THE BOX

- Boxer briefs according to the pack you chose (3, 5 or 10 pieces)


QUICK START

1. Choose the same size you normally wear; if you are between two sizes, take the smaller one.
2. Wash with similar shades on a cold delicate cycle.
3. Dry flat or tumble dry on low.

1. Choosing your size

The measurements in the table match the markings **a**, **b**, **c** and **d** on the drawing and are given in centimetres. Choose the same size you normally wear.

Size	S	M	L	XL	2XL	3XL	4XL
a	32	34	36	38	40	42	44
b	33,5	34,5	35,5	36,5	37,5	38,5	39,5
c	21	22	23	24	25	26	27
d	29	30	31	32	33	34	35



Where measurements a, b, c and d are taken.

Measurements may vary by $\pm 1-2$ cm. If you are between two sizes, choose the smaller one — modal stretches and adapts to the body.

2. Wearing

- Wear the waistband at your waist, not below the belly — that way the legs do not ride up.
- Straighten the legs as you put them on; modal remembers the position you give it.
- For sport and hot days choose half a size down — they sit closer and do not bunch up.

3. Washing and care

- Wash colours with colours. Machine wash cold (up to 30 °C), delicate cycle.
- Do not bleach. Fabric softener reduces the elasticity of the waistband — use it rarely or not at all.
- Dry flat or tumble dry on low.
- Do not iron over the elastic waistband or over the printed label.

4. Troubleshooting

What happens	Cause	Solution
The legs ride up	Size too small, or the waistband worn below the belly	Take one size up and pull the waistband onto your waist
The waistband has gone slack	Washing at a high temperature or fabric softener	Wash cold, without fabric softener
Tight on the thighs	The smaller of two sizes was chosen	For stronger thighs take the larger size — measurement d shows the leg width
The fabric has turned grey	Washed with white laundry	Wash black with black; the first wash separately

5. When to replace a pair

- When the waistband no longer returns to shape after being stretched.
- When the fabric becomes see-through at the points of greatest friction.
- Rotating a 5-pack daily, that is usually after 18 – 24 months.

6. Warranty, exchange and returns

- 30 days money back — return the product in the condition in which you received it.
- Free size exchange within 90 days. An e-mail is enough, no paperwork.
- For an exchange or return write to info@noriks.com and quote your order number.