

Peter-pan collar puff-sleeve babydoll dress

EU38 sewing guide . 10 pieces . 2.6 m fabric at 140 cm

text-first guide, no illustrations in this edition. Every step is the engine's own instruction.

Cut list

Bodice Front - cut 1 on fold

Bodice Center Back - cut 2

Bodice Side Back - cut 2

Front Neck Facing - cut 1 on fold, interface

Back Neck Facing - cut 2, interface

Skirt Front - cut 1 on fold

Skirt Back - cut 2 (center back seam)

Puff Sleeve - cut 2

Peter Pan Collar (bebe yaka) - cut 2 + interfacing (1 upper, 1 under + interfacing), lies flat on the shoulders, rounded outer edge

Smocked Yoke Panel (büzgüyaka panosu) - cut 1 rectangle(s) 1081 x 160 mm (join to a 1051 mm flat top edge that gathers down)

Steps

1. Print and check the 3 cm calibration square before cutting.
2. This block uses standard assumptions for shoulder slope, underbust and arm width . sew a quick muslin (test version) from cheap fabric first and adjust before cutting your real fabric.
3. Cut every piece as labelled: pieces marked 'on fold' on the fabric fold, 'cut 2' twice, sleeves twice.
4. Fuse interfacing to the neck facings.
5. Staystitch the neckline just inside the seam line so it doesn't stretch while you work.
6. Staystitch the curved princess edges too, for the same reason.
7. Sew each bodice princess seam: pin center panel to side panel matching the bust notch, sew, clip the side panel's curve over the bust inside the seam allowance, press toward the center.
8. Sew the remaining waist darts (where a panel wasn't split), pressing toward the center.
9. Sew the bodice shoulder seams and press them open.
10. Sew the front and back neck facings together at the shoulders; finish the facing's outer edge (zigzag, overlock or turn 5 mm and stitch).
11. Attach the facing to the neckline right sides together, leaving the last 2 cm free at each center back edge (the zipper goes there later). Trim to 6 mm, clip into the curve every 2 cm.
12. Understitch: press the seam allowance toward the facing and stitch it to the facing 2 mm from the seam this keeps the facing rolled inside. Turn, press, tack at the shoulder seams.
13. Sew the bodice side seams.

14. Gather the skirt panels along the marked line until they match the bodice waist.
15. Sew the skirt seams (leave the center back seam open where the zipper will go), then join bodice to skirt at the underbust seam (the empire line sits right under the bust), matching side seams and lining the gore seams up with the bodice princess seams as closely as possible.
16. Insert an invisible zipper in the center back through bodice and skirt: install the zipper BEFORE closing the seam below it, then close the rest of the seam.
17. Fold the free facing ends back over the zipper tape and hand-tack them down so the edge sits clean against the zipper.
18. Sew each sleeve seam. Run gathering stitches between the cap notches, ease the cap into the armhole and set the sleeves in.
19. Puff/gathered head: run two rows of gathering along the marked crown line between the two crown notches, then pull them up to fit the armhole between those notches so the extra fullness stands up over the shoulder the length below the notches matches the armhole 1:1, so ease only the crown.
20. Try it on, then hem with a 2 cm double fold.
21. Collar (Peter Pan Collar (bebe yaka)): drafted so its neck edge equals the garment neckline and its outer edge is rounded. Interface the under-collar, sew upper to under-collar right sides together along the outer edge, clip the curves, turn and press so the seam rolls under. Sew the neck edge to the neckline matching centre back and the shoulder notches, then finish with a facing or bias binding.
22. Smocked gathering (büzgüsmok): cut the panel. Transfer the smocking dot grid to the wrong side. Pick up the dots row by row to pleat the fabric down to the marked finished length (3:1), then smock the pleats with your chosen embroidery. Join the gathered edge to the body at the placement notch, matching the finished length.