

Square-neck back-tie babydoll top

EU38 sewing guide . 7 pieces . 1.8 m fabric at 140 cm

text-first guide, no illustrations in this edition. Every step is the engine's own instruction.

Cut list

Top Center Front - cut 1 on fold

Top Side Front - cut 2

Top Center Back - cut 2

Top Side Back - cut 2

Front Neck Facing - cut 1 on fold, interface

Back Neck Facing - cut 2, interface

Back Tie (s1rt ba 1) - cut 2 rectangle(s) 80 x 330 mm (finished 25 x 300 mm), attach at each back waist edge, cross and knot to

Steps

1. Print and check the 3 cm calibration square before cutting.
2. This block uses standard assumptions for shoulder slope and underbust . sew a quick muslin first and adjust before cutting your real fabric.
3. Cut every piece as labelled ('on fold' on the fabric fold, 'cut 2' twice). Check the neck opening against your head circumference . a top has no zipper, it must slip over your head.
4. Fuse interfacing to the neck facings.
5. Staystitch the neckline just inside the seam line so it doesn't stretch while you work.
6. Sew each princess seam: pin center panel to side panel matching the bust notch, sew from armhole to hem in one pass, clip the curve over the bust inside the seam allowance, press toward the center.
7. Sew the shoulder seams and press them open.
8. Sew the front and back neck facings together at the shoulders; finish the facing's outer edge (zigzag, overlock or turn 5 mm and stitch).
9. Attach the facing to the neckline right sides together, sewing exactly on the seam line. Trim to 6 mm, clip into the curve every 2 cm.
10. Understitch: press the seam allowance toward the facing and stitch it to the facing 2 mm from the seam . this is what keeps the facing rolled inside. Turn, press, and tack the facing down at the shoulder seams.
11. Sew the side seams.
12. Finish the armholes with bias binding.
13. Hem with a 2 cm double fold.

14. Ties (ba): cut the tie rectangle(s) as labelled, fold each in half lengthwise right sides together, stitch the long edge and one short end, turn right side out and press. Stitch the raw end to the marked placement notch (right sides together, caught in the seam), then knot into a bow. The tie is self-fabric cut on the straight grain.