

Boat-neck sleeveless shift mini

EU38 sewing guide . 9 pieces . 1.9 m fabric at 140 cm

text-first guide, no illustrations in this edition. Every step is the engine's own instruction.

Cut list

Bodice Center Front - cut 1 on fold

Bodice Side Front - cut 2

Bodice Center Back - cut 2

Bodice Side Back - cut 2

Skirt Center Front - cut 1 on fold

Skirt Side Front - cut 2

Skirt Center Back - cut 2 (center back seam)

Skirt Side Back - cut 2

Steps

1. Print and check the 3 cm calibration square before cutting.
2. This block uses standard assumptions for shoulder slope, underbust - sew a quick muslin (test version) from cheap fabric first and adjust before cutting your real fabric.
3. Cut every piece as labelled: pieces marked 'on fold' on the fabric fold, 'cut 2' twice.
4. Staystitch the neckline just inside the seam line so it doesn't stretch while you work.
5. Staystitch the curved princess edges too, for the same reason.
6. Sew each bodice princess seam: pin center panel to side panel matching the bust notch, sew, clip the side panel's curve over the bust inside the seam allowance, press toward the center.
7. Sew the bodice shoulder seams and press them open.
8. Prepare the neckline bias strip: join the ends as needed and press it in half lengthwise along the marked fold line.
9. Bind the neckline with the bias strip, right sides together and raw edges even, leaving the last 2 cm free at each center back edge (the zipper goes there later). Ease the strip gently around the curves. Trim to 6 mm, turn the folded edge to the inside and topstitch or slipstitch it down.
10. Sew the bodice side seams.
11. Finish each armhole the same way with its bias strip: press it in half, bind the armhole right sides together, ease around the curve, then turn and topstitch it to the inside.
12. Sew each skirt gore seam (center panel to side panel, matching the tip notch), pressing toward the center.
13. Sew the skirt seams (leave the center back seam open where the zipper will go), then join bodice to skirt at the waist seam, matching side seams and lining the gore seams up with the bodice princess seams as closely as possible.

14. Insert an invisible zipper in the center back through bodice and skirt: install the zipper BEFORE closing the seam below it, then close the rest of the seam.
15. Fold the free binding ends back over the zipper tape and hand-tack them down so the edge sits clean against the zipper.
16. Try it on, then hem with a 2 cm double fold.