

RUCKUS One Subscriptions Licensing Guide

No part of this content may be reproduced in any form or by any means or used to make any derivative work (such as translation, transformation, or adaptation) without written permission from Vistance Networks, Inc. and/or its affiliates ("Vistance"). Vistance reserves the right to revise or change this content from time to time without obligation on the part of Vistance to provide notification of such revision or change.

Export Restrictions

These products and associated technical data (in print or electronic form) may be subject to export control laws of the United States of America. It is your responsibility to determine the applicable regulations and to comply with them. The following notice is applicable for all products or technology subject to export control:

These items are controlled by the U.S. Government and authorized for export only to the country of ultimate destination for use by the ultimate consignee or end-user(s) herein identified. They may not be resold, transferred, or otherwise disposed of, to any other country or to any person other than the authorized ultimate consignee or end-user(s), either in their original form or after being incorporated into other items, without first obtaining approval from the U.S. government or as otherwise authorized by U.S. law and regulations.

Disclaimer

THIS CONTENT AND ASSOCIATED PRODUCTS OR SERVICES ("MATERIALS"), ARE PROVIDED "AS IS" AND WITHOUT WARRANTIES OF ANY KIND, WHETHER EXPRESS OR IMPLIED. TO THE FULLEST EXTENT PERMISSIBLE PURSUANT TO APPLICABLE LAW, VISTANCE DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, TITLE, NON-INFRINGEMENT, FREEDOM FROM COMPUTER VIRUS, AND WARRANTIES ARISING FROM COURSE OF DEALING OR COURSE OF PERFORMANCE. Vistance does not represent or warrant that the functions described or contained in the Materials will be uninterrupted or error-free, that defects will be corrected, or are free of viruses or other harmful components. Vistance does not make any warranties or representations regarding the use of the Materials in terms of their completeness, correctness, accuracy, adequacy, usefulness, timeliness, reliability or otherwise. As a condition of your use of the Materials, you warrant to Vistance that you will not make use thereof for any purpose that is unlawful or prohibited by their associated terms of use.

Limitation of Liability

IN NO EVENT SHALL VISTANCE, VISTANCE AFFILIATES, OR THEIR OFFICERS, DIRECTORS, EMPLOYEES, AGENTS, SUPPLIERS, LICENSORS AND THIRD PARTY PARTNERS, BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, PUNITIVE, INCIDENTAL, EXEMPLARY OR CONSEQUENTIAL DAMAGES, OR ANY DAMAGES WHATSOEVER, EVEN IF VISTANCE HAS BEEN PREVIOUSLY ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, WHETHER IN AN ACTION UNDER CONTRACT, TORT, OR ANY OTHER THEORY ARISING FROM YOUR ACCESS TO, OR USE OF, THE MATERIALS. Because some jurisdictions do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of liability for consequential or incidental damages, some of the above limitations may not apply to you.

Trademarks

Vistance Networks, Aurora Networks, and RUCKUS Networks and their associated logos are trademarks of Vistance Networks, Inc. and/or its affiliates in the U.S. and other countries. For additional trademark information see <https://www.vistancenetworks.com/trademarks/>. All product names, trademarks and registered trademarks are property of their respective owners.

Patent Marking Notice

For applicable patents, see:

- www.an-pat.com (Aurora Networks)
- www.RN-pat.com (RUCKUS Networks)

Contents

- Contact Information, Resources, and Conventions.....5**
 - Contacting RUCKUS Customer Services and Support.....5
 - What Support Do I Need?..... 5
 - Open a Case..... 5
 - Self-Service Resources..... 6
 - Document Feedback..... 6
 - RUCKUS Product Documentation Resources..... 6
 - Online Training Resources..... 6
 - Document Conventions.....7
 - Notes, Cautions, and Safety Warnings..... 7
 - Command Syntax Conventions..... 7
- About This Guide..... 9**
 - Introduction..... 9
 - New in This Document..... 9
- RUCKUS One Licenses.....11**
 - RUCKUS One Subscription Licenses..... 11
 - RUCKUS One Renewal Licenses.....13
 - Tiered Licensing System..... 14
 - Essentials Tier.....15
 - Professional Tier.....15
 - Analytics Data Retention.....16
 - RUCKUS One Regions..... 17
 - Customer Account Types..... 17
 - RUCKUS End Customers..... 17
 - RUCKUS One Managed Service Providers..... 17
 - RUCKUS One Value-Added Resellers.....18
 - Subscription Periods for RUCKUS End Customers.....18
 - Courtesy Period.....18
 - License Expiration.....18
 - RUCKUS One License Support for SmartEdge vAppliance..... 19
 - RUCKUS One License Support For RUCKUS IoT Controller.....19
- Activating the RUCKUS One Licenses 21**
 - Subscription Activations.....21
 - Activating the RUCKUS One Licenses..... 21
 - Activating the Essentials License for RUCKUS End Customers..... 21
 - Activating the Professional License for RUCKUS End Customers.....27
 - Activating the License for a RUCKUS Managed Service Provider.....34
 - Activating Licenses for RUCKUS End Customers from the RUCKUS One Web Interface.....41
 - Activating Licenses for Managed Service Providers from the RUCKUS One Web Interface..... 43
 - RUCKUS One Licensing Compliance..... 45
 - License Compliance for RUCKUS One End Customers..... 45
 - Compliance for RUCKUS One Managed Service Providers.....46
- Viewing Licenses..... 49**
 - Viewing the Licenses for RUCKUS End Customers in the RUCKUS One Cloud Portal.....49

Viewing the Licenses for MSP Customers in the RUCKUS One Cloud Portal.....	51
--	----

Contact Information, Resources, and Conventions

- Contacting RUCKUS Customer Services and Support..... 5
- Document Feedback..... 6
- RUCKUS Product Documentation Resources..... 6
- Online Training Resources..... 6
- Document Conventions..... 7
- Command Syntax Conventions..... 7

Contacting RUCKUS Customer Services and Support

The Customer Services and Support (CSS) organization is available to provide assistance to customers with active warranties on their RUCKUS products, and to customers and partners with active support contracts.

For product support information and details on contacting the Support Team, go directly to the RUCKUS Support Portal using <https://support.ruckuswireless.com>, or go to <https://www.ruckusnetworks.com> and select **Support**.

What Support Do I Need?

Technical issues are usually described in terms of priority (or severity). To determine if you need to call and open a case or access the self-service resources, use the following criteria:

- Priority 1 (P1)—Critical. Network or service is down and business is impacted. No known workaround. Go to the **Submit a Case** section.
- Priority 2 (P2)—High. Network or service is impacted, but not down. Business impact may be high. Workaround may be available. Go to the **Submit a Case** section.
- Priority 3 (P3)—Medium. Network or service is moderately impacted, but most business remains functional. Click the **CONTACT** tab at the top of the page and explore the **Self-Service Online Help** options.
- Priority 4 (P4)—Low. Requests for information, product documentation, or product enhancements. Click the **CONTACT** tab at the top of the page and explore the **Self-Service Online Help** options.

Open a Case

When your entire network is down (P1), or severely impacted (P2), call the appropriate telephone number listed below to get help:

- Continental United States: 1-855-782-5871
- Canada: 1-855-782-5871
- Europe, Middle East, Africa, Central and South America, and Asia Pacific, toll-free numbers are available at <https://support.ruckuswireless.com/contact-us> and Live Chat is also available.
- Worldwide toll number for our support organization. Phone charges will apply: +1-650-265-0903

We suggest that you keep a physical note of the appropriate support number in case you have an entire network outage.

Self-Service Resources

The RUCKUS Support Portal at <https://support.ruckuswireless.com> offers a number of tools to help you to research and resolve problems with your RUCKUS products, including:

- Technical Documentation—<https://support.ruckuswireless.com/documents>
- Community Forums—<https://community.ruckuswireless.com>
- Knowledge Base Articles—<https://support.ruckuswireless.com/answers>
- Software Downloads and Release Notes—https://support.ruckuswireless.com/#products_grid
- Security Bulletins—<https://support.ruckuswireless.com/security>

Using these resources will help you to resolve some issues, and will provide the Technical Assistance Center (TAC) with additional data from your troubleshooting analysis if you still require assistance through a support case or Return Merchandise Authorization (RMA). If you still require help, open and manage your case at https://support.ruckuswireless.com/case_management.

Document Feedback

RUCKUS is interested in improving its documentation and welcomes your comments and suggestions.

You can email your comments to RUCKUS at Ruckus-Docs@ruckusnetworks.com.

When contacting us, include the following information:

- Document title and release number
- Document part number (on the cover page)
- Page number (if appropriate)

For example:

- RUCKUS SmartZone Upgrade Guide, Release 5.0
- Part number: 800-71850-001 Rev A
- Page 7

RUCKUS Product Documentation Resources

Visit the RUCKUS website to locate related documentation for your product and additional RUCKUS resources.

Release Notes and other user documentation are available at <https://support.ruckuswireless.com/documents>. You can locate the documentation by product or perform a text search. Access to Release Notes requires an active support contract and a RUCKUS Support Portal user account. Other technical documentation content is available without logging in to the RUCKUS Support Portal.

White papers, data sheets, and other product documentation are available at <https://www.ruckusnetworks.com>.

Online Training Resources

To access a variety of online RUCKUS training modules, including free introductory courses to wireless networking essentials, site surveys, and products, log in to the RUCKUS Training Portal at <https://ruckus.myabsorb.com> using your RUCKUS Partner Portal account credentials. If you do not have an account, you can sign up for one on the login screen. Once logged in, you can access your training dashboard. There you will find links to the RUCKUS Education YouTube channel, Partner training and accreditation courses, the RUCKUS NETWORKING course catalog, and more.

Document Conventions

The following table lists the text conventions that are used throughout this guide.

TABLE 1 Text Conventions

Convention	Description	Example
<code>monospace</code>	Identifies command syntax examples	<code>device(config)# interface ethernet 1/1/6</code>
bold	User interface (UI) components such as screen or page names, keyboard keys, software buttons, and field names	On the Start menu, click All Programs .
<i>italics</i>	Publication titles	Refer to the <i>RUCKUS Small Cell Release Notes</i> for more information.

Notes, Cautions, and Safety Warnings

Notes, cautions, and warning statements may be used in this document. They are listed in the order of increasing severity of potential hazards.

NOTE

A NOTE provides a tip, guidance, or advice, emphasizes important information, or provides a reference to related information.

ATTENTION

An ATTENTION statement indicates some information that you must read before continuing with the current action or task.



CAUTION

A CAUTION statement alerts you to situations that can be potentially hazardous to you or cause damage to hardware, firmware, software, or data.



DANGER

A DANGER statement indicates conditions or situations that can be potentially lethal or extremely hazardous to you. Safety labels are also attached directly to products to warn of these conditions or situations.

Command Syntax Conventions

Bold and italic text identify command syntax components. Delimiters and operators define groupings of parameters and their logical relationships.

Convention	Description
bold text	Identifies command names, keywords, and command options.
<i>italic text</i>	Identifies a variable.
[]	Syntax components displayed within square brackets are optional. Default responses to system prompts are enclosed in square brackets.
{x y z}	A choice of required parameters is enclosed in curly brackets separated by vertical bars. You must select one of the options.
x y	A vertical bar separates mutually exclusive elements.
< >	Nonprinting characters, for example, passwords, are enclosed in angle brackets.
...	Repeat the previous element, for example, <i>member[member...]</i> .
\	Indicates a "soft" line break in command examples. If a backslash separates two lines of a command input, enter the entire command at the prompt without the backslash.

About This Guide

- [Introduction.....](#) 9
- [New in This Document.....](#) 9

Introduction

The *RUCKUS One Subscriptions Licensing Guide* provides information on how to procure and manage RUCKUS One licenses for APs, ICX Switches, and SmartEdge devices.

New in This Document

TABLE 2 Summary of Changes

Feature	Description	Reference
Tiered Licensing	Config Templates are now available only with the PRO license.	Tiered Licensing System on page 14
License support for RUCKUS IoT Controller	The RUCKUS IoT Controller uses standard RUCKUS One device-agnostic subscription licenses. Each onboarded IoT Controller consumes one such license.	RUCKUS One License Support For RUCKUS IoT Controller on page 19
Email Notification	Prime Admins can now receive email notification with details of the entitlement and the allotted quantity of licenses.	Activating Licenses for Managed Service Providers from the RUCKUS One Web Interface on page 43

RUCKUS One Licenses

• RUCKUS One Subscription Licenses.....	11
• Tiered Licensing System.....	14
• RUCKUS One Regions.....	17
• Customer Account Types.....	17
• Subscription Periods for RUCKUS End Customers.....	18
• RUCKUS One License Support for SmartEdge vAppliance.....	19
• RUCKUS One License Support For RUCKUS IoT Controller.....	19

RUCKUS One Subscription Licenses

RUCKUS One subscriptions are now 100% device agnostic. The end-to-end agnostic licensing model eliminates the need for differentiating SKUs between access points (APs), RUCKUS ICX Switches, and SmartEdge devices. You can now purchase, activate, and entitle subscriptions and assign the licenses in Cloud. When you add a new device to your RUCKUS One account, the newly added device will utilize the license from the license pool. When you delete a device from your RUCKUS One account, the device will be removed from your RUCKUS One account and the license is automatically released back to the pool of available licenses. MSP accounts can now assign device subscriptions to their end customers without the specifying device type such as number of APs, number of switches, and number of SmartEdge devices.

RUCKUS One licenses are available as standard licenses and temporary or trial licenses that support full product functionality.

RUCKUS One standard licenses have an activation grace period of 180 days after which the subscription start date cannot be modified. The 180-day activation grace period provides self-service ability to select the subscription start date within 180 days from the day the purchase order was received by RUCKUS. That is, the user can log in to activate the license on any day within the activation grace period of 180 days and can even select a date in the future, within the activation grace period, as the subscription start date. Correspondingly, the subscription end date is calculated automatically by adding the purchased subscription term duration to the selected subscription start date; thereby ensuring the full term of the subscription to the user.

The following table lists the available RUCKUS One subscription licenses.

TABLE 3 RUCKUS One Essentials and Professional Subscription Licenses

License Type	Description	Note
RUCKUS One Essentials Tier for RUCKUS End Customers		
CLD-ESNT-APSW-REC1	RUCKUS One Essentials 1-year subscription for 1 network device (AP or Switch) REC. Switch RMT support is not included and is required to be purchased separately.	• These SKUs are for purchase only by RUCKUS End Customers. • These subscriptions licenses are owned by the RUCKUS End Customers.
CLD-ESNT-APSW-REC3	RUCKUS One Essentials 3-year subscription for 1 network device (AP or Switch) REC. Switch RMT support is not included and is required to be purchased separately.	• These SKUs are for purchase only by RUCKUS End Customers. • These subscriptions licenses are owned by the RUCKUS End Customers.

TABLE 3 RUCKUS One Essentials and Professional Subscription Licenses (continued)

License Type	Description	Note
CLD-ESNT-APSW-REC5	RUCKUS One Essentials 5-year subscription for 1 network device (AP or Switch) REC. Switch RMT support is not included and is required to be purchased separately.	- These SKUs are for purchase only by RUCKUS End Customers. - These subscriptions licenses are owned by the RUCKUS End Customers.
RUCKUS One Professional Tier for RUCKUS End Customers		
CLD-PROF-APSW-REC1	RUCKUS One Professional 1-year subscription for 1 network device (AP or Switch) REC. Switch RMT support is not included and is required to be purchased separately.	- These SKUs are for purchase only by RUCKUS End Customers. - These subscriptions licenses are owned by the RUCKUS End Customers.
CLD-PROF-APSW-REC3	RUCKUS One Professional 3-year subscription for 1 network device (AP or Switch) REC. Switch RMT support is not included and is required to be purchased separately.	- These SKUs are for purchase only by RUCKUS End Customers. - These subscriptions licenses are owned by the RUCKUS End Customers.
CLD-PROF-APSW-REC5	RUCKUS One Professional 5-year subscription for 1 network device (AP or Switch) REC. Switch RMT support is not included and is required to be purchased separately.	- These SKUs are for purchase only by RUCKUS End Customers. - These subscriptions licenses are owned by the RUCKUS End Customers.
RUCKUS One Professional Tier for RUCKUS Partners and Cloud MSPs		
CLD-PROF-APSW-MSP1	RUCKUS One Professional 1-year subscription for 1 network device (AP or Switch) MSP. Switch RMT support is not included and is required to be purchased separately.	- These SKUs are for purchase only by RUCKUS Channel/ Partners/Cloud MSPs. - These subscriptions licenses are owned by the Channel/ Partners/Cloud MSPs.
CLD-PROF-APSW-MSP3	RUCKUS One Professional 3-year subscription for 1 network device (AP or Switch) MSP. Switch RMT support is not included and is required to be purchased separately.	- These SKUs are for purchase only by RUCKUS Channel/ Partners/Cloud MSPs. - These subscriptions licenses are owned by the Channel/ Partners/Cloud MSPs.
CLD-PROF-APSW-MSP5	RUCKUS One Professional 5-year subscription for 1 network device (AP or Switch) MSP. Switch RMT support is not included and is required to be purchased separately.	- These SKUs are for purchase only by RUCKUS Channel/ Partners/Cloud MSPs. - These subscriptions licenses are owned by the Channel/ Partners/Cloud MSPs.
CLD-PROF-APSW-MSP7	RUCKUS One Professional 7-year subscription for 1 network device (AP or Switch) MSP. Switch RMT support is not included and is required to be purchased separately.	- These SKUs are for purchase only by RUCKUS Channel/ Partners/Cloud MSPs. - These subscriptions licenses are owned by the Channel/ Partners/Cloud MSPs.

RUCKUS One Renewal Licenses

The following table lists the available RUCKUS One renewal licenses.

TABLE 4 RUCKUS One Essentials and Professional Subscription Licenses

License Type	Description	Note
RUCKUS One Essentials Tier for RUCKUS End Customers		
CLR-ESNT-APSW-REC1	RUCKUS One Essentials 1-Yr Subscription for 1 network device (AP or Switch) for REC - Renewal. Switch RMT support is not included and is required to be purchased separately.	- These SKUs are for purchase only by RUCKUS End Customers. - These subscriptions licenses are owned by the RUCKUS End Customers.
CLR-ESNT-APSW-REC3	RUCKUS One Essentials 3-Yr Subscription for 1 network device (AP or Switch) for REC - Renewal. Switch RMT support is not included and is required to be purchased separately.	- These SKUs are for purchase only by RUCKUS End Customers. - These subscriptions licenses are owned by the RUCKUS End Customers.
CLR-ESNT-APSW-REC5	RUCKUS One Essentials 5-Yr Subscription for 1 network device (AP or Switch) for REC - Renewal. Switch RMT support is not included and is required to be purchased separately.	- These SKUs are for purchase only by RUCKUS End Customers. - These subscriptions licenses are owned by the RUCKUS End Customers.
RUCKUS One Professional Tier for RUCKUS End Customers		
CLR-PROF-APSW-REC1	RUCKUS One Professional 1-Yr Subscription for 1 network device (AP or Switch) for REC - Renewal. Switch RMT support is not included and is required to be purchased separately.	- These SKUs are for purchase only by RUCKUS End Customers. - These subscriptions licenses are owned by the RUCKUS End Customers.
CLR-PROF-APSW-REC3	RUCKUS One Professional 3-Yr Subscription for 1 network device (AP or Switch) for REC - Renewal. Switch RMT support is not included and is required to be purchased separately.	- These SKUs are for purchase only by RUCKUS End Customers. - These subscriptions licenses are owned by the RUCKUS End Customers.
CLR-PROF-APSW-REC5	RUCKUS One Professional 5-Yr Subscription for 1 network device (AP or Switch) for REC - Renewal. Switch RMT support is not included and is required to be purchased separately.	- These SKUs are for purchase only by RUCKUS End Customers. - These subscriptions licenses are owned by the RUCKUS End Customers.
RUCKUS One Professional Tier for RUCKUS Partners and Cloud MSPs		
CLR-PROF-APSW-MSP1	RUCKUS One Professional 1-Yr Subscription for 1 network device (AP or Switch) for MSP - Renewal. Switch RMT support is not included and is required to be purchased separately.	- These SKUs are for purchase only by RUCKUS Channel/ Partners/Cloud MSPs. - These subscriptions licenses are owned by the Channel/ Partners/Cloud MSPs.

TABLE 4 RUCKUS One Essentials and Professional Subscription Licenses (continued)

License Type	Description	Note
CLR-PROF-APSW-MSP3	RUCKUS One Professional 3-Yr Subscription for 1 network device (AP or Switch) for MSP - Renewal. Switch RMT support is not included and is required to be purchased separately.	- These SKUs are for purchase only by RUCKUS Channel/ Partners/Cloud MSPs. - These subscriptions licenses are owned by the Channel/ Partners/Cloud MSPs.
CLR-PROF-APSW-MSP5	RUCKUS One Professional 5-Yr Subscription for 1 network device (AP or Switch) for MSP - Renewal. Switch RMT support is not included and is required to be purchased separately.	- These SKUs are for purchase only by RUCKUS Channel/ Partners/Cloud MSPs. - These subscriptions licenses are owned by the Channel/ Partners/Cloud MSPs.
CLR-PROF-APSW-BDG1	RUCKUS One Professional 1-Yr Subscription for 1 network device (AP or Switch) for MSP Bulldog only - Renewal. Switch RMT support is not included and is required to be purchased separately.	- These SKUs are for purchase only by RUCKUS Channel/ Partners/Cloud MSPs. - These subscriptions licenses are owned by the Channel/ Partners/Cloud MSPs.
CLR-PROF-APSW-BDG3	RUCKUS One Professional 3-Yr Subscription for 1 network device (AP or Switch) for MSP Bulldog only - Renewal. Switch RMT support is not included and is required to be purchased separately.	- These SKUs are for purchase only by RUCKUS Channel/ Partners/Cloud MSPs. - These subscriptions licenses are owned by the Channel/ Partners/Cloud MSPs.
CLR-PROF-APSW-BDG5	RUCKUS One Professional 5-Yr Subscription for 1 network device (AP or Switch) for MSP Bulldog only - Renewal. Switch RMT support is not included and is required to be purchased separately.	- These SKUs are for purchase only by RUCKUS Channel/ Partners/Cloud MSPs. - These subscriptions licenses are owned by the Channel/ Partners/Cloud MSPs.

The RUCKUS One licenses are considered device-agnostic, which means the licenses can be used for managing network devices such as APs, switches, and SmartEdge devices.

NOTE

Licenses do not include switch RMT support, which must be purchased separately.

Purchased licenses must be activated to become valid. License activation and management can be handled through the RUCKUS Support Portal (<https://support.ruckuswireless.com>).

An email message is sent to the user identified on the purchase order with instructions on how to activate the licenses. For more information, refer to [Activating the RUCKUS One Licenses](#) on page 21.

Tiered Licensing System

This topic provides information on tiered licenses.

RUCKUS One provides the following tiers in the tiered licensing system:

- Essentials
- Professional

Essentials Tier

Essentials is the entry-level tier targeted for small customers to migrate to Software as a Service (SaaS) networking. Most of the customers will be included in the Essentials tier. The Essentials tier provides most of the current RUCKUS capabilities, such as individual products, features, and associated support.

Professional Tier

Professional is the premium tier with additional capabilities, including all the components that are available in the Essentials tier, plus additional capabilities.

The following table shows a basic comparison of the capabilities for the Essentials and Professional tiered licensing system.

TABLE 5 Essentials and Professional Tier Capabilities

Capabilities	Essentials	Professional
Administration		
Wired & Wireless Network Management	Yes	Yes
Edge Gateway Management (RWG & RUCKUS Edge)	Yes	Yes
Multi-language support	Yes	Yes
Admin SSO	No	Yes NOTE Downgrading an MSP-EC tenant from the Professional to the Essentials tier removes the SSO configuration and deletes all associated administrators.
Configuration		
System Notifications via email/SMS/Webhooks	Yes	Yes
SD-LAN Centralized Forwarding (RUCKUS Edge)	Yes	Yes
Configuration Templates	No	Yes
Configuration Templates (MSP)	No	Yes
Personal Identity Network (PIN)	No	Yes
Analytics and Reports		
AI-driven Incident Management (Connection, Performance, and Infrastructure)	Yes	Yes
AI-driven Incident Management (Security: TCP-SYN DDOS)	No	Yes
IntentAI: AI-driven Radio Resource Management (RRM), EquiFlex, and AI Operations	Yes	Yes
AI Health	Yes	Yes
Data Studio (Custom reporting and dashboards)	Yes	Yes
Service Validation	No	Yes
Network Configuration Analysis	No	Yes
Video Call QoE	No	Yes
Analytics Data Retention	1 month	Up to 12 months For more information, see Analytics Data Retention on page 16
Security & Policy Management		

TABLE 5 Essentials and Professional Tier Capabilities (continued)

Capabilities	Essentials	Professional
DPSK or DPSK3	Yes	Yes
Property Management	Yes	Yes
Adaptive Policies	Yes	Yes
Identity and Identity Group management	Yes	Yes
Certificate Templates	Yes	Yes
Onboarding Workflow	No	Yes
APIs		
RF Tools Integrations (Hamina, Ekahau)	Yes	Yes
Open API Support	Yes	Yes

Analytics Data Retention

Analytics data retention refers to the policies and practices for storing and managing data collected from network devices and systems over a period of time. This data can include logs, performance metrics, and other relevant information used for monitoring, troubleshooting, and analyzing network performance.

The following retention criteria apply to searchable data and queryable data across different licensing tiers. The following table lists the retention scope for different capabilities. The terms used in the table are defined as follows:

- **Search Window:** Refers to the maximum period users can select in the date picker to search for historical data.
- **Query Window:** Refers to the maximum period for which data can be retrieved and analyzed in a single query.
- **Data Availability:** Refers to the total duration for which data is stored and accessible within the system.

Analytics data retention for Professional tier licenses is available for up to 12 months.

TABLE 6 Analytics Data Retention Scope for Professional and Essentials Tier Licenses

Capability	Feature/Page	Tier License	Search Window	Query Window	Data Availability
Dashboard	Dashboard Elements	Professional	3 months	1 month	12 months
		Essentials	1 month	1 month	1 month
AI Assurance	Incidents	Professional	3 months	1 month	12 months
		Essentials	1 month	1 month	1 month
AI Assurance	IntentAI	Professional	NA	1 month	IntentAI Audit Trail and KPIs are available for up to last 30 days.
		Essentials	NA	1 month	
AI Assurance	Service Validation Runs	Professional	NA	1 month	1 month. A Service Validation test is retained for 31 days after its most recent run. If no new run is recorded within this period, the test and its associated run data are deleted.
		Essentials	NA	NA	NA
AI Assurance	Configuration Change	Professional	1 month	1 month	1 month
		Essentials	1 month	1 month	1 month

TABLE 6 Analytics Data Retention Scope for Professional and Essentials Tier Licenses (continued)

Capability	Feature/Page	Tier License	Search Window	Query Window	Data Availability
Client Troubleshooting	- Events - Packet Capture (Pcap)	Professional	3 months	1 month	12 months
		Essentials	1 month	1 month	1 month
Business Insights	Data Studio	Professional	NA	3 months	12 months
		Essentials	NA	3 months	1 month
Business Insights	Reports	Professional	12 months	1 month	12 months
		Essentials	1 month	1 month	1 month
	Timeline	Professional	3 months	1 month	
		Essentials Note: For tenants with the Essentials license, the Timeline page allows a selection period of up to 3 months, whereas other pages share a common date picker with a maximum search window of 1 month. This discrepancy can lead to inconsistencies when navigating between pages. If the selected date range on the Timeline page exceeds 30 days, it will be reset to the default range upon leaving the Timeline page.	3 months	1 month	

RUCKUS One Regions

The RUCKUS One tiered licensing system is supported across the following regions:

- North America
- Europe
- Asia

Customer Account Types

The following two customer account types are supported by RUCKUS One:

- RUCKUS End Customers (RECs)
- RUCKUS One Managed Service Providers (MSPs)

RUCKUS End Customers

RUCKUS End Customers (RECs) purchase the subscriptions from the RUCKUS partners. The RECs own the subscription licenses.

RUCKUS One Managed Service Providers

RUCKUS One Managed Service Providers (MSPs) purchase the subscriptions from RUCKUS and sell their services to their own end customers (MSP ECs). The RUCKUS Partners own the subscription licenses.

RUCKUS One Value-Added Resellers

RUCKUS One Value-Added Resellers (VARs) are authorized RUCKUS partners. VARs can add or invite administrators to manage their RUCKUS accounts. VARs manage REC and MSP customers.

Subscription Periods for RUCKUS End Customers

The customer can purchase subscriptions for a time interval to use the RUCKUS One. During the subscription period, the network devices and services remain operational. At the end of the subscription period, the customer must renew the subscription to continue to avail the services and remain a valued customer. The customer is notified of upcoming subscription expiration and presented with multiple opportunities to renew the subscriptions.

Courtesy Period

The courtesy period is 60 days for all device and service subscriptions. During the courtesy period, devices and services remain operational, configurable, and continue to function. Subscription renewals are applicable during the courtesy period. The courtesy period has a one-time extension option triggered by sales or other back-end processes.

RUCKUS One retains the device configuration for 90 days after the end of the courtesy period. If the customer renews the subscription within 90 days, the configuration and original tenant or venue information is retained. During and at the end of the courtesy period, the customer is presented with options to handle the lapse in subscription. The customer is also presented with the ability to resubscribe, remove devices or services that are no longer required, or gracefully exit the subscription. In addition, there will be a default method for removal of data and services in view of the lapsed customer subscription or the time frame exceeding the end of the courtesy period.

The RUCKUS One Professional tier offers a 15-day grace period to continue the Professional tier's 12-month AI data retention benefit, allowing users to upgrade or renew their Professional license in case it gets downgraded to an Essential license. This ensures the continuity of the 12-month AI data validity for Professional tier customers, which is essential for reporting and analytics purposes.

License Expiration

The following behaviors are expected of the network devices (APs, ICX Switches, and RUCKUS Edge devices) in case of a lapsed subscription.

Access points display the following expected behaviors:

- APs are removed from RUCKUS One.
- APs continue to broadcast locally available WLANs.
- APs can connect to AP registrar for direction.

Switches display the following expected behaviors:

- Switches are removed from RUCKUS One.
- Switches retain the last good configuration.
- Switches continue to pass traffic.
- Local access by means of a console or CLI or SSH is available with administrator credentials.
- Switches can connect to the device Registrar for direction.

RUCKUS Edge displays the following expected behaviors:

- RUCKUS Edge will be removed from RUCKUS One.
- RUCKUS Edge will retain the last good configuration.

- RUCKUS Edge continues to pass traffic.
- RUCKUS Edge can connect to the device Registrar for direction.

RUCKUS One License Support for SmartEdge vAppliance

The SmartEdge vAppliance utilizes standard RUCKUS One device-agnostic subscription licenses. Each SmartEdge vAppliance that you onboard, uses five RUCKUS One device-agnostic licenses. This applies to both paid and trial licenses. Unlike typical RUCKUS appliance products, the SmartEdge vAppliance does not require an RTU license.

License support for the SmartEdge vAppliance applies to the following RUCKUS One account types:

- RUCKUS One End Customers (REC)
- RUCKUS One Managed Service Providers (MSP) / Value-Added Resellers (VAR)

RUCKUS One License Support For RUCKUS IoT Controller

The RUCKUS IoT Controller utilizes standard RUCKUS One device-agnostic subscription licenses. Each RUCKUS IoT Controller that you onboard, use one RUCKUS One device-agnostic license. This applies to both paid and trial licenses.

For proper operation of the IoT solution, IoT RCAP licenses are required and must be installed directly onto the IoT Controller.

When the IoT Controller is used in conjunction with RUCKUS One, an IoT RTU license is required in addition to the RCAP license. However, this RTU license is provided at a minimal nominal cost.

License support for the RUCKUS IoT Controller applies to the following RUCKUS One account types:

- RUCKUS One End Customers (REC)
- RUCKUS One Managed Service Providers (MSP) / Value-Added Resellers (VAR)

Activating the RUCKUS One Licenses

- Subscription Activations..... 21
- Activating the RUCKUS One Licenses..... 21
- RUCKUS One Licensing Compliance..... 45

Subscription Activations

First-time users can activate their RUCKUS One subscriptions by logging in to the RUCKUS Support portal. For more information, refer to “Activating the RUCKUS One License”. Activation of a subscription can be handled by the customer upon purchase of the subscription license. Entitlements are created automatically. Once entitlements are activated on the RUCUS Support portal, there is no option to de-activate the entitlements.

Activating the RUCKUS One Licenses

You must have a RUCKUS Support Portal account (including user name and password). You can use this account to access general RUCKUS Support site content, including software upgrades, knowledge base articles, and technical documents. If you do not have a RUCKUS Support Portal account, you must register before continuing with your license activation. You can initiate the activation process by either clicking the Activation Code link in the SPA email message or using the **Activate Purchase** option on the RUCKUS Support website (<https://support.ruckuswireless.com>).

Every purchased license has its own unique activation code, and must be activated for the license to become valid and available for use by RUCKUS One. You receive the activation code in a separate Support Purchase Acknowledgment (SPA) email message for each license. Depending on the product, you may receive up to three different SPA email messages for all of your licenses.

NOTE

The first three characters of the activation code indicate the license type to which the code is applicable.

You can initiate the activation process by either clicking the Activation Code link in the SPA email message or using the **Activate Purchase** option on the RUCKUS Support website (<https://support.ruckuswireless.com>).


Activating the Essentials License for RUCKUS End Customers

Complete the following steps to active the Essentials license for a RUCKUS end customer (REC).

1. Open the SPA email message that you received from RUCKUS, and verify the End User Account information. Only a registered user can complete the activation process.

2. Click the Activation Code link in the email message.

FIGURE 1 Verifying End User Account Information




You are redirected to the RUCKUS Support website " <https://support.ruckuswireless.com>". If you are not logged in to the website, the RUCKUS Single Sign-on page is displayed.

3. Log in to the RUCKUS Single Sign-on using your credentials.

NOTE

Ensure you log in as a valid user in the End User Account. Only valid users are authorized to activate the licenses.

FIGURE 2 Logging into the Support Portal

The image shows a web browser window displaying the RUCKUS Single Sign-on login page. The RUCKUS logo, featuring a white dog silhouette and the text 'RUCKUS COMMScope', is in the top left corner. The main heading is 'RUCKUS Single Sign-on'. Below it are two input fields: 'Email' and a password field with masked characters. A 'Forgot password' link is positioned below the password field. A blue 'Log in' button is to the right. At the bottom, a link says 'Don't have an account? Join now'.

NOTE

If you are unable to activate the license due to account mismatch error, contact the Support Team using <https://support.ruckuswireless.com/contact-us>.

After a successful login, the **Activating Your Support Contract & License Code** page is displayed.

FIGURE 3 Code Validation from the Activating Your Support Contract & License Code Page

The screenshot shows the RUCKUS website interface. At the top, there's a navigation bar with links like PURCHASE SUPPORT, PROGRAMS, CONTACT, ABOUT, LMAN, CLOUD, and a user profile icon. Below this is a secondary navigation bar with links like DOCUMENTATION, DOWNLOADS, KNOWLEDGE, HOW-TO HUB, FORUMS, CASES, ASSETS, and WARRANTY. A search bar labeled 'NEW Advanced Search' is also present. The main content area is titled 'Activating Your Support Contract & License Code'. It includes instructions for activation and a form to enter a code. The code 'ACX-03712143-BEE-BIN-FEE' is entered in the 'Code' field, and the 'Validate' button is highlighted.

Because you have initiated the activation process by clicking the Activation Code link in the email message, the code is populated by default.

If you have initiated the activation process using the **Activate Purchase** option on the RUCKUS Support website "<https://support.ruckuswireless.com>", you must manually enter the activation code received in the SPA mail.

FIGURE 4 License Activation: Manual Code Entry

The screenshot shows the RUCKUS website interface. On the left, there's a sidebar with various links. The 'Activate Purchase' link is highlighted with a red box. The main content area is titled 'Activating Your Support Contract & License Code'. It includes instructions for activation and a form to enter a code. The code 'ACX-03712143-BEE-BIN-FEE' is entered in the 'Code' field, and the 'Validate' button is highlighted.

4. Click **Validate**.

After the successful validation of the license code, you can review the purchase order and user account details.

5. Accept the terms and conditions and click **Activate Purchase**.

The following page is displayed if you are activating the line item in the activation code for the first time. For subsequent license activations, this step is skipped.

FIGURE 5 Accepting Terms and Conditions

Please Review The Order

You are about to activate a RUCKUS One Subscription which is associated with below accounts.

Distributor: RUCKUS TEST DISTY
Partner: GH-VAR-1
Customer Account: GH-EU-1

Activation Code: ACX-03723422-CAT-EVE-FAN

You have logged in as:
Name: Login1 Gheu1
Email: login1@gheu1.com.masked
Ruckus Customer ID: 50543496
Company: GH-EU-1
Account Type: Enterprise

This code belongs to account:
Name: GH-EU-1

Qty	Product Code	Product Description
10	CLD-ESNT-APSW-REC1	R1 Essentials 1 AP/Sw/Edge REC 1-Yr

☐ Accept Terms and Conditions
☒ By checking accept, you hereby acknowledge and agree to the following [Terms and Conditions](#)

[Activate Purchase](#) [Cancel](#)

Activating the RUCKUS One Licenses


Activating the RUCKUS One Licenses

- Click the license entry for RUCKUS One (CLD-ESNT-APSW-REC1) to activate the license.

NOTE

A single Activation Code can carry multiple assets that are part of the original purchase order and sales order. Therefore, there may be multiple line items within one Activation Code. Each line item must be activated. For example, if you have Cloud Wi-Fi, Cloud Switching, and RUCKUS One purchased under the same purchase order, you will see three entries, and each must be activated separately.

FIGURE 6 Activating a RUCKUS One Essentials License for a REC



The **Entitling Your Asset For Support** page is displayed.

- In the **Entitling Your Asset For Support** page, select the following options:
 - The region where you want to maintain your RUCKUS One data. Currently, the supported regions are Asia, Europe, and North America.
 - The subscription start date. You can select any date within a 180-day activation grace period as the subscription start date. The dates beyond the activation grace period are disabled in the calendar.

NOTE

Once the start date is selected, the subscription end date is automatically calculated by adding the purchased subscription duration to the selected start date; thereby ensuring the full term of the subscription to the customer.


- Click **Submit Activation** to activate the license.

A confirmation dialog box is displayed.

- Click **Continue with Activation** to proceed with the selected options.

If the asset is successfully activated, a green banner with a confirmation message "Support added to serial number" is displayed.


FIGURE 7 Activation Confirmation of the Essentials License for a REC



You can click the activated product code to view the activation and subscription details.

The Essentials license subscription details for the REC are displayed.

FIGURE 8 Essentials License Subscription Details for a REC



Activating the Professional License for RUCKUS End Customers

Complete the following steps to activate the Professional license for a RUCKUS end customer (REC).

- Open the SPA email message that you received from RUCKUS, and verify the End User Account information. Only a registered user can complete the activation process.

2. Click the Activation Code link in the email message.

FIGURE 9 Verifying End User Account Information

Dear Valued Customer:

Thank you for purchasing RUCKUS One subscription.

What is this?

This is the activation email for your new RUCKUS One purchase. Please review and proceed to activate.

RUCKUS One Purchase Details

Distributor:
RUCKUS TEST DISTY

VAR:
GH-VAR-1

End User:
GH-EU-1

Subscription Start Date End Date	Quantity	Subscription SKU	Subscription Description	Serial Numbers
End User Site Reference / PO: UAT-MSP				
5/18/2023 5/18/2024	10	CLD-PROF-APSW-MSP1	R1 Pro 1 AP/Sw/Edge MSP 1-Yr	N/A

ACTION REQUIRED: You MUST click on the activation Code below to complete your registration:

- You will be required to login to RUCKUS Support Portal.
- If you don't have an account, you will be required to create one.
- If there are renewals in your order, they are automatically activated.

ACTIVATION CODE: [ACX-03723427-CAT-EVE-AXE](#)


You are redirected to the RUCKUS Support website " <https://support.ruckuswireless.com>". If you are not logged in to the website, the **RUCKUS Single Sign-on** page is displayed.

3. Log in to the RUCKUS Support portal using your credentials.

NOTE

Ensure you log in as a valid user in the End User Account. Only valid users are authorized to activate the licenses.

FIGURE 10 Logging into the Support Portal

The image shows a web browser window displaying the RUCKUS Single Sign-on login page. The RUCKUS logo, featuring a white dog silhouette and the text 'RUCKUS COMMScope', is in the top left corner. The main heading is 'RUCKUS Single Sign-on'. Below it are two input fields: 'Email' and a password field with masked characters. A 'Forgot password' link is positioned below the password field. A blue 'Log in' button is to the right of the password field. At the bottom, a link says 'Don't have an account? Join now'.

NOTE

If you are unable to activate the license due to account mismatch error, contact the Support Team using <https://support.ruckuswireless.com/contact-us>.

After a successful login, the **Activating Your Support Contract & License Code** page is displayed.

FIGURE 11 Code Validation from the Activating Your Support Contract & License Code Page

The screenshot shows the RUCKUS website interface. At the top, there is a navigation bar with links: PURCHASE SUPPORT, PROGRAMS, CONTACT, ABOUT, LMAN, CLOUD, and a user profile icon. Below this is a secondary navigation bar with links: DOCUMENTATION, DOWNLOADS, KNOWLEDGE, HOW-TO HUB, FORUMS, CASES, ASSETS, and WARRANTY. A search bar labeled 'NEW Advanced Search' is positioned below the navigation. The main content area is titled 'Activating Your Support Contract & License Code'. It includes a sub-header 'Instructions' with a list of five steps: 1. Enter your Code below. Code is case-sensitive. 2. Click "Validate" button. 3. Check your order when it displays. 4. Accept the Terms and Conditions. 5. Click "Register Code" button. Below the instructions, there is a form with a label 'Code' and a text input field containing 'ACX-03712144-BEE-BIN-GUM'. A blue 'Validate' button is to the right of the input field.

Because you have initiated the activation process by clicking the Activation Code link in the email message, the code is populated by default.

If you have initiated the activation process using the **Activate Purchase** option on the RUCKUS Support website "<https://support.ruckuswireless.com>", you must manually enter the activation code received in the SPA mail.

FIGURE 12 License Activation: Manual Code Entry

The screenshot shows the RUCKUS website interface. On the left, there is a sidebar with a list of links: Announcements, Upgrade Guides, License Management, Warranty & RMA, KB & Forums, Tools, and Asset Management. The 'Activate Purchase' link is highlighted with a red box. The main content area is titled 'Activating Your Support Contract & License Code'. It includes a sub-header 'Instructions' with a list of five steps: 1. Enter you Code below. Code is case-sensitive. 2. Click "Validate" button. 3. Check your order when it displays. 4. Accept the Terms and Conditions. 5. Click "Register Code" button. Below the instructions, there is a form with a label 'Code' and a text input field containing 'ACX-03712143-BEE-BIN-FEE'. A blue 'Validate' button is to the right of the input field.

4. Click **Validate**.

After the successful validation of the license code, you can review the purchase order and user account details.

5. Accept the terms and conditions and click **Activate Purchase**.

The following page is displayed if you are activating the line item in the activation code for the first time. For subsequent license activations, this step is skipped.

FIGURE 13 Accepting Terms and Conditions

Please Review The Order

You are about to activate a RUCKUS One Subscription which is associated with below accounts.

Distributor: RUCKUS TEST DISTY
Partner: GH-VAR-1
Customer Account: GH-EU-1

Activation Code: ACX-03723427-CAT-EVE-AXE

You have logged in as:
Name: Login1 Gheu1
Email: login1@gheu1.com.masked
Ruckus Customer ID: 50543496
Company: GH-EU-1
Account Type: Enterprise

This code belongs to account:
Name: GH-EU-1

Qty	Product Code	Product Description
10	CLD-PROF-APSW-MSP1	R1 Pro 1 AP/Sw/Edge MSP 1-Yr

☐ Accept Terms and Conditions
☒ By checking accept, you hereby acknowledge and agree to the following [Terms and Conditions](#)

6. Click the license entry for RUCKUS One (CLD-PROF-APSW-REC1) to activate the license.

NOTE

A single Activation Code can carry multiple assets that are part of the original purchase order and sales order. Therefore, there may be multiple line items within one Activation Code. Each line item must be activated. For example, if you have Cloud Wi-Fi, Cloud Switching, and RUCKUS One purchased under the same purchase order, you will see three entries, and each must be activated separately.

FIGURE 14 Activating a RUCKUS One Professional License for a REC

[DOCUMENTATION](#)
[DOWNLOADS](#)
[KNOWLEDGE](#)
[HOW-TO HUB](#)
[FORUMS](#)
[CASES](#)
[ASSETS](#)
[WARRANTY](#)

[» Support Activations](#) » ACX-03723426-CAT-EVE-AID

ACX-03723426-CAT-EVE-AID

RUCKUS One Activation Details

Product Code	Product Name	Purchased Quantity	Activated?
CLD-PROF-APSW-REC1	R1 Pro 1 AP/Sw/Edge REC 1-Yr	10	NO

The **Entitling Your Asset For Support** page is displayed.

Activating the RUCKUS One Licenses

Activating the RUCKUS One Licenses

7. In the **Entitling Your Asset For Support** page, select the following options:

- The region where you want to maintain your RUCKUS One data. Currently, the supported regions are Asia, Europe, and North America.
- The subscription start date. You can select any date within a 180-day activation grace period as the subscription start date. The dates beyond the activation grace period are disabled in the calendar.

NOTE

Once the start date is selected, the subscription end date is automatically calculated by adding the purchased subscription duration to the selected start date; thereby ensuring the full term of the subscription to the customer.

FIGURE 15 Entitling Assets

[Always Hide Instructions](#)

Step 2 Of 2

Select the region for your RUCKUS One subscription

☐ Asia

☐ Europe

☒ North America

Select Max grace period Date for your RUCKUS One subscription

(End Date is auto-calculated based on the selected Start Date; thereby ensuring the full term of the purchased subscription.)

50 subscription licenses will be activated.

To activate, click "Submit Activation"

Current Cloud Subscriptions

Name	Start Date	End Date
------	------------	----------

Support Info

Important:

If you are activating your first purchased license and currently have a Cloud trial account, you will experience a short network downtime (up to 30mins) when your trial network is migrated to a production network. Please delay this activation process to better manage the network down time. If you are adding more licenses to your existing production cloud Wi-Fi account, there will be no impact to your Wi-Fi network.

SPA Code: ACX-03724953-KEA-KID-BID

Product Code: CLD-PROF-APSW-REC1

Product Class: ACX-PROF-NEW

Product Name: R1 Pro 1 AP/SW REC 1-Yr


Purchased Quantity: 50

To Be Activated: 1

Quantity Activated: 0

8. Click **Submit Activation** to activate the license.
A confirmation dialog box is displayed.

FIGURE 16 Confirmation Dialog Box




Activating the RUCKUS One Licenses

Activating the RUCKUS One Licenses

9. Click **Continue with Activation** to proceed with the selected options.
- If the asset is successfully activated, a green banner with a confirmation message "Support added to serial number" is displayed.


FIGURE 17 Activation Confirmation of the Professional License for a REC



You can click the activated product code to view the activation and subscription details.

The Professional license subscription details for the REC are displayed.

FIGURE 18 Professional License Subscription Details for a REC



Activating the License for a RUCKUS Managed Service Provider

Complete the following steps to activate the Managed Service Provider (MSP) license.

1. Open the SPA email message that you received from RUCKUS, and verify the End User Account information. Only a registered user can complete the activation process.

2. Click the Activation Code link in the email message.

FIGURE 19 Verifying End User Account Information

Dear Valued Customer:

Thank you for purchasing RUCKUS One subscription.

What is this?

This is the activation email for your new RUCKUS One purchase. Please review and proceed to activate.

RUCKUS One Purchase Details				
Distributor: RUCKUS TEST DISTY	VAR: GH-VAR-1	End User: GH-EU-1		

Subscription Start Date End Date	Quantity	Subscription SKU	Subscription Description	Serial Numbers
End User Site Reference / PO: UAT-MSP				
5/18/2023 5/18/2024	10	CLD-PROF-APSW-MSP1	R1 Pro 1 AP/Sw/Edge MSP 1-Yr	N/A

ACTION REQUIRED: You MUST click on the activation Code below to complete your registration:

- You will be required to login to RUCKUS Support Portal.
- If you don't have an account, you will be required to create one.
- If there are renewals in your order, they are automatically activated.

ACTIVATION CODE: [ACX-03723427-CAT-EVE-AXE](#)

You are redirected to the RUCKUS Support website " <https://support.ruckuswireless.com>". If you are not logged in to the website, the **RUCKUS Single Sign-on** page is displayed.

Activating the RUCKUS One Licenses


Activating the RUCKUS One Licenses

3. Log in to the RUCKUS Support portal using your credentials.

NOTE

Ensure you log in as a valid user in the End User Account. Only valid users are authorized to activate the licenses.

FIGURE 20 Logging into the Support Portal

The image shows a web browser window displaying the RUCKUS Single Sign-on login page. The RUCKUS logo, featuring a white dog silhouette and the text 'RUCKUS COMMScope', is in the top left corner. The main heading is 'RUCKUS Single Sign-on'. Below it are two input fields: 'Email' and a password field with masked characters. A 'Forgot password' link is positioned below the password field. A blue 'Log in' button is to the right. At the bottom, a link says 'Don't have an account? Join now'.

NOTE

If you are unable to activate the license due to account mismatch error, contact the Support Team using <https://support.ruckuswireless.com/contact-us>.

After a successful login, the **Activating Your Support Contract & License Code** page is displayed.

FIGURE 21 Code Validation from the Activating Your Support Contract & License Code Page

The screenshot shows the RUCKUS website interface. At the top, there's a navigation bar with links like PURCHASE SUPPORT, PROGRAMS, CONTACT, ABOUT, LMAN, CLOUD, and a user profile icon. Below this is a secondary navigation bar with links like DOCUMENTATION, DOWNLOADS, KNOWLEDGE, HOW-TO HUB, FORUMS, CASES, ASSETS, and WARRANTY. A search bar labeled 'NEW Advanced Search' is also present. The main content area is titled 'Activating Your Support Contract & License Code'. It includes instructions for activation and a form to enter a code. The code 'ACX-03712143-BEE-BIN-FEE' is entered in the 'Code' field, and the 'Validate' button is highlighted.

Because you have initiated the activation process by clicking the Activation Code link in the email message, the code is populated by default.

If you have initiated the activation process using the **Activate Purchase** option on the RUCKUS Support website "<https://support.ruckuswireless.com>", you must manually enter the activation code received in the SPA mail.

FIGURE 22 License Activation: Manual Code Entry

The screenshot shows the RUCKUS website interface. On the left, there's a sidebar with various links. The 'Activate Purchase' link is highlighted with a red box. The main content area is titled 'Activating Your Support Contract & License Code'. It includes instructions for activation and a form to enter a code. The code 'ACX-03712143-BEE-BIN-FEE' is entered in the 'Code' field, and the 'Validate' button is highlighted.

4. Click **Validate**.

After the successful validation of the license code, you can review the purchase order and user account details.

5. Accept the terms and conditions and click **Activate Purchase**.

The following page is displayed if you are activating the line item in the activation code for the first time. For subsequent license activations, this step is skipped.

FIGURE 23 Accepting Terms and Conditions

Please Review The Order

You are about to activate a RUCKUS One Subscription which is associated with below accounts.

Distributor: RUCKUS TEST DISTY

Partner: GH-VAR-1

Customer Account: GH-EU-1

You have logged in as:

Name: Login1 Gheu1

Email: login1@gheu1.com.masked

Ruckus Customer ID: 50543496

Company: GH-EU-1

Account Type: Enterprise

Activation Code: ACX-03723427-CAT-EVE-AXE

This code belongs to account:

Name: GH-EU-1

Qty	Product Code	Product Description
10	CLD-PROF-APSW-MSP1	R1 Pro 1 AP/Sw/Edge MSP 1-Yr

☐ Accept Terms and Conditions

☒ By checking accept, you hereby acknowledge and agree to the following [Terms and Conditions](#)

Activate Purchase

Cancel

6. Click the license entry for RUCKUS One (CLD-PROF-APSW-MSP1) to activate the license.

NOTE

A single Activation Code can carry multiple assets that are part of the original purchase order and sales order. Therefore, there may be multiple line items within one Activation Code. Each line item must be activated. For example, if you have Cloud Wi-Fi, Cloud Switching, and RUCKUS One purchased under the same purchase order, you will see three entries, and each must be activated separately.

FIGURE 24 Activating a RUCKUS One Professional License for a RUCKUS MSP

DOCUMENTATION | DOWNLOADS | KNOWLEDGE | HOW-TO HUB | FORUMS | CASES | ASSETS | WARRANTY

» Support Activations » ACX-03723427-CAT-EVE-AXE

NEW Advanced Search

ACX-03723427-CAT-EVE-AXE

RUCKUS One Activation Details

Product Code	Product Name	Purchased Quantity	Activated?
CLD-PROF-APSW-MSP1	R1 Pro 1 AP/Sw/Edge MSP 1-Yr	10	NO

The **Entitling Your Asset For Support** page is displayed.

7. In the **Entitling Your Asset For Support** page, select the following options:
 - The region where you want to maintain your RUCKUS One data. Currently, the supported regions are Asia, Europe, and North America.
 - The subscription start date. You can select any date within a 180-day activation grace period as the subscription start date. The dates beyond the activation grace period are disabled in the calendar.

NOTE


Once the start date is selected, the subscription end date is automatically calculated by adding the purchased subscription duration to the selected start date; thereby ensuring the full term of the subscription to the customer.

8. Click **Submit Activation** to activate the license.

A confirmation dialog box is displayed.

9. Click **Continue with Activation** to proceed with the selected options.
- If the asset is successfully activated, a green banner with a confirmation message "Support added to serial number" is displayed.


FIGURE 25 Activation Confirmation of a Professional License for a RUCKUS MSP



You can click the activated product code to view the activation and subscription details.

The Professional license subscription details for the RUCKUS MSP are displayed.

FIGURE 26 Professional License Subscription Details for a RUCKUS MSP



Activating Licenses for RUCKUS End Customers from the RUCKUS One Web Interface

RUCKUS One allows you to activate your license subscriptions from within the RUCKUS One web interface. Every purchased subscription must be activated for the subscription to become active and usable.

Follow these steps to activate a subscription license from the web interface:

1. On the RUCKUS One web interface, navigate to **Administration > Account Management > Subscriptions**.

The **Subscriptions** page provides access to information about subscriptions already activated and those that are pending activation.

The **My Subscriptions** tab displays utilization of your paid, trial, and assigned subscription licenses in the context of number of licenses in use versus the total number of licenses available by the subscriptions. Subscription-specific information is displayed in table format, including the RUCKUS part number, the number of licenses, the start and expiry dates, time remaining, and status. The Manage Subscriptions option allows you to view and manage cloud subscription purchases via the RUCKUS Support website.

2. Click the **Pending Activations** tab.

The **Pending Activations** tab displays information about license purchases that are pending activation. You can activate pending license subscriptions from this tab.

FIGURE 27 Activating Pending Subscriptions

Order Date	SPA Activation Code	Part Number	Part Number Description	Quantity	Subscription Term	Last Day of Grace Activation
08/30/2024	ACX-03734659-EMU-KID-BAG	CLD-R1-TMP090	RUCKUS One Trial 90-Day	30	3 mos	--
		CLD-R1-TMP090	RUCKUS One Trial 90-Day	40	3 mos	--
05/30/2024	ACX-03731118-CAT-KID-AXE	CLD-ESNT-APSW-EDU5	R1 Essentials 1 AP/SW EDU 5-Yr	50	60 mos	05/30/2024
		CLD-PROF-APSW-BDG1	R1 Pro 1 AP/SW MSP BDG 1-Yr	160	12 mos	05/30/2024
		CLD-PROF-APSW-BDG3	R1 Pro 1 AP/SW MSP BDG 3-Yr	170	36 mos	05/30/2024
		CLD-PROF-APSW-BDG5	R1 Pro 1 AP/SW MSP BDG 5-Yr	180	60 mos	05/30/2024
		CLD-PROF-APSW-EDU3	R1 Pro 1 AP/SW EDU 3-Yr	90	36 mos	05/30/2024

The following information is displayed:

- **Order Date:** Displays the date on which the subscription was purchased.
 - **SPA Activation Code:** Displays the RUCKUS activation code for your purchase order, which can contain one or more license Part Numbers. The activation code is an interactive link that allows you to activate the associated subscriptions through the RUCKUS Support Portal. The **SPA Activation Code** is unique to a Sales Order.
 - **Part Number:** Displays the subscription SKU.
 - **Part Number Description:** Displays a brief description that reflects the license subscription type and term length. For example, **CLD-PROF-APSW-REC3** is a RUCKUS One Professional tier license for one network device (AP or switch) for a RUCKUS End Customer (REC) for three years.
 - **Quantity:** Displays the Part Number quantity that was purchased.
 - **Subscription Term:** Displays the duration of the purchased subscription in months.
 - **Last of Grace Activation Period :** Displays the last date by which you can select a specific start date for your subscription. If you activate your subscription on or before this date, you may select any start date from the current date to through the **Activation Period Ends** date. If you activate your subscription after this date, then the start date is automatically set to the **Activation Period Ends** date.
3. Click a specific **SPA Activation Code** to activate the purchased Part Numbers. You will be redirected to the RUCKUS Support portal to perform the activation.

4. Click a specific **Part Number** to activate the purchased Part Numbers from the RUCKUS One web interface.

The **Activate Purchase** page is displayed.

5. Select the region for the RUCKUS One hosted cloud service. Options include Asia, Europe, and North America.
6. Select the start date for the service.

The **Last of Grace Activation Period** field is not applicable for trial licenses. For paid licenses, this field is populated with the date till when the license is active. Ensure that you activate the license before this date.

7. Click the checkbox to accept the RUCKUS One terms and conditions.
8. Click **Activate**.

A notification appears confirming the successful activation of the license, with additional details available in the **Activities** page. The newly activate license information is displayed in **Subscriptions > My Subscriptions**. Click **Refresh** to see the latest subscriptions.

Activating Licenses for Managed Service Providers from the RUCKUS One Web Interface

RUCKUS One allows Managed Service Providers (MSPs) to activate license subscriptions from within the RUCKUS One web interface. Every purchased subscription must be activated for the subscription to become active and usable.

Follow these steps to activate a subscription license from the web interface:

1. On the RUCKUS One web interface, select **Subscriptions** on the main menu.

The **Subscriptions** page is displayed.

The **MSP Subscriptions** tab displays utilization of paid subscriptions in the context of device count by MSP End Customer (EC), MSP Assigned, and Available. Subscription-specific information is displayed in table format, including the RUCKUS part number, the number of devices supported, the start and expiry dates, time remaining, and status.

The **Generate Usage Report** option allows you to create and download a subscription usage report for which selectable criteria include time period, format, and customer base.

The **Manage Subscriptions** option allows you to view and manage cloud subscription purchases via the RUCKUS Support website.

The **MSP Assigned Subscriptions** tab displays utilization of paid subscriptions and trial subscriptions, in the context of device count by MSP EC, MSP Assigned, and Available.

Subscription-specific information is displayed in table format, including the subscription name, the number of devices supported, the start and expiry dates, time remaining, and status.

You can assign the number of devices, and the start and expiration dates for the subscription, by clicking **Assign MSP Subscriptions**.

The **Pending Activations** tab displays information about license purchases that are pending activation. You can activate pending licenses from this tab.

- Click the **Pending Activations** tab.

FIGURE 28 Activating Pending Subscriptions

Subscriptions							Manage My Account
MSP Subscriptions	MSP Assigned Subscriptions	Pending Activations	Compliance				
Order Date	SPA Activation Code	Part Number	Part Number Description	Quantity	Subscription Term	Last Day of Grace Activation Period	
07/03/2024	ACK-03731690-ELK-ADD-FEE	CLD-ESNT-APSW-REC1	R1 Essentials 1 AP/SW REC 1-Yr	10	12 mos	12/30/2024	
		CLD-ESNT-APSW-REC3	R1 Essentials 1 AP/SW REC 3-Yr	20	36 mos	12/30/2024	
		CLD-ESNT-APSW-RECS	R1 Essentials 1 AP/SW REC 5-Yr	30	60 mos	12/30/2024	
		CLD-PROF-APSW-BDG1	R1 Pro 1 AP/SW MSP BDG 1-Yr	160	12 mos	12/30/2024	
		CLD-PROF-APSW-BDG3	R1 Pro 1 AP/SW MSP BDG 3-Yr	170	36 mos	12/30/2024	
		CLD-PROF-APSW-BDG5	R1 Pro 1 AP/SW MSP BDG 5-Yr	180	60 mos	12/30/2024	
		CLD-PROF-APSW-EDU3	R1 Pro 1 AP/SW EDU 3-Yr	90	36 mos	12/30/2024	
		CLD-PROF-APSW-EDU5	R1 Pro 1 AP/SW EDU 5-Yr	100	60 mos	12/30/2024	
		CLD-PROF-APSW-MSP1	R1 Pro 1 AP/SW MSP 1-Yr	110	12 mos	12/30/2024	
		CLD-PROF-APSW-MSP3	R1 Pro 1 AP/SW MSP 3-Yr	120	36 mos	12/30/2024	

The following information is displayed:

- **Order Date:** Displays the date on which the subscription was purchased.
 - **SPA Activation Code:** Displays the RUCKUS activation code for your purchase order, which can contain one or more license Part Numbers. The activation code is an interactive link that allows you to activate the associated subscriptions through the RUCKUS Support Portal. The **SPA Activation Code** is unique to a Sales Order.
 - **Part Number:** Displays the subscription SKU.
 - **Part Number Description:** Displays a brief description that reflects the license subscription type and term length. For example, **CLD-PROF-APSW-REC3** is a RUCKUS One Professional tier license for one network device (AP or switch) for a RUCKUS End Customer (REC) for three years.
 - **Quantity:** Displays the Part Number quantity that was purchased.
 - **Subscription Term:** Displays the duration of the purchased subscription in months.
 - **Last of Grace Activation Period :** Displays the last date by which you can select a specific start date for your subscription. If you activate your subscription on or before this date, you may select any start date from the current date to through the **Activation Period Ends** date. If you activate your subscription after this date, then the start date is automatically set to the **Activation Period Ends** date.
- Click **SPA Activation Code** to activate the purchased Part Numbers. You will be redirected to the RUCKUS support portal to perform the activation.
 - Click a specific **Part Number** to activate the purchased Part Numbers from the RUCKUS One web interface.
The **Activate Purchase** page is displayed.
 - Select the checkbox next to **I accept the Terms and Conditions**.
 - Click **Activate**.
 - Select the region for the RUCKUS One hosted cloud service. Options include Asia, Europe, and North America.

8. Select the start date for the service.

The **Last of Grace Activation Period** field is not applicable for trail licenses. For paid licenses, this field is populated with the date till when the license is active. Ensure that you activate the license before this date.


9. Click the checkbox to accept the RUCKUS One terms and conditions.

10. Click **Activate**.

A notification appears confirming the successful activation of the license, with additional details available in the **Activities** page. The newly activate license information is displayed in **Subscriptions > My Subscriptions**. Click **Refresh** to see the latest subscriptions.

RUCKUS One users with a **Prime Admin** role receive an email notification as shown.

FIGURE 29 Sample Email



RUCKUS One Licensing Compliance


The **Compliance** page offers a detailed overview of the RUCKUS One licenses that are allocated, utilized, and available for networking devices.

License Compliance for RUCKUS One End Customers

To view the RUCKUS One End Customers (REC) license compliance for networking devices, navigate the main menu, selecting **Administration > Subscriptions**, then click the **Compliance** tab.

The **Compliance** page is displayed.

FIGURE 30 RUCKUS One End Customer License Compliance



On the **Compliance** page, the **Device Networking Subscriptions** tile displays license utilization, allocation, and availability details for your networking devices. The tile contains a visual indicator; a green check means licenses are still available, a red exclamation mark indicates there is a shortage of licenses. The tile also contains the following licensing details:


- **Devices:** Devices supported by RUCKUS One licenses. For example: Access Points, Switches, SmartEdge vAppliances, and RWGs.
- **Configured:** The number of configured devices, per device type, configured in RUCKUS One.
- **Licenses Used:** The number of RUCKUS One licenses used by each device type.
- **Active Paid Licenses:** The number of RUCKUS One licenses which were purchased and are effective, along with the license count expected to expire soon and the date of expiry.
- **Active Trial Licenses:** The number of RUCKUS One trial licenses purchased which are effective, along with the license count expected to expire soon and the date of expiry.
- **Licenses Used:** The total number of licenses used by all the devices, which includes paid and trial licenses.
- **Licenses Available / Gap:** The difference between the number of licenses purchased and the number of licenses used. A positive number in green indicates available licenses, including both paid and trial. A negative number, such as -11 in red, indicates a shortage of licenses.

Compliance for RUCKUS One Managed Service Providers

To view the RUCKUS One Managed Service Providers (MSP) license compliance for networking devices, on the main menu, select **Subscriptions**, then click the **Compliance** tab.

The **Compliance** page is displayed.

FIGURE 31 MSP License Compliance



On the **Compliance** page, the **Device Networking Subscriptions** tiles display license utilization, allocation, and availability details for the account types under MSP purview. Each tile contains a visual indicator; a green check means licenses are still available, a red exclamation mark indicates there is a shortage of licenses. The tiles also contain the following licensing details:

My Account License Expiration (the MSP's own account)

- **Devices:** Devices supported by RUCKUS One licenses. For example: Access Points, Switches, SmartEdge vAppliances, and RWGs.
- **Configured:** The number of configured devices, per device type, configured in RUCKUS One.
- **Licenses Used:** The number of RUCKUS One licenses used by each device type.
- **Active Paid Licenses:** The number of RUCKUS One licenses which were purchased and are effective, along with the license count expected to expire soon and the date of expiry.
- **Active Trial Licenses:** The number of RUCKUS One trial licenses purchased by the MSP which are effective, along with the license count expected to expire soon and the date of expiry.
- **Assigned Paid Licenses:** The number of RUCKUS One purchased license assigned to the MSP's own account.
- **Assigned Trial Licenses:** The number of RUCKUS One trial licenses assigned to the MSP's own account.
- **Licenses Used:** The total number of licenses used by all the devices, which includes paid, trial, and assigned licenses.
- **Licenses Available / Gap:** The difference between the number of licenses purchased and the number of licenses used. A positive number in green indicates available licenses, including both paid and trial. A negative number, such as -11 in red, indicates a shortage of licenses.

MSP Customers License Expiration

- **Devices:** Devices supported by RUCKUS One licenses. For example: Access Points, Switches, SmartEdge vAppliances, and RWGs.
- **Configured:** The number of configured devices, per device type, configured in RUCKUS One.
- **Licenses Used:** The number of RUCKUS One licenses used by each device type.

Activating the RUCKUS One Licenses

RUCKUS One Licensing Compliance

- **Active Paid Licenses:** The number of RUCKUS One licenses which were purchased and are effective, along with the license count expected to expire soon and the date of expiry.
- **Licenses Used:** The total number of licenses used by all the devices, which includes paid and trial licenses.
- **Licenses Available / Gap:** The difference between the number of licenses purchased and the number of licenses used. A positive number in green indicates available licenses, including both paid and trial. A negative number, such as -11 in red, indicates a shortage of licenses.

Viewing Licenses


- Viewing the Licenses for RUCKUS End Customers in the RUCKUS One Cloud Portal..... 49
- Viewing the Licenses for MSP Customers in the RUCKUS One Cloud Portal..... 51

Viewing the Licenses for RUCKUS End Customers in the RUCKUS One Cloud Portal

You can view the REC licenses in the RUCKUS One Cloud portal after they are activated.
Complete the following steps to view the activated REC licenses in the RUCKUS One Cloud portal.

1. Log in to the RUCKUS One Cloud portal.
The RUCKUS One dashboard is displayed.


FIGURE 32 RUCKUS One Dashboard



Viewing Licenses
Viewing the Licenses for RUCKUS End Customers in the RUCKUS One Cloud Portal


- 2. Click **Administration > Subscriptions**.

FIGURE 33 Navigating to the Subscriptions Page



The **Subscriptions** page is displayed.

FIGURE 34 Viewing License Subscriptions for a REC



In the **Subscriptions** page, you can view the following subscription details:

- **Subscription:** The network device utilizing the subscription.

- **Part Number:** The part number of the purchased subscription.
 - **Device Count:** The number of licenses associated with the license subscription.
 - **Starting Date:** The starting date of the subscription.
 - **Expiration Date:** The date the subscription expires.
 - **Time Left:** The time remaining before the subscription expires.
 - **Status:** The status of the license subscription (active or inactive).
3. (Optional) Click **Manage Subscriptions** to go to the **Subscription** web page.
 4. Click **Refresh** to view any new licenses added in the **Subscriptions** page (for example, when additional licenses are activated).

Viewing the Licenses for MSP Customers in the RUCKUS One Cloud Portal

You can view the MSP licenses in the RUCKUS One Cloud portal after they are activated.

Complete the following steps to view the activated MSP licenses in the RUCKUS One Cloud portal.

1. Log in to the RUCKUS One Cloud portal for an MSP account.

The **MSP Customers** page is displayed with information about the MSP customers.

FIGURE 35 Viewing the MSP Customers


Customers	Status	Address	MSP Admin Count	Integrator	Installer	Wi-Fi Licenses	Wi-Fi License Utilization	Switch Licenses	Active From	Service Expires On
1	Trial		1	Integrator	-	25	0%	25	04/25/2023	05/25/2023

Viewing Licenses

Viewing the Licenses for MSP Customers in the RUCKUS One Cloud Portal

- 2. From the navigation bar, click **Subscriptions** to view the MSP subscriptions.

FIGURE 36 Viewing the MSP Subscriptions



- 3. To add an MSP customer account, from the navigation bar, select **My Customers > MSP Customers**. In the **MSP Customers** page, click **Add Customer**.

The **Add Customer Account** page is displayed.

FIGURE 37 Account Details Page

RUCKUS R

US

My Customers | Tech Partners | Device Inventory | Subscriptions

Customers / Add Customer Account

Account Details

Customer Name *

Address *

Set address here

MSP Administrators: ruckusonetest007@gmail.com (Prime Ad... Manage)

Integrator: — Manage

Installer: — Manage

Customer Administrator

Email *

First Name * Last Name *

Role *

Prime Admin

Cancel Back Next

- 4. In the **Customer Name** field, enter the name of the customer.
- 5. In the **Address** field, enter the customer address.
- 6. For **MSP Administrators**, click **Manage** and select an MSP administrator.
- 7. (Optional) Toggle the **Customer Administrator** option to add a customer administrator
- 8. Under the **Customer Administrator** section, enter the email address in the **Email** field.
- 9. In the **First Name** and **Last Name** fields, enter the first and the last name of the administrator.
- 10. In the **Role** list, select a role and click **Next**.

11. In the **Subscriptions** page, by default, **Trial Mode** is selected. The **Trial Mode** subscription is valid for 30 days from the date of activation. You can upgrade from **Trial Mode** to **Paid Subscription**.
12. For **Paid Subscription**, specify the number of devices and service expiration date and click **Next**.

FIGURE 38 Subscriptions

The screenshot displays the 'Add Customer Account' interface. At the top, the breadcrumb 'My Customers / MSP Customers /' is visible. The main heading is 'Add Customer Account'. On the left, a vertical progress bar shows three steps: 'Account Details', 'Subscriptions' (which is highlighted with an orange dot), and 'Summary'. The 'Start service in' section has two radio buttons: 'Trial Mode' (unselected) and 'Paid Subscription' (selected). Below this, the 'Paid Subscriptions' section contains a 'Device Networking' input field with the value '0' and the text 'licenses out of 49 available'. The 'Service Start Date' is set to '08/21/2024'. The 'Service Expiration Date' section includes a dropdown menu currently showing 'Custom date' and a 'Select date' button with a calendar icon. At the bottom of the form, there are three buttons: 'Cancel', 'Back', and 'Next' (which is highlighted in orange).


13. On the **Summary** page, review the customer information and click **Add Customer**.

Viewing Licenses

Viewing the Licenses for MSP Customers in the RUCKUS One Cloud Portal


14. To view the RUCKUS One Cloud dashboard, click **My Customers** > **MSP Customers** > **Manage My Account**.

FIGURE 39 Using the Manage My Account Option




The RUCKUS One dashboard is displayed.

FIGURE 40 RUCKUS One Dashboard




15. Click **My Customers** > **VAR Customers** to view the information about VAR customers.

FIGURE 41 Selecting the VAR Customers



The **VAR Customers** page is displayed.

FIGURE 42 Viewing the VAR Customers



The **VAR Customers** page displays the account information of the VAR customers who have been sent invites to become administrators. To invite VAR customers, refer to the *RUCKUS One MSP Guide*.



© 2026 Vistance Networks, Inc. All rights reserved.
350 West Java Dr., Sunnyvale, CA 94089 USA
<https://www.ruckusnetworks.com>