






## USB





Raspberry Pi  
RP2350A QFN-60




## 12MHz Clock



## Flash



## Status Bar



Sheet: /MCU/  
File: MCU.kicad\_sch

Title: AuraMon

Size: A4 Date:  
KiCad E.D.A. 9.0.2

Rev: v0.1  
Id: 2/7

1 2 3 4 5 6

A

A

B


B

C

C

D

D





Sheet: /Modbus/  
File: Modbus.kicad\_sch

**Title: AuraMon**


Size: A4 Date:  
KiCad E.D.A. 9.0.2

Rev: v0.1  
Id: 3/7

1 2 3 4 5 6



## 25MHz Clock




Sheet: /LAN/  
File: LAN.kicad\_sch

**Title:** AuraMor

Size: A4 Date: KiCad E.D.A. 9.0.2

Rev: v0.1  
Id: 4/7




1 2 3 4 5 6

A

B

C

D



Sheet: /Power/  
File: Power.kicad\_sch





**Title: AuraMon**

Size: A4 Date:  
KiCad E.D.A. 9.0.2

**Rev: v0.1**  
Id: 6/7

1 2 3 4 5 6

1 2 3 4 5 6

**Reset****Indicators****Bus Bar****Pair**

Sheet: /Control/  
File: Control.kicad\_sch

**Title: AuraMon**

Size: A4 Date:  
KiCad E.D.A. 9.0.2

**Rev: v0.1**  
Id: 7/7

1 2 3 4 5 6