



Example of a 92PE pulse

Example of a 55PE pulse




Example of a 34PE pulse

Example of a 35PE pulse




Example of a 92PE pulse


Example of a 110PE pulse




Example of a 60PE pulse

Example of a 58PE pulse









Example of a 90PE pulse


Example of a 82PE pulse







Example of a 52PE pulse

Example of a 71PE pulse










Example of a 21PE pulse

Example of a 20PE pulse









Example of a 98PE pulse

Example of a 70PE pulse




Example of a 72PE pulse

Example of a 55PE pulse



Example of a 51PE pulse

Example of a 53PE pulse



Example of a 78PE pulse

Example of a 54PE pulse