













## 1185 PE distribution x=0mm y=0mm Example of a 22PE pulse Example of a 183PE pulse run 1185 merged 767 events 1220 1225 1230 1235 1240 1245 Time [ns] Time [ns] Example of a 101PE pulse Example of a 20PE pulse ADC -PΕ 1205 210 215 220 225 230 235 240 245 1205 210 215 220 225 230 235 240 245

Time [ns]

Time [ns]

Counts Counts















